

Original

AMGO® Hydraulics

Installation And Service Manual



FLUSH-MOUNT SCISSORS LIFT

XL-9F

CONTENTS

Product Features and Specifications	1
Installation Requirement	2
Steps of Installation.....	4
Exploded View	11
Test Run.....	19
Operation Instruction	20
Maintenance	21
Trouble Shooting	22
Lift Disposal.....	22

I. PRODUCT FEATURES AND SPECIFICATIONS (See Fig.1)

FLUSH-MOUNT SCISSORS MODEL XL-9F

- Electronic control operating system, friendly to use.
- Dual self-lock mechanism.
- Dual cylinders automatic synchronization system.
- Dual self-lock mechanical safety system.
- Double Extended platforms.
- Photo cell protection.



Fig. 1

MODEL XL-9F SPECIFICATIONS

Model	Lifting Capacity	Lifting Height	Lifting Time	Overall Length	Overall Width	Runway Width	Width Between runways	Motor
XL-9F	9000lbs	87-3/4"	49S	65"~80-3/4"	74-3/4"	21-5/8"	31-1/2"	2.0HP

II. INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

- ✓ Rotary Hammer Drill
($\Phi 19$ 、 $\Phi 10$ 、 $\Phi 4$)



- ✓ Hammer



- ✓ Level Bar



- ✓ English Spanner (12")



- ✓ Wrench set (15#, 17#)



- ✓ Grease gun



- ✓ Carpenter's Chalk



- ✓ Screw Sets



- ✓ Tape Measure (7.5m)



- ✓ Pliers



- ✓ Lock Wrench



- ✓ Ratchet Spanner with Socket



Fig. 2

B. Equipment storage and installation requirements.

The equipment should be stored or installed in a shady, normal temperature, ventilated and dry place.

C. SPECIFICATIONS OF CONCRETE

**Specifications of concrete must be adhere to the specifications as following.
Failure to do so may result in lift and/or vehicle falling.**

1. Lift Location: Always use architect plans when available. Check layout dimension against floor plan requirements and make sure that adequate space is available.
2. Overhead Obstructions: The area where the lift will be located should be free of overhead obstructions such as heaters, building supports, electrical lines etc.
3. Concrete: Visually inspect the site where the lift is to be installed and check for cracked or defective concrete. All models must be installed on 3000psi (210kg/cm²) minimum concrete with a minimum thickness 6".

D. POWER SUPPLY

The electrical source must be 2.0HP minimum. The source cable size must be 2.5mm² and in good condition of contacting with floor.

WARNING !

A level floor is recommended for proper installation and level adjustment. Small differences in floor slopes may be compensated by shim. If a floor is of questionable slope, consider pouring a new concrete slab.

- ✓ **DO NOT** install this lift on any asphalt surface or any surface other ground than concrete.
- ✓ **DO NOT** install this lift on expansion seams or on cracked or defective concrete.
- ✓ **DO NOT** install this lift on a second/elevated floor without first consulting build architect.
- ✓ **DO NOT** install this lift outdoors unless special consideration has been made to

protect the power unit from weather conditions.

III. STEPS OF INSTALLATION

A. Location of installation (See Fig. 3)

Review the layout as shown below and select a location that is best suited for your application. Be sure to use the dimensions that are applicable to your lift model.





Fig. 3

- Note:** 1. Concrete must be thickness 6" minimum and must be of test strength 3,000psi (210kg/cm²) minimum.
2. All the tubes must be Φ2 PVC tube.

B. Check the parts before assembly, make sure all the parts are well received .

1. Packaged lift, parts box, control cabinet (**See Fig.4**).



2. Move the parts aside, open the outer packing and check the parts according to the shipment parts list (**See Fig. 5**).




Fig. 5

3. Open the parts box, check the parts according to the part list (**See Fig. 6**).



Fig. 6

4. Check the parts of the parts bag according to the parts bag list (**See Fig. 7**).




Fig. 7

C. Layout the machine and install oil system and air line system.

1. Layout the equipment with forklift or other equipment to the location according to **Step B**. Lift the equipment to about 1 meter high for oil system and air line system installation (See Fig. 8).




Fig. 8

2. Locate the cabinet control to the preserved place, install relevant air lines and wires through the embedded PVC pipe
3. Connecting the oil hose and air line (See Fig. 9).





Fig. 9

4. Install the oil-water separator (See Fig. 10).



D. Install electric system

1. Wire connection for 220V hydraulic power unit

1.1. Connect the power wire and limit switch wire according to the Wiring diagram (See Fig. 11).




Fig. 11

1.2 Circuit Diagram (See Fig. 12)




Fig. 12

Electric Component 220V

Item	Name	Code	Specification
1	Power switch	QS	25A
2	Breaker	FU ₁	2P
3	Breaker	FU ₂	1P
4	AC contactor	KM	16A 24V AC
5	Intermediate Relay	KA2	24V AC
6	Time relay	KT	24V AC
7	Limit switch (high)	SQ ₁	10A
8	Limit switch (low)	SQ ₂	10A
9	Hydraulic solenoid valve	Y _A	24V AC
10	Air solenoid valve	Y _B	24V AC
11	Push button	Up	Duplex
12	Push button	Lock	Duplex
13	Push button	Down	Trigeminy
14	Lower alarm button	K	Duplex
15	Motor	M	Single Phase
16	Buzzer	H	24VAC
17	Transformer	TC	24V AC
18	Intermediate relay	KA	24V AC
19	Power indicator	R	White 24V
20	Fuse	FU3	5A
21	Intermediate relay	KA3	24V DC
22	rectifier bridge	UR	KBPC10-10
23	Photo Cell Device	SP	24V DC

E. Leveling two platforms and install anchor bolts.

1. Check by level bar and use the shim to adjust the platforms until two platforms are in the same level.




Fig. 13

2. Install anchor bolts.

2.1 Raise the lift to 1000mm then drill holes to install the anchor bolts (**See Fig.14**).




Fig. 14

2.2 Fix the Anchor bolts ($3/4 \times 5 \frac{1}{2}$ ").

Drilling the hole for the anchor bolt with the rotary hammer drill, type the anchor bolt into the ground, and then fasten it with Ratchet spanner (**See Fig. 15**).

Note: The torque of anchor bolt is 150N.m, the length inside ground of anchor bolt must be over 90mm.




Fig. 15

3. Fix the control cabinet anchor bolts (M10×100mm) (See Fig. 16).




Fig. 16

IV. EXPLODED VIEW

MODEL XL-9F




Fig. 17

PARTS LIST FOR XL-9F

Item	Part No.	Description	QTY
1	11610001A	Extended Platform Assembly	4
1A	10207021	Socket Bolt M6*12	8
2	11610127	Runway Platform Assembly	2
3	10610003	Slider for platform	4
4	10610006A	Upper Scissors (out) Assembly	2
5	11610005A	Connecting Pin for Cylinder	2
6	10610098	Snap Ring	4
7	11610128	Safety device support panel assembly	2
8	10610023	Slider for base	4
9	10610108	Washer $\phi 44 \times \phi 30.5 \times 2$	16
10	10680005	Cup Head Bolt M6*10	4
11	10520011	Air Cylinder SDA32*25	2
12	10420153	Cup Head Bolt M6*20	8
13	11610018	Rotating Shaft A	8
14	10610019	Self-locking Nut M30*3.5	8
15	10620064	Greasing Fitting	38
16	10520023	Snap Ring	4
17	11610030A	Fix-Pin for cylinder	2
18	10610031A	Secondly Cylinder $\phi 100 \times 510$	1
19	11610032A	Safety Lock Tube (Secondly)	1
20	11610017A	Base Frame Assembly	2
21	10610096	Hex Nut	8
22	10610095	Hex Nut	8
23	11610014C	Lower Scissors (in) Assembly	2
24	11610009A	Rotating Shaft B	16
25	10610008	Snap Ring	16
26	11610013B	Lower Scissors (out) Assembly	2
27	10610012	Washer	16
28	11610011B	Upper Scissors (in) Assembly	2
29	10610070	Rubber Pad 120*100*70	4
30	071201	Power Unit	1
31	10610029A	Main Cylinder $\phi 120 \times 510$	1
32	11610028A	Safety Lock Tube (main)	1
33	610007A	Cabinet Control	1
34	10610118	Limit switch Assembly	1
35	10620095	Hex Nut	6
36	10420164	Cup Head Bolt	2
37	10420047	Fitting	2

38	10520065	Air Line $\Phi 6 \times \Phi 4 \times 2000\text{mm}$	2
Item	Part No.	Description	QTY
39	10610114	Air Line $\Phi 6 \times \Phi 4 \times 6300\text{mm}$	1
40	10420124	T-Fitting	1
41	10520069	90°Fitting	1
42	10510023	Straight Fitting For Cylinder	2
43	10201022	T-Fitting For Cylinder	1
44	10610068	Oil Hose (No.3) $1/4 \times 2100$	1
45	10610112	Oil Hose (No.1) $1/4 \times 4350$	1
46	10610113	Oil Hose (No.2) $1/4 \times 4420$	1
47	10420146	Fitting for Air Line	1
48	10420018	Self-Locking Nut	2
49	10680005	Cup head bolt M6*10	4
50	10420076	90°Fitting	1
51	10420145	Oil Water Separator	1
52	10620065	Shim(2 mm)	20
53	10201090	Shim((1 mm)	20
54	10209059	Anchor bolt $3/4 \times 5-1/2$	8
55	10620071	Anchor bolt M10*100	4
56	10440009	Straight Fitting for Power Unit	1
57	1052K027	90°Fitting	1
58	10420097	90°Fitting	2
59	1061K018	Two-way Valve	1
60	10610500	Parts Box	1
61	10610125	Photo Cell switch assembly	1

1. CYLINDERS




Fig. 18

Parts for Hydraulic Cylinder

Item	Part No.	Description	QTY
31	10610029	Main Cylinder	1
31-1	11610033	Main cylinder assembly	1
31-2	10520053	O Ring($\phi 118 \times 5.3$)	1
31-3	11520043	Head cap (main)	1
31-4	10520052	Support Ring($\phi 67 \times \phi 73 \times 15$)	1
31-5	10520051	Y Ring ISI($\phi 67 \times \phi 77 \times 6$)	1
31-6	10520050	Dust Ring ($\phi 67 \times \phi 75$)	1
31-7	11610035	Piston Rod (main)	1
31-8	10520054	O Ring ($\phi 38 \times 3.55$)	1
31-9	10520055	Y Ring OSI($\phi 105 \times \phi 120 \times 9$)	2

31-10	10520056	Support Ring ($\phi 114*\phi 120*15$)	1
Item	Part No.	Description	QTY
31-11	11520045	Piston (main)	1
31-12	10520049	Set screw	2
31-13	10520047	Hex Nut	1
31-14	10530009	Hose Burst Valve	2
18	10610031A	Secondly Cylinder	1
18-1	11610034	Secondly Cylinder assembly	1
18-2	10520060	O Ring($\phi 100*3.55$)	1
18-3	11520044	Head Cap (secondly)	1
18-4	10201034	Bleeding Plug	3
18-5	10520058	O Ring($\phi 45*3.55$)	1
18-6	10520057	Dust Ring($\phi 45*\phi 53$)	1
18-7	11610036	Piston Rod (secondly)	1
18-8	10520061	O ring($\phi 28*3.55$)	1
18-9	10520062	Support Ring($\phi 94*\phi 100*15$)	1
18-10	10520063	Y Ring OSI($\phi 85*\phi 100*9$)	1
18-11	11520046	Piston (secondly)	1
18-12	10520049	Set screw	1
18-13	10520048	Hex Nut M27	1

2. CONTROL CABINET (10610007A)




Fig. 19

Parts For Control Cabinet

Item	Part No.	Description	QTY
33-1	10201094	Power indicator	1
33-2	10420071	Button UP	1
33-3	10420071	Button LOCK	1
33-4	10420072	Button DOWN	1
33-5	1152K001B	Control Panel	1
33-6	10420074	Power Switch (QS)	1
33-7	11610109	Cabinet Body	1
33-8	10420167C	Air Line 6*8*200mm	2
33-9	1061K110	Straight Fitting for Air Line	1
33-10	10209145	Cup Head Bolt	4
33-11	10420076	90° Fitting for Air Line	2
33-12	10420143	Buzzer	1
33-13	10420142	Lowering Alarm Button K	1
33-14	1152K022A	Cabinet Door	1
33-15	10720038	Cup Head Bolt M6*30	4
33-16	1152K006A	Terminal Panel for Installing Element	1
33-17	10202046	Circuit breaker 2P 25A	1
33-18	10420135	Timer Relay Base	4
33-19	10420141	Intermediate Relay	2
33-20	1061K052	Cup Head Bolt with washer M4*8	17
33-21	104101492	Intermediate Relay	1
33-22	10420083	Timer Relay	1
33-23	10420134	Transformer	1
33-24	10420084A	AC Contactor	1
33-25	10580101	Rectifier bridge	1
33-26	10510081	Circuit breaker	1
33-27	10620082	Terminal	1

3. ELECTRIC POWER UNIT (071021)

Electric power unit 220V/60Hz/ single phase




Fig. 20

Parts for Electric Power Unit 220V/60HZ/1 Phase


Item	Part No.	Description	QTY
1	81400180	Rubber Pad	2
2	81400130	Start Capacitor	1
3	81400088	Run Capacitor	1
4	10420148	Cup head bolt with washer	6
5	81400066	Protective Cover for capacitor	2
6	81400363	Motor Connecting shaft	1
7	81400362	Manifold block	1
8	10209149	Washer $\phi 6$	4
9	81400276	Iron Plug	1
10	81400259	Red Plug	1
11	85090142	Socket Bolt	4
12	81400292	Gear Pump	1
13	10209034	Washer $\phi 8$	2
14	81400295	Socket Bolt	2
15	81400365	O Ring	1
16	10209152	Tie	1
17	85090167	Magnet	1
18	81400290	Filter	1
19	81400413	Motor	1
20	81400287	Cover of Motor Terminal Box	1
21	71111108	AMGO Power unit sticker	1
22	81400459	Throttle valve	1
23	81400266	Relief Valve	1
24	81400284	Iron Plug	1
25	81400420	Solenoid valve winding	1
26	81400423	Electrical Release Valve	1
27	81400566	Check valve	1
28	81400288	Inlet pipe	1
29	81400289	Oil Return pipe	1
30	81400364	Hose Clamp (stainless steel)	1
31	81400263	Filler Cap	1
32	81400275	Reservoir	1

V. TEST RUN

A. Oil-Filling Adjustment


1. Connect the power cord according to the circuit diagram, then turn on the power.
2. Fill reservoir with Hydraulic Oil (**Note: In consideration of power unit's durability and the best performance, please use Hydraulic Oil 46#.**)
3. Turn the Two-way valve to the filling position (See **fig.21**), push button "**Up**" and fill oil into the secondly cylinder till it is full, and then push button "**Lock**" for a while for bleeding air. Repeating this operation until no air in the hydraulic system.
4. Turn the Two-way valve to the working position (See fig.22), push button "**Up**" to raise and lower the lift for several times, meanwhile do the synchronous adjustment till the two safety device can lock and release at the same time.
5. Remove the power cord between 1# and 2# (See fig.23)

Note: Once the PI/PII Platforms fail to keep at the same level during working, which make the photo cell switch out of work range, the power would be shut off. Open the control cabinet, connect 1# and 2# with power cord (see fig.23), do the filling/synchronizing operations again, then remove the power cord, the equipment can work again.



Oil Filling Position

Fig. 21



Normal Working Position

Fig. 22




Fig. 23

Remove the cord after synchronizing

B. Test run

Check the height limit switch, the hose and fitting connection, and do test run. The lift must be tested run and checked carefully before in use.

VI. OPERATION INSTRUCTIONS

To lift vehicle

1. Keep clear of site near the lift, and down the lift to the lowest position.
2. Drive vehicle to the platform and put on the brake.
3. Turn on the power and push the button **"UP"**, raise the lift to the working position.

Note: make sure the vehicle is steady when the lift is rising

4. Push button **"Lock"** to lock the lift in the safety device. Make sure the safety is locked in the same height before working.

To lower vehicle

1. Be sure clear of around and under the lift, only leaving operator in lift area.
2. Push the button **"Down"**, the lift is lowered continually and stopped at the height 600mm from ground. Keep feet clear off lift, push button **"DOWN"** while push the **Lowering Alarm Button(black)** at the side of control cabinet, the lift is lowered to ground with alarm tone;
3. Drive away the vehicle when the lift is lowered to the lowest position.
4. Turn off the power.




Fig. 24

VII.MAINTENANCE SCHEDULE

Monthly:

1. Re-torque the anchor bolts to 150 Nm.
2. Lubricate all moving parts with lubricant.
3. Check all fittings, bolts and pins to insure proper mounting.
4. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage.
5. Adjusting the lifting level on both platform.

Note: All anchor bolts should take full torque. If any of the bolts does not function for any reason, **DO NOT** use the lift until the bolt has been replaced.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust the platform as necessary to insure level lifting.
3. Check all fastener and re-torque.

VIII.TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	1.Button does not work 2. AC contactor burned out 3. Motor burned out	1. Replace button 2. Replace AC contactor 3. Repair or replace motor
Motor have voice but not run	1.Wiring connections of 3 phase are not in good condition. 2. AC contactor main contacts in poor contact	1. Check the 3 phase wiring connections, and repair it if not in good condition. 2. Replace AC contactor.
Motor runs but the lift is not raised	1.Motor runs in reverse rotation 2.Low oil level 3.The Gear Pump out of operation 4.Relief valve or check valve in damage 5.Shaft Coupling in damage	1.Reverse two power wire 2.Fill tank 3.Repair or replace 4.Repair or replace 5.Replace Shaft Coupling
Lift raised slowly	1.Oil line is jammed 2. Gear Pump leaks 3.Overload lifting 4.Power Voltage low 5.Oil mixed with air	1.Clean the oil line 2.Replace Pump 3.Check load 4.Check electrical system 5.Fill tank and bleeding air
Lift cannot lower	1. Hydraulic Solenoid valve out of operation 2. Low Air pressure can't open the lock	1. Check Solenoid valve and Air line 2.Adjusting Air pressure of Compressor

IX. LIFT DISPOSAL:

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.



AMGO HYDRAULIC CORPORATION

1931 Jo Rogers Blvd, Manning, South Carolina, USA

Tel: (803) 505-6410

Fax: (803) 505-6410

NO.: 72168601

Date: 2019/12