

USE AND MAINTENANCE MANUAL

ELECTRO-HYDRAULIC 2-POST LIFT KT-H120D

Autokato Engineering LTD

Support: +1 217-904-6576
Email: info@autokato.co
Website: www.autokato.com
company Add: 4050 W. Harmon Ave # 3&4
Las Vegas NV 89103

SAFETY INSTRUCTIONS:

(READ THE INSTRUCTIONS ENTIRELY BEFORE OPERATING)

1. Do not install the lift on any asphalt surface.
2. Read and understand all safety warning procedures before operating the lift
3. The lift, in its standard version, is not designed for outdoor use
4. Keep hands and feet away from any moving parts. Keep feet clear of lift when lowering
5. The lift may only be used by qualified staff, properly trained for the specific use of the machine.
6. Do not wear unfit clothes such as large clothe with flounces, tires, etc, which could get caught by moving parts of the machine.
7. The lifts surrounding area must be free from people or objects which could be a danger for lifting operations
8. The lift only designed to lift the entire body of vehicle, having maximum weight not more than the lift capacity
9. Always insure the safety devices are engaged before any attempt to work on or near vehicle.
10. The vehicle must be centered and positioned in a stable correct way with respect to the posts and following the instruction given by manufacturer
11. Make sure that the machine and its devices are working correctly, according to the specific instructions for maintenance.
12. Lower the lift to its lowest position when service finish.
13. Do not modify the machine without manufacturer's advice.
14. If the machine is not to be used any more, owners are suggested to make it unusable by removing the power supply connections, emptying the oil tank and disposing the liquids by ring way.
15. If the lift is to be left unused for a long period, proceed as follows
 - a. Disconnect the energy source;
 - b. Empty the control unit tank;

- c. Grease the moving parts which might be damaged by dust or drying out.

All safety warning signs presented on the machine with the purpose to draw the operator's attention from dangerous or unsafe situations. The labels must be kept clean and they have to be replaced if detached or damaged. Read the meaning of the labels carefully and memorize it.

Special specification

1. Equipment damage which in the process of shipment shall be claim by the buyer to the carrier.
2. Design and manufacture have considered the safety performance. However, proper training and thorough operation can increase the safety. Not reading illustrates, shall not operate or repair the equipment.
3. Identify the motor and the current state requirement of the nameplate, by professional and qualified electrician to connect.
4. Products of the company to the part structure improvement without notice. On the previous sales product updates without any obligation to notify customer.
5. Please carefully to read and fill in the instruction of the 《warranty card》, feedback to the distributor and the company filing. As the evidence of after service. Or regard give up the enjoyment of the corresponding service power, responsible for themselves responsibility.
6. Not be more than the rated lifting weight.
7. Please carefully read the warning marks.

Content

1、INTRODUCTION-----	1-4
2、MAIN TECHNICAL PARAMETERS-----	5
3、OUTLINE DIMENSION -----	6
4、THE STRUCTURE AND WORKING PRINCIPLE OF THE MACHINE -----	6
5、INSTALLATION AND DEBUGGING -----	7-11
6、HYDRAULIC AND ELECTRIC SYSTEM -----	12
7、OPERATION-----	14
8、MAINTENANCE -----	15
9、TROUBLE SHOOTING -----	16
10、WARRANTY CARD-----	17
11、EXPLODED DIAGRAM-----	18-23
12、CERTIFICATE OF CONFORMITY-----	24

1、 Introduction:

This guide has been made to supply the owner as well the user with the basic instructions for a correct use of the machine. Read this guide carefully before using the machine and following the instructions given by this guide to grant the machine a correct function, efficiency and a long service life.

This machine through careful designed, adopts double column structure, hydraulic driven, work stable and convenient operation, low noise, have safety device inside , safe and reliable. Small space, is the ideal equipment for car repair and maintenance.




Chart 1

2、 Main technical parameters:

Lifting capacity:	12000LBS
Lifting height:	1800mm
Overall height	2820mm
Minimum height:	110mm
Lifting time:	50s
Power supply	220V, 3.0kw
Rated oil pressure	18Mpa
Overall weight	560kg

3 、 Outline Dimension:




Chart 2

4、 The structure and working principle of the machine:

The machine are make up of main and auxiliary column,hydraulic system driving two cylinders, push the wheel,drive the lifting steel chain elevate the pulley (see Figure 1 、2 and figure 3). Four lifting arms are hinged on the pulley, rotate 90° , in a swing and sliding telescopic arm to adapt to the different models of the

supporting parts. The lifting arm is provided with a locking mechanism to prevent rotation of the lifting arm (see Figure 4). Two pulleys by synchronous wire rope keep up and down. Two pulleys are provided with a mechanical safety device. In the rising as insurance mechanical keys can automatically enter and disengage from the insurance point, sound crash, as judge mechanical insurance device work normal or not and two pulley are synchronized or not.




Chart 3 Installation steel rope

5、 Installation and debugging:

5.1 Installation requirements:

- (1) The thickness is more than 150mm, label more than 150# fine stone concrete, according to chart 5 to dig, Otherwise, according to figure 5 to make the concrete foundation bolt or directly buried anchor bolt M18.
- (2) The difference between two columns bases shall not be more than 8mm, otherwise it shall be amended or put proper plate under the post.




Chart 5 Installation

BEFORE INSTALLATION

1. Identify the components and check for shortages. Contact us immediately if shortage
2. Installation, adjusting and testing operations are to be performed by qualified staff only.
3. The lift must be installed on a level concrete floor, having minimum thickness of 15cm and
an extension of at least 1.5m from anchoring points.
4. The lift installation concrete surface must be relatively smoothes, leveled in all directions
5. After unloading the lift, place it near the intended installation location.
Remove the shipping brands and packing materials from the unit.
Remove the packing brackets and bolts holding the two columns together.

SPACE REQUIRED

Please refer to the drawing for detailed installation size.

5.2 Installation steps:

PLEASE READ THE FOLLOWING INSTRUCTIONS BEFORE ASSEMBLING THE LIFT

STEP ONE: DETERMINE LOCATION AND MARKS WITH CHALK ON THE FLOOR

1. Determine which side will be the approach side and which side the power unit to be mounted.
2. Once the location is selected, use a chalk line to layout a grid for the post locations and make an outline of the posts on the floor at each location.
3. Before proceeding, double check measurements and make certain that the bases of each column are square and aligned with the chalk line.

STEP TWO: MOUNTING TWO COLUMNS, POWER UNIT COLUMN FIRST THEN THE OTHER.

1. Drill each anchor hole in the concrete using a rotary hammer drill. To assure full holding power, do not ream the hole or allow drill to wobble.
2. After drilling, remove dust thoroughly from each hole and make certain that the column remains aligned with the chalk line during this process
3. If shimming is required, insert the shims as necessary under the base plate so that when the anchor bolts are tightened, the columns will be plumb.
4. With the shims and anchor bolts in place, tighten by securing the nut to the base then turning. 2-3 full turns clockwise. DO NOT use an impact wrench for this procedure.
5. Position the other column at the designated chalk locations and secure to the floor following the same procedures as outlined in step 1,2,3,4.

STEP THREE: MOUNTING POWER UNIT

Attach the power unit to the power unit column with supplied tools and parts.
Fill the reservoir with hydraulic oil.

STEP FOUR: INSTALLING HYDRAULIC HOSE

Install the hydraulic lines as shown in HYDRAULIC CONNECTION, paying careful attention to keep the hoses clean and free of debris.;

STEP FIVE: INSTALLING THE LIFTING ARMS

Install the swing arms on the carriages using the included pins. Check for proper engagement of the arm lock.

STEP SIX: MAKE THE ELECTRICAL HOOK UP TO POWER UNIT.

WARNING: THE WIRING MUST COMPLY WITH LOCAL CODE. HAVE A

CERTIFIED
ELECTRICIAN MAKE THE ELECTRICAL HOOK UP TO THE POWER UNIT.




Chart 6 Installation checking

5.3 Load test:

No-load test:

- (1) Full inspection installation before using.
- (2) Press up button, if piston rod can extend explain the motor rotating is right.
- (3) lifting pulley, if the rising chain relaxation, need to press up button, make the oil cylinder piston rod slowly stretched out to prevent chain extrusion wheel groove. Until the chain is tight.
- (4) Declined, as long as the unlocking handle pull down and no automatic retraction is opened the machinery insurance. Before release lever pulled down to open the insurance, you must first rise block to 10-20mm.
- (5) First down the pulley to the lowest, then up the pulley. The crash in the insurance bond should be issued at the same time. If the sound has successively, then stop rising, make the pulley enter into the insurance, observation which pulley first stop

falling (advanced into the insurance), with special socket spanner according to chart 3 tighten the pulley nut, further tightening synchronous wire rope. If necessary, it may be appropriate to relax the other wire rope. Until the crash sound and two pulley enter into insurance basic synchronization. In the heavy load required polyphonic synchronization.

Synchronization is abnormal, do not rise the pulley to the limit position

Heavy load test:

- (1) According to the instructions of the operation, carry out heavy load test
- (2) In accordance with the requirements of polyphonic synchronous pulley
- (3) Full travel rise and down several times, observe whether the hydraulic pipeline leakage or not, mechanical insurance is working properly. The lifting time and lifting height are all in line with the technical parameters, and the test load is over.




Chart 7 Security mechanical

The safety mechanism of the machine is composed of an unlocking plate, a torsion spring, a linkage steel wire rope, a lock tooth plate, etc. the protection function is as follows:

When rise the working table, under the action of the torsion spring , safety lock

keeps working, if have an accident (such as high pressure hose or rope rupture), working table abnormal down, safety lock unlocking plate, which is locked plate teeth stuck, and working table stop decline, to ensure safety.

When the work table fall, first rise work table a little 10-20mm, then pull down the main pillar of unlocking handle, under the action of steel rope ,around the unlocking plate pop-up the tooth groove at the same time, it is get rid of safety lock state. Press the manual unloading handle, the working table is under the action of self weight to down.

6、Hydraulic and electric system:




Chart 8 pump station

Electric system:





Chart 9 hydraulic system



10Electric chart

NO.	Code name	Name	Model	Quantity	Remarks
1	KM	AC contactor	CJX2-1210-AC220V	1	
2	M	Motor	2.2KW	1	
3	F	Insurance	RT18-32-2A	1	
4	DZ	Circuit breaker	DZ108-20-6.3-10A/380V (DZ108-20-10-16A/220V)	1	
5	HK	Combination switch	HZ5-20/4L03	1	

Hydraulic pump station (Chart 8) hanging on the column, hydraulic system see chart 9, adjust the "relief valve" can change the system pressure (the factory has adjust well), change the lifting capacity (but not adjusted rated oil pressure 21MPa). Press down the manual unloading valve handle can down.

7、 OPERATION:

WARNING: DO NOT PLACE ANY VEHICLE ON THE LIFT BEFORE TRIAL OPERATION. CYCLE THE UP AND DOWN SEVERAL TIMES TO INSURE LATCHES CLICK TOGETHER AND AIR IS REMOVED FROM THE CYLINDERS.

BEFORE OPERATION

- a. Check all the pipelines and joints before use. The machine only can be used after there is not any leakage.
- b. The lift, if its safety device malfunctions, shall not be used.
- c. The machine shall not lift or lower an automobile if the center of gravity of automobile is not within the supporting range of the supporting device. Otherwise, the manufacturer will not bear any responsibility for the consequence resulted from the operation above mentioned.
- d. The staff or operators shall be in a safe position when the machine lift or lower.
- e. Raise and lower several times to make sure no air in the cylinder. Air inside of the cylinder makes raising not smoothly.

INSTRUCTIONS FOR USE

RAISING THE LIFT

1. Make sure that you have read the operation manual before operation.
2. Always lift the vehicle at the manufacturer recommended points.
3. Position the vehicle between columns
4. Adjust the swing lift arms so that the vehicle is positioned with the center of gravity of midway between pads.
5. Raise the lift by pressing the push button on power unit until the pads touch firmly the right points and recheck if the vehicle is secure.
6. Press down handle to make the lift in safe condition then perform maintenance or repair work.

LOWERING THE LIFT

1. Clean all the obstacles before lowering the vehicle.
2. Press the release handle and down handle, then go down.
3. Release your hand when vehicle lowered to the height you want.

8、 MAINTENANCE:

8.1 DAILY PRE-OPERATION CHECK

The user should perform daily check. Daily check of safety latch system is very important the discovery of device failure before needed could save you from expensive property damage, lost production time, serious personal injury, even death.

- . Check safety lock audibly and visually while in operation.
- . Check hydraulic connections, and hoses for leakage.
- . Check chain connections, cable connections, wiring and switch for damage.
- . Check bolts, nut and screws and tighten.
- . Check swing arm restraints.

8.2 WEEKLY MAINTENANCE

- . Check the cleanness of the mobile parts.
- . Check the safety device as previously described.
- . Check hydraulic fluid level as follow: let the trolleys go up completely and in case they do not reach maximum height, add oil.
- . Check and tighten bolts, nuts and screws.

8.3 MONTHLY MAINTENANCE

- . Check the tightening of screws.
- . Check the hydraulic system seal and tighten the loose unions, if necessary.
- . Check the greasing and wear condition of pins, rollers, bushes, of trolley structure as well as arms and relevant extensions, if necessary, replace the damaged parts by original spare parts.

8.4 YEARLY MAINTENANCE

Empty the tank and check the conditions of the hydraulic fluid. Clear the oil filter.

9、TROUBLE SHOOTING:

TROUBLES	POSSIBLE REASONS	WAYS TO SOLVE
MOTOR DOES NOT RUN	A. Breaker or fuse blown. B. Motor thermal overload tripped. C. Faulty wrong connections. D. Defective up button.	A. Replace it. B. Wait for overload to cool C. Call electrician for checking D. Call electrician for checking
MOTOR RUNS BUT WILL NOT RAISE	A. A piece of trash is under check valve. B. Check the clearance between the plunger valves of the lowering handle. C. Remove the check valve cover and clear the ball and seat. D. Oil level too low. Oil level should be just under the vent cap port when the lift is down.	Push handle down and push the up button at the same time. Hold for 10-15 seconds, which should flush the system.
OIL BLOWS OUT BREATHER OF POWER UNIT.	A. Oil reservoir overfilled. B. Lift lowered too quickly while under a heavy load. C. Bad capacitor. D. Low voltage call electrician for checking. E. Lift overloaded.	Call electrician for checking.
MOTOR HUMS AND WILL NOT RUN	A. Impeller fan cover is dented. B. Faulty wiring. C. Bad capacitor. D. Low voltage call electrician for checking. E. Lift overloaded.	A. Take off and straighten. B. Call electrician for checking. C. Call electrician for checking.
LIFT JERKS GOING UP AND DOWN	Air in hydraulic system.	Raise lift all the way to the top and return to floor. Repeat several times. Do not let this overheat the power unit.
OIL LEAKS	A. Power unit: if the power unit leaks hydraulic oil around the tank mounting flange check the oil level in the tank. The level should be two inches below the flange of the tank. B. Rod end of the cylinder. The rod seal of the cylinder is out. C. Breather end of the cylinder: the piston seal of the cylinder is out.	A. Check with a screwdriver. B. Rebuild or replace the cylinder. C. Rebuild or replace the cylinder.

LIFT MAKES EXCESSIVE NOISE	A. Leg of the lift is dry and requires grease. B. Cylinder pulley assembly or cable pulley assembly is not moving smoothly. C. May have excessive wear on pins or cylinder yoke.	
----------------------------	--	--

10、Warranty card

User name		Contact number		Date of purchase	
Contact add					
Product ID		Serial number		Invoice number	
Maintenance place name				Warranty phone	

Maintenance record card

Date	Record content	Change parts content				broker	appendix
		Name	Model	specification	quantity		


Warranty conditions


1、Begin from the date of purchase one year, under the normal use condition and the user in accordance with the 《operation manual》 require to operate this product failure, our company will give limited free repair.

2、In the warranty time need repairs, user holds this warranty cards、 invoices for free services. Change parts belong to our company.

3、Does not belong to the scope of warranty: a. As transportation、 improper use、 base strength is not enough、 power supply is not accordance with the stipulate、 not accordance with 《operation manual》 caused damage is covered by warranty; b. Exceed the time of free service, provide service need charging as the company cost; c. Easy wear parts do not belong to the scope of warranty.


11、 Exploded diagram





Part number	Name	QTY	Model
1A	Car components	2	
2a	Main Column	1	
2b	Auxiliary Column	1	
3B	Cylinder components	2	
4	Cover hat	2	
5	Chain	2	
6	Wire rope assembly	2	
7	Sprocket	2	
8	Sprocket shaft	2	
9	Rope pulley	6	
10C	Power unit	1	
11	Fixed plate for approach bridge	4	
12	Long oil pipe	1	
13	Main oil pipe	1	
14	Long connector	1	
15	Short connector	2	
16	Approach bridge plate	1	
G1	Shaft snap ring	8	Ø25
G2	Hexagonal bolt	8	M10X35
G3	Flat Washer	8	M10
G4	Spring Washer	8	M10

G5	Hexagonal nut	8	M10
G6	Internal hexagonal bolt	4	M8X15
G7	External hexagonal bolt	4	M8X25
G8	Flat Washer	4	M8
G9	Spring Washer	4	M8
G10	Hexagonal nut	4	M8
18	Unlock Axis	2	
19	Torsion spring sleeve	4	
20	Main Lock	1	
21	Auxiliary lock	1	
22	Torsion spring	1	
23	Release handle	1	
24	Release lower wheel	2	
25	Flat shaft	2	
26	Main rope wheel stand	1	
27	Auxiliary rope wheel stand	1	
A9	Handle ball	1	
G16	Internal hexagonal bolt	6	M6*20
G48	Countersunk bolt	2	M6*14
G55	Half round head bolt	4	M6*20
G56	Flat Washer	4	M6
28	Rope wheel bolt	2	
29	Unlock upper wheel	2	
30	Unlock steel wire rope	1	



Part number	Name	QTY	Model
A1	Car components	2	
A2-1	One support arm	4	
A2-2	Two support arm	4	
A3	Support arm pin shaft	4	
A4	Slider	16	
A5	armrest	4	
A6	Scroll cover	4	
A7	Pallet	4	
A8	Locking tooth	4	
A9	Handle ball	4	
A10	Locking rod	4	
A11	External locking tooth	4	
A12	Lock tooth pressure spring	4	
A13	Support arm rubber washer	4	

Part number	Name	QTY	Model
A17	Pallet rubber washer	4	
A18	Anti collision rubber washer	2	
G1	Snap ring	4	25
G8	Flat washer	8	8
G16	Internal hexagonal bolt	4	M6*15
G20	Half round head bolt	8	M6*25
G21	Hexagonal nut	8	M6
G40	Internal hexagonal nut	4	M8*14
G45	Internal hexagonal bolt	8	M8*12
G46	Internal hexagonal bolt	12	M10*20
G47	Countersunk bolt	8	M6*5
G48	Countersunk bolt	8	M6*14
G49	Snap ring	4	40
G50	Flat washer	4	22

Certificate of conformity

This equipment is qualified to grant leave the factory

Product name: Two post lift

Product ID:

Date of inspection:

Test Technician: seal