

# XPR-10 Series Two-Post Lifts

## Installation and Operation Manual

Manual P/N 5900951 — Manual Revision E — March 2021

Models:

- XPR-10S
- XPR-10AS
- XPR-10XLS
- XPR-10AXLS



*Model XPR-10S shown.*

**Designed and engineered by BendPak Inc. in Southern California, USA. Made in China.**

 **DANGER**

**Read the *entire contents* of this manual *before* using this product. Failure to follow the instructions and safety precautions in this manual can result in serious injury or death. Make sure all other operators also read this manual. Keep the manual near the product for future reference. *By proceeding with setup and operation, you agree that you fully understand the contents of this manual and assume full responsibility for product use.***

**Manual.** XPR-10 Series Two-Post Lifts, *Installation and Operation Manual*, Manual Part Number 5900951, Manual Revision E, released March 2021.

**Copyright.** Copyright © 2021 by BendPak Inc. All rights reserved. You may make copies of this document if you agree that: full attribution goes to BendPak Inc., you are not authorized to make changes to the content, you do not gain any rights to this content, and you will not use the copies for commercial purposes.

**Trademarks.** BendPak and the BendPak logo are registered trademarks of BendPak Inc. All other company, product, and service names are used for identification only. All trademarks and registered trademarks mentioned in this manual are the property of their respective owners.

**Limitations.** Every effort has been made to ensure complete and accurate instructions are included in this manual. However, product updates, revisions, and/or changes may have occurred since this manual was published. BendPak reserves the right to change any information in this manual without incurring any obligation for equipment previously or subsequently sold. BendPak is not responsible for typographical errors in this manual. You can always find the latest version of the **manual for your product on the BendPak website**.

**Warranty.** The BendPak warranty is more than a commitment to you: it is also a commitment to the value of your new product. Contact your nearest BendPak dealer or visit [www.bendpak.com/support/warranty](http://www.bendpak.com/support/warranty) for full warranty details. Go to [bendpak.com/support/register-your-product/](http://bendpak.com/support/register-your-product/) and fill out the online form to register your product (be sure to click **Submit**).

**Safety.** Your Lift was designed and manufactured with safety in mind. Your safety also depends on proper training and thoughtful operation. Do not set up, operate, maintain, or repair the Lift without reading and understanding this manual and the labels on the unit; **do not use your Lift unless you can do so safely!**

**Owner Responsibility.** In order to maintain your product properly and to ensure operator safety, it is the responsibility of the product owner to read and follow these instructions:

- Follow all installation, operation, and maintenance instructions.
- Make sure product installation conforms to all applicable local, state, and federal codes, rules, and regulations, such as state and federal OSHA regulations and electrical codes.
- Read and follow all safety instructions. Keep them readily available for operators.
- Make sure all operators are properly trained, know how to safely operate the unit, and are properly supervised.
- Do not operate the product until you are certain all parts are in place and operating correctly.
- Carefully inspect the product on a regular basis and perform all maintenance as required.
- Service and maintain the unit only with approved replacement parts.
- Keep the manual with the product and make sure all labels are clean and visible.
- **Only use the Lift if it can be used safely!**

**Unit Information.** Enter the Model Number, Serial Number, and the Date of Manufacture from the ID label on your unit. This information is required for part or warranty issues.

Model: \_\_\_\_\_

Serial: \_\_\_\_\_

Date of Manufacture: \_\_\_\_\_

<b>BP BendPak</b>		Santa Paula, CA USA <a href="http://www.bendpak.com">www.bendpak.com</a>
MODEL NUMBER		
DESCRIPTION		
LIFT CAPACITY	DATE OF MFG.	
VOLTAGE	SERIAL NUMBER	
<input type="checkbox"/> 110-240V, 50-60 Hz, 1 Ph		
<input type="checkbox"/> 208-240V, 50-60 Hz, 1 Ph		
<input type="checkbox"/> 380-415V, 50-60 Hz, 3 Ph		
<input type="checkbox"/> 208-440V, 50-60 Hz, 3 Ph		
		UPC
<b>DANGER!</b> Disconnect Power Before Servicing		
WARRANTY VOID IF DATA PLATE IS REMOVED		CE EAC PN 5905950

---

# Table of Contents

<b>Introduction</b> .....	<b>3</b>	<b>Operation</b> .....	<b>59</b>
<b>Shipping Information</b> .....	<b>3</b>	<b>Maintenance</b> .....	<b>65</b>
<b>Safety Considerations</b> .....	<b>4</b>	<b>Troubleshooting</b> .....	<b>67</b>
<b>FAQ</b> .....	<b>6</b>	<b>Wiring Diagrams</b> .....	<b>68</b>
<b>Components</b> .....	<b>7</b>	<b>Labels</b> .....	<b>69</b>
<b>Specifications</b> .....	<b>8</b>	<b>Parts Drawings</b> .....	<b>72</b>
<b>Installation Checklist</b> .....	<b>14</b>	<b>ALI Store</b> .....	<b>95</b>
<b>Installation</b> .....	<b>15</b>		

## Introduction

This manual describes these XPR-10 Series Two-Post Lift models:

- **XPR-10S.** A Two-Post *Symmetric* Lift that raises Vehicles up to 10,000 pounds (4,536 kg). Also available with extended height (for taller Vehicles), Low-Pro™ arms, and both.
- **XPR-10AS.** A Two-Post *Asymmetric* Lift that raises Vehicles up to 10,000 pounds (4,536 kg). Also available with extended height (for taller Vehicles), Low-Pro™ arms, and both.
- **XPR-10XLS.** A Two-Post *Symmetric Lift with extended rise under the Vehicle* (for taller mechanics) that raises Vehicles up to 10,000 pounds (4,536 kg). Also available with extended height (for taller Vehicles), Low-Pro™ arms, and both.
- **XPR-10AXLS.** A Two-Post *Asymmetric Lift with extended rise under the Vehicle* (for taller mechanics) that raises Vehicles up to 10,000 pounds (4,536 kg). Also available with extended height (for taller Vehicles), Low-Pro™ arms, and both.

All models support Narrow or Wide drive-through configurations; choose the desired width configuration **before** installation based on your specific space or Vehicle width requirements. All models have Overhead Assemblies and clear floors. **All models are ALI certified.**

 **DANGER** Be very careful when installing, operating, maintaining, or repairing this equipment; failure to do so could result in property damage, product damage, injury, or (in very rare cases) death. Make sure only authorized personnel operate this equipment. All repairs must be performed by an authorized technician. Do not make modifications to the unit; this voids the warranty and increases the chances of injury or property damage. Make sure to read and follow the instructions on the labels on the unit.

More information about the full line of BendPak products is available at [bendpak.com](http://bendpak.com).

---

***This manual is mandatory reading for all users*** of XPR-10 Series Lifts, including anyone who installs, operates, maintains, or repairs them. Keep this manual on or near the equipment at all times.

Technical support and service is available from your dealer, on the Web at [bendpak.com/support](http://bendpak.com/support), by email at [support@bendpak.com](mailto:support@bendpak.com), or by phone at **(800) 253-2363**, extension 196.

You may also contact BendPak for parts replacement information (please have the model and serial number of your unit available) at **(800) 253-2363**, extension 191.

## Shipping Information

Your equipment was carefully checked before shipping. Nevertheless, you should thoroughly inspect the shipment **before** you sign to acknowledge that you received it.

When you sign the bill of lading, it tells the carrier that the items on the invoice were received in good condition. ***Do not sign the bill of lading until after you have inspected the shipment.*** If any of the items listed on the bill of lading are missing or damaged, do not accept the shipment until the carrier makes a notation on the bill of lading that lists the missing or damaged goods.

If you discover missing or damaged goods **after** you receive the shipment and have signed the bill of lading, notify the carrier at once and request the carrier to make an inspection. If the carrier will not make an inspection, prepare a signed statement to the effect that you have notified the carrier (on a specific date) and that the carrier has failed to comply with your request.

It is difficult to collect for loss or damage after you have given the carrier a signed bill of lading. If this happens to you, file a claim with the carrier promptly. Support your claim with copies of the bill of lading, freight bill, invoice, and photographs, if available. Our willingness to assist in helping you process your claim does not make us responsible for collection of claims or replacement of lost or damaged materials.

## Safety Considerations

***Read this entire manual carefully before using your new product.*** Do not install or operate the product until you are familiar with all operating instructions and warnings. Do not allow anyone else to operate the product until they are familiar with all operating instructions and warnings.

### Safety Information

Please note the following:

- XPR-10 Series Lifts are two-post service Lifts. ***Use them only for their intended purpose.***
- Only operate your Lift between temperatures of 41°F to 104°F (5°C to 40°C).
- The Lift should only be operated by authorized personnel. Keep children and untrained personnel away from the Lift.
- Do not make any modifications to the Lift; this voids the warranty and increases the chances of injury or property damage.
- Do not use the Lift while tired or under the influence of drugs, alcohol, or medication.
- Make sure all operators read and understand this *Installation and Operation Manual*. Keep the manual near the Lift at all times.

- 
- Make a visual inspection of the Lift before using it. Do not use the Lift if you find any missing or damaged parts. Instead, take it out of service, then contact an authorized repair facility, your distributor, or BendPak at **(805) 933-9970** or [support@bendpak.com](mailto:support@bendpak.com).
  - BendPak recommends making a **thorough** inspection of the Lift at least once a year. Replace any damaged or severely worn parts, decals, or warning labels.

## Symbols

Following are the symbols used in this manual:



**DANGER**

Calls attention to a hazard that **will** result in death or injury.



**WARNING**

Calls attention to a hazard or unsafe practice that **could** result in death or injury.



**CAUTION**

Calls attention to a hazard or unsafe practice that could result in personal injury, product damage, or property damage.

**NOTICE**

Calls attention to a situation that could result in product or property damage.



**Tip**

Calls attention to information that can help you use your unit better.

## Liability Information

BendPak assumes **no** liability for damages resulting from:

- Use of the equipment for purposes other than those described in this manual.
- Modifications to the equipment without prior, written permission from BendPak.
- Injury or death caused by modifying, disabling, overriding, or removing safety features.
- Damage to the equipment from external influences.
- Incorrect operation of the equipment.

## Electrical Information



**DANGER**

All wiring **must** be performed by a licensed, certified Electrician. Do not perform any maintenance until main electrical power has been disconnected from the Lift and cannot be re-energized until all procedures are complete.

Important electrical information:

- Improper electrical installation can damage the Power Unit motor, which is not covered by the warranty.
- The Lift uses electrical energy; if your organization has Lockout/Tagout policies, make sure to implement them after connecting to a power source.
- Use a separate circuit breaker for each Power Unit.
- Protect each circuit with a time delay fuse or circuit breaker:
  - For a 208 to 230 VAC, **single phase** circuit, use a 25 amp fuse.
  - For a 208 to 230 VAC, **three phase** circuit, use a 20 amp fuse.
  - For a 380 to 440 VAC, **three phase** circuit, use a 15 amp fuse.

---

# Frequently Asked Questions

**Question:** What kinds of Vehicles can I raise on my XPR-10 Series Lift?

**Answer:** Cars, trucks, SUVs, and so on; up to 10,000 lbs (4,536 kg) each.

**Q:** Does the Lift have to be anchored in place?

**A:** Yes. Two-Post Lifts **must** be anchored. Your Lift comes with high-quality Anchor Bolts; use only the Anchor Bolts that came with your Lift.

**Q:** How thick does my Concrete have to be?

**A:** 4.25 inches thick, 3,000 PSI, cured for a minimum of 28 days. Do not install the Lift on cracked or defective Concrete. **Do not install on asphalt or any surface other than Concrete.**

**Q:** Can I install my Lift outside?

**A:** No. All XPR-10 Series Lifts are approved for indoor installation and use **only**.

**Q:** How long can I leave a Vehicle raised up on my Lift?

**A:** For a long time, as long as you leave the Lift *engaged* on its Safety Locks. Once the Lift is engaged on its Safety Locks, gravity holds it in position.

**Q:** Does the Lift have a Front and Rear?

**A:** Yes and no. Because you can drive onto a two-post Lift from either opening, there is technically no Front and Rear. However, most garages have an Approach side and a Wall side, so in that case, the Wall side is the Front and the Approach side is the Rear. If you have an Asymmetric Lift, the 30° angle faces the Rear of the Lift, so the other end is the Front.

**Q:** What is the difference between a Symmetric and an Asymmetric Lift?

**A:** The Bases of Symmetric Lifts face each other directly and when a Vehicle is on the Lift, it is more or less balanced; the same amount of weight on either side of an imaginary line drawn between the Posts. The Bases of Asymmetric Lifts are angled 30 degrees towards the Approach, making it easier to open the doors of some Vehicles.


**Q:** Are Vehicles on an Asymmetric Lift balanced?

**A:** Yes. Even though Asymmetric Lifts are angled, the Arms are positioned such that the Vehicle is still balanced when raised on the Lift.

**Q:** How do I know where to put the Adapters when I want to raise a Vehicle?

**A:** The Vehicle needs to be balanced, so you must put the Adapters (sometimes called Pads) so that they contact the manufacturer's recommended Lifting Points. **If you do not know where the manufacturer's recommended Lifting Points are on a Vehicle, you must find out before you raise it.** Your Lift came with books that will help: *Vehicle Lifting Points for Frame Engaging Lifts* shows the Lifting Points for hundreds of Vehicles. *Lifting It Right* includes information about how to raise Vehicles correctly.

# Components






*Asymmetric model shown. Not all components shown. Powerside Post shown on the right.*

XPR-10 Series Lift components include:

- **Powerside Post:** The Powerside Post holds the Power Unit, the Safety Lock Release Handle, the Lowering Handle (which is on the Power Unit), and the Power Disconnect Switch.
- **Offside Post:** The other Post.
- **Power Unit:** Provides Hydraulic Fluid to the Lift and connects to an appropriate power source. Includes the Up Button, the Lowering Handle, and the Hydraulic Fluid reservoir.
- **Up Button:** Press and hold to raise the Vehicle on the Lift.
- **Safety Lock Release Handle:** Located on the Power Post above the Power Unit, it disengages the Safety Locks so you can lower the Lift.
- **Lowering Handle:** Lowers the Lift when used at the same time as the Safety Lock Release Handle. Located on the Power Unit.
- **Power Disconnect Switch:** Immediately interrupts main electrical power to the Lift.
- **Lift Heads:** Sometimes called carriages. Lift Heads move up and down in the Posts. They connect to the Lift Arms, so when the Lift Heads move up, the Lift Arms also move up.
- **Lift Arms:** Extendable steel arms that attach to the Lift Heads.
- **Safety Locks:** Hold the Lift Heads up when engaged. ***Only leave your Lift fully lowered or engaged on Safety Locks.***
- **Overhead Assembly:** The steel beam that sits between the tops of the two Posts, it supports the Lift's structure, holds Cables and Hydraulic Lines.
- **Safety Shutoff Bar:** Located on the underside of the Overhead Assembly, the Safety Shutoff Bar stops upward movement of the Lift if the top of a Vehicle hits it.
- **Equalizing Cables:** Two cables that keep the Lift Heads synchronized. You do not want one Lift Head lowering or raising faster than the other Lift Head; the Cables keep them synchronized.

# Specifications






*Symmetric model shown.*

Model	<b>XPR-10S / -LP</b>	<b>XPR-10S-168 / -168-LP</b>
Lifting Capacity	10,000 lbs / 4,536 kg	
Maximum Capacity Front Axle	5,000 / 2,268 kg	
Maximum Capacity Rear Axle	5,000 / 2,268 kg	
<b>A</b> – Rise	69" / 1,753 mm	
<b>B</b> – Lifting Height w/Pad*	73.75" / 1,873 mm	
<b>C</b> - Maximum Lifting Height*	78.5" / 1,991 mm	
<b>D</b> – Minimum Height w/Pad	4.75" / 120 mm	
<b>E</b> – Height Overall	144.75" / 3,678 mm	168.75" / 4,284 mm
<b>F</b> – Width Overall (Narrow)	132" / 3,353 mm	
<b>F</b> – Width Overall (Wide)	145" / 3,683 mm	
<b>G</b> – Outside Posts (Narrow)	126.75" / 3,219 mm	
<b>G</b> – Outside Posts (Wide)	139.75" / 3,549 mm	
<b>H</b> – Inside Posts (Narrow)	105.5" / 2,679 mm	
<b>H</b> – Inside Posts (Wide)	118.5" / 3,009 mm	
<b>I</b> – Drive-Thru Width (Narrow)	93" / 2,364 mm	
<b>I</b> – Drive-Thru Width (Wide)	106" / 2,694 mm	
<b>J</b> – Floor to Top Switch	140.75" / 3,576 mm	164.75" / 4,182 mm
<b>K</b> – Front Arm Reach (min)	25.5" / 646 mm	
<b>K</b> – Front Arm Reach (max)	49.5" / 1,255 mm	
<b>L</b> – Rear Arm Reach (min)	32.25" / 820 mm	
<b>L</b> – Rear Arm Reach (max)	52.5" / 1,333 mm	
Motor	220 VAC, 60 Hz, 1 Phase	
Time to Full Rise	60 – 70 seconds	
Maximum Hydraulic Pressure	2500	
Sound	<70 dB	

\* *Lifting Height w/Pad* is maximum lifting height with Pads at lowest height, no adapter. *Maximum Lifting Height* is maximum lifting height with Pads at top height and with the 2.5" / 63 mm Adapter.

***Specifications subject to change without notice.***



*Asymmetric model shown.*

Model	<b>XPR-10AS / -LP</b>	<b>XPR-10AS-168 / -168-LP</b>
Lifting capacity	10,000 lbs / 4,536 kg	
Maximum Capacity Front Axle	5,000 / 2,268 kg	
Maximum Capacity Rear Axle	5,000 / 2,268 kg	
<b>A</b> – Rise	69" / 1,753 mm	
<b>B</b> – Lifting Height w/Pad*	73.75" / 1,872 mm	
<b>C</b> - Maximum Lifting Height*	78.25" / 1,990 mm	
<b>D</b> – Minimum Height w/Pad	4.75" / 119 mm	
<b>E</b> – Height Overall	144.75" / 3,678 mm	168.75" / 4,284 mm
<b>F</b> – Width Overall (narrow)	137" / 3,480 mm	
<b>F</b> – Width Overall (wide)	145" / 3,684 mm	
<b>G</b> – Outside Posts (narrow)	133.25" / 3,386 mm	
<b>G</b> – Outside Posts (wide)	141.25" / 3,590 mm	
<b>H</b> – Inside Posts (narrow)	106.25" / 2,700 mm	
<b>H</b> – Inside Posts (wide)	114.25" / 2,903 mm	
<b>I</b> – Drive-Thru Width (narrow)	93.75" / 2,382 mm	
<b>I</b> – Drive-Thru Width (wide)	101.75" / 2,585 mm	
<b>J</b> – Floor to Top Switch	140" / 3,558 mm	164" / 4,164 mm
<b>K</b> – Front Arm Reach (min)	23.5" / 595 mm	
<b>K</b> – Front Arm Reach (max)	43.75" / 1,110 mm	
<b>L</b> – Rear Arm Reach (min)	40.25" / 1,024 mm	
<b>L</b> – Rear Arm Reach (max)	58" / 1,474 mm	
Motor	220 VAC, 60 Hz, 1 Phase	
Time to Full Rise	60 – 70 seconds	
Maximum hydraulic pressure	2500	
Sound	<70 dB	

\* *Lifting Height w/Pad* is maximum lifting height with Pads at lowest height, no adapter. *Maximum Lifting Height* is maximum lifting height with Pads at top height and with the 2.5" / 63 mm adapter.

***Specifications subject to change without notice.***

Model	<b>XPR-10XLS / -LP</b>	<b>XPR-10XLS-181 / -181-LP</b>
Lifting capacity	10,000 lbs / 4,536 kg	
Maximum Capacity Front Axle	5,000 / 2,268 kg	
Maximum Capacity Rear Axle	5,000 / 2,268 kg	
<b>A</b> – Rise	75" / 1,905 mm	
<b>B</b> – Lifting Height w/Pad*	79.75" / 2,025 mm	
<b>C</b> - Maximum Lifting Height*	84.5" / 2,143 mm	
<b>D</b> – Minimum Height w/Pad	4.75" / 120 mm	
<b>E</b> – Height Overall	156.75" / 3,983 mm	180.75" / 4,589 mm
<b>F</b> – Width Overall (narrow)	132" / 3,353 mm	
<b>F</b> – Width Overall (wide)	145" / 3,683 mm	
<b>G</b> – Outside Posts (narrow)	126.75" / 3,219 mm	
<b>G</b> – Outside Posts (wide)	139.75" / 3,549 mm	
<b>H</b> – Inside Posts (narrow)	105.5" / 2,679 mm	
<b>H</b> – Inside Posts (wide)	118.5" / 3,009 mm	
<b>I</b> – Drive-Thru Width (narrow)	93" / 2,364 mm	
<b>I</b> – Drive-Thru Width (wide)	106" / 2,694 mm	
<b>J</b> – Floor to Top Switch	152" / 3,863 mm	176" / 4,469 mm
<b>K</b> – Front Arm Reach (min)	25.5" / 646 mm	
<b>K</b> – Front Arm Reach (max)	49.5" / 1,255 mm	
<b>L</b> – Rear Arm Reach (min)	32.25" / 820 mm	
<b>L</b> – Rear Arm Reach (max)	52.5" / 1,333 mm	
Motor	220 VAC, 60 Hz, 1 Phase	
Time to Full Rise	60 – 70 seconds	
Maximum hydraulic pressure	2500	
Sound	<70 dB	

\* *Lifting Height w/Pad* is maximum lifting height with Pads at lowest height, no adapter. *Maximum Lifting Height* is maximum lifting height with Pads at top height and with the 2.5" / 63 mm adapter.

***Specifications subject to change without notice.***

Model	<b>XPR-10AXLS / -LP</b>	<b>XPR-10AXLS-181 / -181-LP</b>
Lifting capacity	10,000 lbs / 4,536 kg	
Maximum Capacity Front Axle	5,000 / 2,268 kg	
Maximum Capacity Rear Axle	5,000 / 2,268 kg	
<b>A</b> – Rise	75" / 1,905 mm	
<b>B</b> – Lifting Height w/Pad*	79.75" / 2,025 mm	
<b>C</b> - Maximum Lifting Height*	84.25" / 2,143 mm	
<b>D</b> – Minimum Height w/Pad	4.75" / 119 mm	
<b>E</b> – Height Overall	156.75" / 3,983 mm	180" / 4,573 mm
<b>F</b> – Width Overall (narrow)	137" / 3,480 mm	
<b>F</b> – Width Overall (wide)	145" / 3,684 mm	
<b>G</b> – Outside Posts (narrow)	133.25" / 3,386 mm	
<b>G</b> – Outside Posts (wide)	141.25" / 3,590 mm	
<b>H</b> – Inside Posts (narrow)	106.25" / 2,700 mm	
<b>H</b> – Inside Posts (wide)	114.25" / 2,903 mm	
<b>I</b> – Drive-Thru Width (narrow)	93.75" / 2,382 mm	
<b>I</b> – Drive-Thru Width (wide)	101.75" / 2,585 mm	
<b>J</b> – Floor to Top Switch	152" / 3,863 mm	175.25" / 4,453 mm
<b>K</b> – Front Arm Reach (min)	23.5" / 595 mm	
<b>K</b> – Front Arm Reach (max)	43.75" / 1,110 mm	
<b>L</b> – Rear Arm Reach (min)	40.25" / 1,024 mm	
<b>L</b> – Rear Arm Reach (max)	58" / 1,474 mm	
Motor	220 VAC, 60 Hz, 1 Phase	
Time to Full Rise	60 – 70 seconds	
Maximum hydraulic pressure	2500	
Sound	<70 dB	

\* *Lifting Height w/Pad* is maximum lifting height with Pads at lowest height, no adapter. *Maximum Lifting Height* is maximum lifting height with Pads at top height and with the 2.5" / 63 mm adapter.

***Specifications subject to change without notice.***

---

# Installation Checklist

Following are the steps needed to install an XPR-10 Series Lift; perform them in this order.

- 1. Review the Safety Rules.
- 2. Plan for Electrical work.
- 3. Make sure you have the necessary Tools.
- 4. Review the Installation Orientation.
- 5. Review Clearances around the Lift.
- 6. Select the Installation Location.
- 7. Choose a Wide or Narrow Configuration (***do not proceed until you have chosen***).
- 8. Put Equalizing Cables into position.
- 9. Add Extension Pieces for models with extensions.
- 10. Learn about Hydraulic Fluid contamination.
- 11. Learn about Liquid Thread Sealant.
- 12. Routing the Hydraulic Hoses.
- 13. Create Chalk Line Guides for the Posts.
- 14. Install the Posts.
- 15. Prepare and install the Overhead Assembly, Safety Shutoff Bar, and the Microswitch.
- 16. Install the Equalizing Cables.
- 17. Route the Safety Lock Cable.
- 18. Install the Safety Assemblies and the Safety Lock Cable.
- 19. Mount the Power Unit (*do not connect it yet*).
- 20. Connect the Hydraulic Hoses.
- 21. Learn about Arm Restraint Gears.
- 22. Install the Lift Arms.
- 23. Perform final Leveling.
- 24. Contact the Electrician.
- 25. Wire the Microswitch (***Electrician required***).
- 26. Connect the Power Unit (***Electrician required***).
- 27. Install the Power Disconnect Switch and Thermal Disconnect Switch (***Electrician required***).
- 28. Install the Safety Covers.
- 29. Lubricate the Lift.
- 30. Perform an Operational Test.
- 31. Review the final Checklist.

---

# Installation

The installation process includes multiple steps. Perform them in the order listed.

## Reviewing the Safety Rules

When installing a Lift, your safety depends on proper training and thoughtful operation.

 **WARNING** Do not install this equipment unless you have automotive lift installation training. Always use proper lifting tools, such as a Forklift or Shop Crane, to raise heavy components. Do not install this equipment without reading and understanding this Manual and the Labels on the unit.

Only fully trained personnel should be involved in installing this equipment. Pay attention at all times. Use appropriate tools and lifting equipment. Stay clear of moving parts.

 **WARNING** You must wear appropriate protective equipment at all times during installation: leather gloves, steel-toed work boots, eye protection, back belts, and hearing protection.

## Preparing for Electrical Work

You will need to have a licensed, certified Electrician available at some point during the installation.

 **DANGER** All wiring *must* be performed by a licensed, certified Electrician.

Make sure all electrical work conforms to applicable local, state, and federal codes, rules, and regulations, such as state and federal OSHA regulations and electrical codes.

Notify your Electrician in advance so they come prepared with the items required to connect to the facility's power system or an appropriate power cord with plug for connecting to an appropriate power source, a Power Disconnect Switch, and a Thermal Disconnect Switch. These items are *not* supplied with the Lift.

The Electrician needs to:

- **Connect to power.** The Power Unit comes with a pigtail for wiring to a power source. Have your Electrician connect a power cord with plug to the electrical box on the Lift (for connection to a power outlet) or have them wire it directly into the electrical system at the Lift location.
- **Connect the Microswitch wiring to the Power Unit.** The Microswitch has to be wired to the Power Unit. The necessary wiring is included with the Lift.
- **Install a Power Disconnect Switch.** A Power Disconnect Switch is used to shut down the Lift in the event of an electrical circuit fault, emergency situation, or when the Lift is being serviced. Refer to [Installing a Power Disconnect Switch](#) for more information.
- **Install a Thermal Disconnect Switch.** A Thermal Disconnect Switch automatically shuts down the equipment in the event of an overload or an overheated motor. Refer to [Installing a Thermal Disconnect Switch](#) for more information.

---

## Gathering Your Tools

You may need some or all of the following tools:

- Rotary hammer drill (or similar)
- ¾ inch carbide bit (conforming to ANSI B212.15)
- Hammer
- Four-foot level
- Open-end wrench set, SAE and metric
- Socket and ratchet set, SAE and metric
- Hex key wrench set
- Crescent and pipe wrenches
- Torque wrench
- Crow bar
- Chalk line
- Medium-sized flat screwdriver
- Tape measure, 25 feet or more
- Needle-nose pliers
- Forklift or Shop Crane
- Two 12-foot ladders
- Two saw horses

## Checking the Installation Orientation

Keep these factors in mind when deciding how you are going to orient the Lift:

- The first thing to figure out is which direction you will be driving the Vehicles in, called the Approach.

In some cases, this is very easy: there's a driveway on one side and a wall on the other side. The driveway is your Approach. This makes the wall side the Front of the Lift and the driveway side the Rear of the Lift.

If both sides are open, decide which way you will be driving the Vehicles onto the Lift. This is the Approach. The drive-**on** side is the Rear of the Lift and the drive-**off** side is the Front.

Designating Front and Rear is important because the shorter Lift Arms go on the Front of the Lift and the longer Lift Arms go on the Rear.


To determine the Front of your Lift, drive a Vehicle straight in (do not back it in) and stop. The Front of the Lift is where the Front of the Vehicle is.

- The Power Unit must go on the Powerside Post. You can identify the Powerside Post by the Mounting Bracket to which the Power Unit attaches; only one Post that came with your Lift has a Mounting Bracket.

- If you are installing a Symmetric model, the Powerside Post can go on either side as you are looking at the Lift. Put the Post with the Mounting Bracket on the side you want, no other changes are necessary. How do you make this decision? One factor is: where is the power source—you generally want the power source as close as possible to the Power Unit. Otherwise, pick the side that works best for the site and/or get the opinion of the Lift owner.

### **XPR-10 Series, *Symmetric* Models**


Power Unit can go at either X.



- If you are installing an Asymmetric Lift, the Powerside Post and the Power Unit must go on the right. The 30° angles of the Posts of an Asymmetric Lift must face the Rear of the Lift.


### **XPR-10 Series, *Asymmetric* Models**

Power Unit must go at X.



## Checking Clearances

For safety purposes, a specified amount of clear space around the Lift is **required**.



*Drawing is a top view. Not necessarily to scale. Not all components shown. Additional distance is required for the Front and Rear as Vehicles can be driven in or driven off from these directions.*

---

## Selecting a Location

When selecting the location for your Lift, consider:

- **Architectural plans.** Consult the architectural plans for the desired location. Make sure there are no contradictions between what you want to do and what the plans show.
- **Available space.** Make sure there is enough space for the Lift: front, back, sides, and **above**. Refer to **Specifications** for exact measurements.
- **Symmetric or Asymmetric.** Asymmetric models can be installed with the Front a little closer to a wall, as only 30 percent of the length of the Vehicles will be in Front of the Posts.
- **Overhead obstructions.** Check for overhead obstructions such as building supports, heaters, lights, electrical lines, low ceilings, and so on.
- **Power.** You need an appropriate power source for the Lift's Power Unit.
- **Outdoor installations.** XPR-10 Series Lifts are approved for **indoor installation and use only**. *Outdoor installation is prohibited.*
- **Floor.** Only install the Lift on a flat, concrete floor; do not install on asphalt or any other surface. The surface must be level; do not install if the surface has more than three degrees of slope.

 **WARNING** Installing your Lift on a surface with more than three degrees of slope could lead to injury or even death. Only install your Lift on a level floor (defined as no more than 3/8 of an inch difference over the installation area). If your floor is not level, consider making the floor level or using a different location.

- **Concrete specifications.** Make sure the concrete is at least 4.25 inches thick, 3,000 PSI, and cured for a minimum of 28 days. Do not install the Lift on cracked or defective concrete. Anchor Bolts must be more than 6 inches from cracks and expansion joints in the concrete or from a wall.

 **CAUTION** BendPak Lifts are supplied with installation instructions and concrete anchors that meet the criteria set by the latest version of the American National Standard "Automotive Lifts – Safety Requirements for Construction, Testing, and Validation", ANSI/ALI ALCTV. Consult with an expert for any special regional structural and/or seismic anchoring requirements specified by any other agencies and/or codes such as the Uniform Building Code (UBC) and/or International Building Code (IBC).

Check your floor for the possibility of it being a post-tension slab. In this case, contact the building architect **before** drilling. Using ground penetrating radar may help you find tensioned steel.

 **WARNING** Cutting through a tensioned cable can result in injury or death. Do not drill into a post-tension slab unless the building architect confirms you are **not** going to hit tensioned steel or you have located it using ground penetrating radar. ***If colored sheath comes up during drilling, stop drilling immediately.***

- **Unloading the components.** Unload the Lift components as close to the installation location as possible. The Lift includes a number of heavy pieces, so the closer you unload them to the installation location, the better off you will be.


 **WARNING** Some Lift components are very heavy; if handled incorrectly, they can damage materials like tile, sandstone, and brick. Try to handle the Lift components just twice: once when delivered and once when moved into position. You must have a Forklift or Shop Crane to move some of the Lift components into position. ***Use care when moving Lift components.***

---

## Choosing a Wide or Narrow Configuration

XPR-10 Series Lifts can be installed in a Wide or Narrow Configuration:

- **Wide Configuration.** The Posts are further apart, which means you can raise wider Vehicles on the Lift. This is usually the best choice *if* your Lift location is wide enough to support it. When installing the Equalizing Cables, use the Button End at the very end of the cable.



- **Narrow Configuration.** The Posts are closer together. This is usually the best choice for narrower garages, as it uses less width. When you are installing the Equalizing Cables, use the Button End *away* from the end of the cable.

**Important:** XPR-10 Series Lifts are shipped from the factory with the Overhead Assembly and the Safety Shutoff Bar *already configured in the Narrow Configuration*. Refer to [Installing the Overhead Assembly, Safety Shutoff Bar, and the Microswitch](#) for information about switching to the Wide Configuration.

You do not need to do anything to the Overhead Assembly at this point, but you have to **decide** on a Wide or Narrow Configuration **now** for two reasons:


- **Routing the Equalizing Cables.** The Equalizing Cables come with two Button ends, one for the Wide Configuration and one for the Narrow Configuration. *You need to know which Button end to use when you put the Equalizing Cables into position.*
- **Creating the Chalk Line Guides.** You use the Width Overall setting (in [Specifications](#)) to create the Chalk Line Guides, so you know how far apart to put your Posts. There are two Width Overall settings, one for the Wide Configuration and one for the Narrow Configuration. You need to know which one to use when you are creating your Chalk Line Guides.

## Putting Equalizing Cables into Position


It is much easier to put the Equalizing Cables into position **before** you stand up the Posts. Note that this is **not a full install** of the Equalizing Cables, just putting them into position.

**CAUTION** BendPak recommends wearing gloves while handling the Equalizing Cables.

The following drawing shows an Equalizing Cable; the ends are exaggerated for clarity.



**Important:** For Symmetric models, the two Equalizing Cables are the same length. **For Asymmetric models, the two Equalizing Cables are different lengths.** For Asymmetric models, the longer cable is routed over the Overhead Assembly Sheaves on the Approach side of the Lift (the Overhead Assembly Sheaves that are furthest apart from each other).



*Not necessarily to scale. Not all components shown. Some components exaggerated for clarity. Asymmetric model shown, so one cable is longer than the other.*


The following procedure puts the two Equalizing Cables into place at the bottom of each Post.

**To put the Equalizing Cables into position:**

1. Put both Posts either flat on the ground or mostly on the ground with their tops elevated on a sawhorse or similar.


The **insides** of the Posts need to be accessible, facing up.

2. Slide the Lift Heads away from the bottoms of both Posts by at least 24 inches / 610 mm, to give yourself some space to work.



*Not necessarily to scale. Not all components shown. Top view looking at inside of Post.*

3. Look at the inside of the Lift Head you just moved, from the bottom looking towards the top — it looks something like the following drawing.



*Drawing is not to scale. Not all components shown. View is from under bottom of Lift Head looking towards top of Lift Head. Both Posts look the same from this viewpoint.*

4. Remove the Post Sheave from the bottom of the Post whose Lift Head you just moved up. Keep the Post Sheave, the pin, and the bolt nearby; you will be re-installing them soon.
5. Find the two Equalizing Cables.

For Symmetric models, both Equalizing Cables are the same length, so it does not matter which one you install first.


For Asymmetric models, the Equalizing Cables are different lengths. You must route the longer Equalizing Cable over the Overhead Assembly Sheaves closer to the Approach side of the Lift.

**Important:** The lengths of each Equalizing Cable are shown on a tag attached to the cable. If the tags have fallen off, lay the cables out to determine which is longer. The difference may be only a few inches. However, if you mix them up, the Lift will not work correctly and you will have to remove them and then re-install them correctly.

6. Take an Equalizing Cable and locate the Button end you are going to use (for a Wide Configuration, use the Button end at the very end of the cable; for a Narrow Configuration, use the Button end away from the end of the cable).

If you are installing an Asymmetric model, route the longer Equalizing Cable over the Overhead Assembly Sheaves on the Approach side of the Lift (the Sheaves that are furthest apart) and the shorter Equalizing Cable over the Sheaves on the Front side of the Lift.

7. Push the Button end up through the bottom of the Lift Head up towards the Lock Plate, then into the slot in the Lock Plate.




It can be difficult to get the Button end into the Slot, as it may be hard to reach the Lock Plate. You may want to use a metal rod or a long tool to push the Button end into the Slot.



**Tip** If you are having problems getting the Button end into the Slot, you might want to try pushing the Button end past the Lock Plate and out the Hole at the Top of the Lift Plate; now, move the Equalizing Cable around to get the *cab*le into the Slot. Once the cable is in the Slot, pull on the other end of the cable to slide the Button end into the Slot. Try to keep the cable taut until the Equalizing Cable is connected at the other end, done later in the installation. It can be difficult to get the cable back into the Slot if it comes out.

8. If you are using the Narrow configuration, bend the top of the Equalizing Cable so that so that it is out of the way of the other components in the Post.
9. Route the Equalizing Cable down to where the Post Sheave used to be and then up again towards the top of the Post.
10. Re-install the Post Sheave, making sure the Equalizing Cable is routed under it and in the Sheave.
11. Push the Threaded end of the Equalizing Cable through the Lift Head and out the Hole at the Top of the Lift Head.
12. Coil up and bind the rest of the Equalizing Cable (the portion above the Hole at the Top of the Lift Head), then leave it resting on top of the Post until later in the installation.
13. Move both Lift Heads back down to the bottom of each Post.



---

## Adding Extensions Pieces

XPR-10 Series model options with **-168** or **-181** in their names come with Post Extensions that raise the height of the Posts, letting you raise taller Vehicles.

The Post Extensions are slipped over the top of both Posts and then bolted into place.


### To install Post Extensions:

1. Locate the two Post Extensions and the eight Bolts, eight Flat Washers, eight Split-Lock Washers, and eight Nuts.
2. Slide one of the Post Extensions over the top of one of the Posts.

See the drawing to the right.

The opening in the Post Extension goes on the inside.

3. Take a Bolt, put a Flat Washer on the Bolt, and then install the Bolt from the outside of the Post Extension into one of the four holes on the Post Extension.
4. Add a Split-Lock Washer to the Bolt on the inside of the Post Extension, add a Nut to the end of the Bolt, and then tighten the Nut.
5. Perform Steps 3 and 4 for the other three holes on the Post Extension.
6. Slide on the other Post Extension and secure it the same way.





## IMPORTANT! PLEASE READ NOW



**Hydraulic Fluid Contamination poses a serious issue for your Lift**, contaminants such as water, dirt, or other debris can get into the Hydraulic Hoses and Fittings on the Lift, making your new Lift inoperable and unusable.

Your Lift is shipped with clean components; however, BendPak strongly recommends that you take secondary precautions and clean all Hydraulic Hoses and Fittings prior to making connections. It is better and less costly to take these extra steps now so that you do not need to take your Lift out of service later to fix issues that could have been prevented at the time of installation.

There are several ways to clean Hydraulic Hoses and Fittings:

- **Compressed Air.** Use an air compressor to blow out contaminants from each Hydraulic Hose and Fitting prior to installation. Clean, dry air is preferred. Wear ANSI-approved eye protection (safety glasses, goggles, or face shield) when using compressed air for cleaning. Never point an air hose nozzle at any part of your body or any other person.
- **Fluid Flushing.** As long as the Hydraulic Fluid is clean and compatible with the system fluid, you can flush Hoses and Fittings to create turbulent flow and remove particulates. Always ensure that the fluid itself is contaminant-free.

Some additional steps that will help keep the Hydraulic Fluid clean:

- **Remove old thread seal tape.** Some ports on the Hydraulic Cylinders are shipped with temporary plugs secured with thread seal tape, so make sure to thoroughly remove any leftover thread seal tape that may inadvertently enter the Hydraulic System.
- **Use a liquid thread sealant only.** Liquid thread sealant (Loctite™ 5452 or similar) is recommended. Do not use thread seal tape on any fitting. Liquid thread sealant is recommended for NPT connections, fine for JIC connections, but *not* necessary for O-ring (ORB) connections.
- **Always use clean equipment.** If you use a dirty bucket or funnel to transfer the Hydraulic Fluid into the Hydraulic Fluid Reservoir, the contaminants will likely be introduced into the Fluid. When using cleaning rags, use a lint-free rag.
- **Proper storage.** Keep the Hydraulic Fluid sealed in its container until ready for use; store the Fluid in a clean, dry, and cool area.
- **Cover the Hoses and Fittings.** Before installation, do not leave the ends of the Fittings exposed; the same applies for the Hydraulic Hoses. As a general rule, keep the Hydraulic Hoses and Fittings capped and in a clean area until ready for use.
- **Filter the new Hydraulic Fluid.** Just because it is new does not necessarily mean it is *clean*. Use an offline filtration cart or kidney loop system to make sure the Hydraulic Fluid is clean before being transferred into the Hydraulic Fluid Reservoir (even using a heavy duty nylon mesh screen is better than trusting what is left at the bottom of the barrel).
- **Avoid mixing different types of Hydraulic Fluid.** If Hydraulic Fluid needs to be replaced, make sure to flush the Hydraulic System of the old Hydraulic Fluid before you add the replacement Fluid; do not mix the two together.

---

## About Thread Sealants

Liquid Thread Sealant lubricates and fills the gaps between the Fitting threads, and leaves no residue that could contaminate the Hydraulic Fluid. Other types of Thread Sealants (like Teflon Tape) can shred during installation or removal and eventually enter the Hydraulic System.

Thread Sealant can be used with most Hydraulic Fittings, although you probably only need to use with NPT connectors.

### To apply Thread Sealant:

1. Make sure the Fittings and connectors you are going to use are clean and dry.

If you are adding Thread Sealant to a Fitting or connector that has already been used with a different sealant, use a wire brush to thoroughly remove the old sealant before adding more.

2. Apply a small amount of Thread Sealant to the first four threads of the Fitting.

 **WARNING** Always wear the proper protective equipment when handling Thread Sealant.

You only need a small amount because the sealant spreads to the other threads as it is tightened into place.

If you put too much, the excess liquid will be pushed out when the Fitting is tightened; use a rag to wipe the excess.

3. Tighten the Fitting into the connector; do **not** over tighten the Fitting.
4. Allow the manufacturer-recommended curing time before pressurizing the system.


## Routing the Hydraulic Hoses

It is easier to put some hydraulic components into position **before** you stand up the Posts.

All XPR-10 Series Lifts use either three or four Hydraulic Hoses (see drawing below):

- **One Short Hydraulic Hose (A).** Goes from the Power Unit up to the Tee Fitting on the Powerside Post; connects on the **outside** of the Post.
- **One Medium Hydraulic Hose (B).** Goes from the Tee Hydraulic Fitting on the **inside** of the Powerside Post down to the bottom of the Powerside Hydraulic Cylinder.
- **One Long Hydraulic Hose (C).** Goes from the **inside** of the Powerside Post above the Tee Fitting, over the Overhead Assembly, and down the Offside Post to the bottom of the Offside Hydraulic Cylinder.
- **One Very Short Hydraulic Hose (D).** Goes on the inside of the Powerside Post, connecting to the Tee Hydraulic Fitting and the Long Hydraulic Hose; **for Wide Configurations only.** Without this extension, the Long Hydraulic Hose would not be long enough for Wide Configurations. This Line is ~13" for Symmetric Lifts, ~8" for Asymmetric Lifts. *Not used for Narrow Configurations.*

All Hydraulic Hoses and Hydraulic Fitting locations are shown in the drawing below.



*Drawing not necessarily to scale. Not all components shown. Some components exaggerated for clarity. Drawing shows Long Hydraulic Hose (C) in place across the Overhead Assembly, but that cannot be done until later in the installation. The Elbow Hydraulic Fitting on the Power Unit is not the same as the Elbow Hydraulic Fittings on the bottom of each Hydraulic Cylinder.*

### To put the Hydraulic Hoses and Hydraulic Fittings into position:


1. Find the necessary Hydraulic Hoses: One Short, one Medium, one Long, and one Very Short (for Wide Configurations only).
2. Find the necessary Hydraulic Fittings: Two Elbow Fittings (P/N 5550113), one Tee Fitting (P/N 5550003), and one Nipple (P/N 5550095); the Nipple Fitting is for Wide Configurations only.

**Note:** The Elbow Hydraulic Fitting on the Power Unit and the Short Hydraulic Hose cannot be installed at this point, as the Power Unit is not yet in place.

3. **Starting most of the way up the Powerside Post**, push the Tee Fitting through the hole above the Mounting Bracket for the Power Unit **from inside the Powerside Post**.

**Note:** There is only one Tee Fitting and it is installed on the Powerside Post *above* where the Power Unit will be installed.

The end result of installing the Tee Fitting is two connectors inside the Powerside Post, one connector protruding outside the Powerside Post, as shown in this drawing.



*Drawing not to scale. Not all components shown. Some components exaggerated for clarity.*

- 
4. Tighten the Nut on the **outside** of the Powerside Post to hold the Tee Fitting in place.
  5. **Switching to the bottom of the Powerside Post**, remove the Shipping Plug from the Hydraulic Line Connector on the **bottom** of the Hydraulic Cylinder.

You can turn or move the Hydraulic Cylinder if necessary.

You might want to have a rag nearby in case some fluid leaks out of the Hydraulic Line Connector.

6. Connect one of the two Elbow Fittings to the Hydraulic Line Connector; tighten the Elbow Fitting appropriately.

Point the JIC connector towards the side of the Post with the Clips. **Use liquid thread sealant on the NPT threads only.**

7. Turn the Hydraulic Cylinder so that the Elbow Hydraulic Fitting is accessible from the bottom back side of the Powerside Post.

**Important:** When routing Hydraulic Hoses, after they are positioned correctly, put them into the nearby Clips and lightly crimp the Clips together. When all Hydraulic Hoses have been installed, go back and fully crimp all of the Clips. *There are Clips only along one side of each Post.*

8. Take the Medium Hydraulic Hose, connect the Straight End to the bottom of the Tee Fitting, and tighten securely.
9. Push the Curved End of the Medium Hydraulic Hose down to the bottom of the Powerside Post and connect it to the JIC end of the Elbow Fitting on the Hydraulic Cylinder; tighten securely.
10. **Switching to the Offside Post**, connect the other Elbow Hydraulic Fitting to the Hydraulic Line Connector at the bottom of the Hydraulic Cylinder; tighten the Elbow Fitting securely.

Point the JIC connector towards the side of the Post with the Clips. **Use liquid thread sealant on the NPT threads only.**

11. Take the Long Hydraulic Hose, push the Curved End down through the Post until it is at the bottom of the Post, then connect the Curved End to the Elbow Hydraulic Fitting you just connected and tighten securely.

Be sure to clip the Long Hydraulic Hose to the Clips in the Post.

12. Carefully coil up and bind the rest of the Long Hydraulic Hose, then leave it resting on top of the Offside Post until later in the installation.


**Important:** You should now have the Long Hydraulic Hose connected to the bottom of the Hydraulic Cylinder in the Offside Post, with the rest of the Long Hydraulic Hose coiled up at the top of the Offside Post. It will be connected to the rest of the Hydraulic System later in the installation.

## Putting in Chalk Line Guides

Based on the Specifications for your Lift, create Chalk Line Guides on the ground for the two Posts prior to moving them into position.

Use the **Width Overall** value in **Specifications for your Lift model** to determine where to place the Chalk Line Guides. The Width Overall value is defined as the distance from the back of one base plate to the back of the other base plate.


The following drawing shows how to create Chalk Line Guides for an **Asymmetric** Lift.



*Not necessarily to scale. Not all components shown.*

Make sure to choose the Width Overall value for the Narrow or Wide orientation, based on the selection you made earlier.

The following drawing shows how to create Chalk Line Guides for a **Symmetric** Lift.



*Not necessarily to scale. Not all components shown.*

#### **To add Chalk Line Guides:**

1. Decide where you want to locate the Lift.
2. Create an Alignment Chalk Line at the Front of the Lift. For Symmetric Lifts, see the drawing above.

For Asymmetric Lifts, put the Alignment Chalk Line through the notches; see the drawing on the previous page.

Make the Alignment Chalk Line **longer** than the Width Overall setting for your Lift model.

Make sure to use the Width Overall setting for Narrow or Wide orientation.

3. Create two Perpendicular Chalk Lines at 90° angles to the Alignment Chalk Lines at the Width Overall distance for the Lift model you are installing.

The two Perpendicular Chalk Lines must be **X** distance from each other, where **X** is the Width Overall setting (Narrow or Wide, depending on your selection) for your Lift model.

4. When you move the Posts into position for a **Symmetric** Lift, put the Base Plates into the corners created by the Chalk Line Guides, as shown in the drawing on this page.
5. When you move the Posts into position for an **Asymmetric** Lift, align the correct notches in each of the Bases Plates with the Alignment Chalk Line, as shown in the drawing on the previous page.

---

## Installing the Posts

We strongly recommend having multiple people work together to install the Posts.

 **DANGER** Pay *special* attention when installing the Posts. If done incorrectly, the Lift could fall over, potentially causing damage to the Vehicle, the Lift, and injuring bystanders.

Concrete specifications are:

- **Depth:** 4.25 inches / 108 mm thick, minimum
- **PSI:** 3,000 PSI, minimum
- **Cured:** 28 days, minimum

Anchor Bolt specifications are:

- **Length:** 6.3 inches / 160 mm
- **Diameter:** .75 inch / 19 mm
- **Anchor torque:** 85 – 95 pound feet (never less than 80 or more than 110)
- **Effective embedment:** 3.25 inches / 82.5 mm or more

The Concrete floor where you want to install your Lift must meet the following requirements:

- The floor must be a flat, Concrete floor. It must be level; **do not install the Lift on a surface with more than 3° of slope.**
- Do not install the Lift on cracked or defective Concrete.
- Check the floor for the possibility of it being a post-tension slab. In this case, contact the building architect before drilling. Using ground penetrating radar may help you find the tensioned cable.

 **WARNING** Cutting through a tensioned cable can result in injury or death. Do not drill into a post-tension slab unless the building architect confirms you are *not* going to hit a tensioned cable or you have located it using ground penetrating radar. **If colored sheath comes up during drilling, stop drilling immediately.**

 **WARNING** Your Concrete and Anchor Bolts *must* meet these specifications. Only install your Lift on a Concrete surface. If you install a Lift on asphalt or any other surface, or your Concrete or Anchor Bolts do not meet these specifications, it could lead to product damage, Vehicle damage, personal injury, or even loss of life.

BendPak Lifts are supplied with installation instructions and concrete fasteners meeting the criteria as prescribed by the latest version of the American National Standard “Automotive Lifts – Safety Requirements for Construction, Testing, and Validation” ANSI/ALI ALCTV.

 **WARNING** Use only the ALI-certified Anchor Bolts that came with your XPR-10 Series Lift. If you use components from a different source, you void your warranty and compromise the safety of everyone who installs or uses the Lift.

Lift buyers are responsible for conforming to all regional, structural, and seismic anchoring requirements specified by any other agencies and/or codes, such as the Uniform Building Code and/or International Building Code.




**Tip**

Consider *not* torquing the Anchor Bolts into position yet. Installing the Overhead Assembly and doing final leveling may be easier if there is some play in the Posts.

**Effective Embedment** is the location in the Hole where the Expansion Sleeve presses into the Concrete. This is where the Anchor Bolts get their holding strength; the further down into the Hole, the greater the holding strength.

**Nominal Embedment** is how far down into the Hole the bottom of the Anchor Bolt is, which does not tell you anything about the holding strength.




*Not necessarily to scale. Not all components shown.*

#### To install the Posts:

1. Using a Forklift or Shop Crane, move the Posts to the Chalk Line Guides you created earlier.
2. Stand up each Post, *one at a time*, and move it to the locations created by the Chalk Lines.
3. Double check your measurements against the **Specifications** for your Lift model.
4. Using the Base Plates as guides, drill each hole **4 inches** deep.

Do **not** drill all the way through the Concrete; if you punch completely through the slab, you could compromise the holding strength of the Anchor Bolts.




Go in straight; do not let the drill wobble.

Use a carbide bit (conforming to ANSI B212.15).

The diameter of the drill bit must be the same as the diameter of the Anchor Bolt. So if you are using a  $\frac{3}{4}$  inch diameter Anchor Bolt, for example, use a  $\frac{3}{4}$  inch diameter drill bit.

5. Vacuum each hole clean.




BendPak recommends using a vacuum to get the hole very clean.

You can also use a wire brush, hand pump, or compressed air; just **make sure to thoroughly clean each hole**.

Do **not** ream the hole. Do **not** make the hole any wider than the drill bit made it.

**Important:** The holding strength of an Anchor Bolt is partially based on the how cleanly the Expansion Sleeve presses against the Concrete. If the hole is dirty or too wide, there is less holding strength.

6. Make sure the Washer and Nut are in place, then insert the Anchor Bolt into the hole.





The Expansion Sleeve of the Anchor Bolt may prevent the Anchor Bolt from passing through the hole in the Base Plate; this is normal. Use a hammer or mallet to get the Expansion Sleeve through the Base Plate and into the hole.

Even using a hammer or mallet, the Anchor Bolt should only go into the hole part of the way; this is normal. If the Anchor Bolt goes all the way in with little or no resistance, the hole is too wide.


Once past the hole in the Base Plate, the Anchor Bolt eventually stops going down into the hole as the Expansion Sleeve contacts the sides of the hole; this is normal.

7. Hammer or mallet the Anchor Bolt the rest of the way down into the hole. Stop when the Washer is snug against the Base Plate.
8. Plumb each Post; install any needed Shims or the optional Adapter Trays (which let you stack the provided Auxiliary Adapters — also called Extenders — conveniently near the Lift Arms).



**Tip** If you are going to torque the Anchor Bolts later so that installing the Overhead Assembly and doing final leveling is a little easier, skip the next step. Instead, make sure the Anchor Bolts are securely in position; you do not want the Posts moving too much during the rest of the installation procedure.

9. Wrench each Nut **clockwise** to the recommended installation torque, 85 – 95 pound feet, using a Torque Wrench.



**Important:** Do **not** use an impact wrench to torque the Anchor Bolts.

Wrenching the Nut forces the Wedge up, forcing out the Expansion Sleeve and pressing it tightly against the Concrete.

---

## Installing the Overhead Assembly, Safety Shutoff Bar, and the Microswitch

The Overhead Assembly goes above and between the Powerside and Offside Posts. It holds the Equalizing Cables, the Hydraulic Hoses, the Microswitch wiring, and the Safety Lock Cable.

The Safety Shutoff Bar and the Microswitch (or two Microswitches if you ordered a three-phase Power Unit) are installed on the underside of the Overhead Assembly.

The Safety Shutoff Bar shuts off power to the Lift if the top of a Vehicle hits it; this trips the Microswitch, which cuts off power to the Lift, preventing it from going any higher.

The Microswitch **wiring** goes over the Overhead Assembly and down the Powerside Post to the Power Unit. Wiring the Microswitch is not covered in this section; it is covered in **Wiring the Microswitch**.

**⚠ DANGER** This section describes how to install the Microswitch(es) for your Lift. You do **not** need an Electrician to **install** the Microswitch, but **you do need an Electrician to connect the Microswitch(es) to electrical power.**

The Overhead Assembly is two pieces that are bolted together. The Overhead Assembly and the Safety Shutoff Bar come from the factory already assembled in the Narrow Configuration. On rare occasions, the two pieces could come from the factory unassembled.

This leaves you with these options:

- **You want the Wide Configuration.** If the Overhead Assembly and the Safety Shutoff Bar came from the factory assembled in the Narrow Configuration, and you earlier decided on the Wide Configuration, you need to change the Overhead Assembly and the Safety Shutoff Bar to the Narrow Configuration, install the Microswitch, and then put the Overhead Assembly into place.

**Note:** The Narrow or Wide Configuration decision should already have been made (in **Choosing a Wide or Narrow Configuration**). Refer to that section for additional information.

- **You want the Narrow Configuration.** If the Overhead Assembly and the Safety Shutoff Bar came from the factory assembled in the Narrow Configuration, which is what you want, install the Microswitch and then put the Overhead Assembly into place.
- **The Overhead Assembly comes unassembled.** If the Overhead Assembly and the Safety Shutoff Bar came from the factory unassembled, install the Overhead Assembly in the desired configuration, install the Safety Shutoff Bar, install the Microswitch, and then put the Overhead Assembly into place.

BendPak recommends putting the Overhead Assembly on saw horses to prepare it.

### To prepare and install the Overhead Assembly:

1. If the Overhead Assembly came unassembled, locate the two Overhead Assembly pieces and the four M10 x 1.5 x 25 Hex Head Bolts, four M10 x Ø20 Flat Washers, four M10 x Ø18 Split Lock Washers, and four M10 x 1.5 Nuts needed to connect them.


If your Overhead Assembly came assembled from the factory, even if in the wrong configuration for your installation, these pieces are already in place.

2. Put the Overhead Assembly together in the desired configuration.
3. Remove all four Overhead Assembly Sheaves and their Pins and Bolts from the ends of the Overhead Assembly pieces.


Keep them nearby, you will be putting them back into place in the next section of the installation.

The following drawings shows the bolting locations for both Narrow and Wide Configurations for Symmetric and Asymmetric models.

### Symmetric



### Asymmetric




**Note:** When you line up the two Overhead Assembly pieces together, there will be four holes that go through both pieces. Two holes on each side of the Overhead Assembly.

- Put the Safety Shutoff Bar in place in the desired configuration.

If you are switching the Safety Shutoff Bar from Narrow to Wide Configuration, loosen the Slider Stops, adjust the Safety Shutoff Bar appropriately, then re-tighten the Slider Stops.

The following drawing shows the components on the Safety Shutoff Bar.



The following procedure describes how to install a Microswitch on the Overhead Assembly, but does not describe how to wire it, which is covered in [Wiring the Microswitch](#).

If you have **two** Microswitches because you are using a three-phase Power Unit, simply install the two of them next to each other in the Microswitch Bracket.


**To install the Microswitch:**

1. Locate the Microswitch, the Microswitch Cover, the Bolts, and the Nuts required to install the Microswitch.

Each Microswitch comes with an individual cover that covers the connection points and wiring at the top of the Microswitch. The Microswitch Cover covers the Microswitch from the bottom; it bolts onto the Microswitch Bracket.

2. Put the Microswitch into position in the Microswitch Bracket such that the Safety Shutoff Bar, when moved upwards, will push up the Trigger.

The following drawing is a side view showing the Safety Shutoff Bar getting pushed up and triggering the Microswitch.



When the Trigger is pushed up, it completes the circuit and cuts power to the Power Unit, stopping the Lift from rising any further and thus preventing the top of your Vehicle from hitting the Overhead Assembly.

3. If you are installing a second Microswitch, put it into position next to the one you just installed.
4. Use the Bolts and Nuts to secure the Microswitch in place.
5. Bolt the Microswitch Cover into place.
6. Use an appropriate lifting device to put the Overhead Assembly into position.

Make sure the Microswitch Bracket is on the Powerside.

7. Bolt the Overhead Assembly to the top of the Posts using two Bolts and Nuts on each end.


## Installing the Equalizing Cables

Both Equalizing Cables should have been put into position on the Posts before the Posts were raised, which was covered in **Putting Equalizing Cables into Position**.

This section picks up where that section left off: the Button Ends of the Equalizing Cables (on both Posts) have been installed, routed around the Post Sheaves, and then pushed up above the Lift Head. They now need to be routed over the Overhead Assembly and then down to the top of the Lift Head.

**Important:** If your Equalizing Cables are not yet in position, you must go back and put them into position before performing the following procedure.

When Equalizing Cables are fully routed, they are mirror images of each other.



*Not necessarily to scale. Not all components shown. Some components exaggerated for clarity. Asymmetric model shown, so one cable is longer than the other.*

### To route the Equalizing Cables:

1. Manually raise both Lift Heads about 28 inches / 711 mm off the ground and engage them on the closest Safety Lock.

Make sure both Lift Heads are the same distance off the ground.


2. Make sure the Button Ends of both Equalizing Cables are still in the Slots in their Lock Plates, that both Equalizing Cables go under the Post Sheave in their Posts, and that the Threaded Ends have been routed through the Hole at the Top of the Lift Head.

Remember, for a Wide Configuration, use the Button End at the very end of the Equalizing Cable. For a Narrow Configuration, use the Button End away from the end of the Equalizing Cable.


3. Choose which one of the two Equalizing Cables you are going to put into position first, then remove the Nut from the Threaded End of that cable.

The Overhead Assembly Sheave, Sheave Pin, and Sheave Pin Bolt were previously removed. If they were mistakenly re-installed, you need to remove them again.

- Route the Threaded End of the Equalizing Cable up on the inside of the Post, under the Sheave Bracket, and then out over the top of the Overhead Assembly.



- Re-install the Overhead Assembly Sheave, Sheave Pin, and Sheave Pin Bolt.
- At the other Post, remove the Nut from the Threaded End of the other Equalizing Cable.  
The Overhead Assembly Sheave, Sheave Pin, and Sheave Pin Bolt were previously removed. If they were mistakenly re-installed, you need to remove them again.
- Route the Threaded End under the Sheave Bracket, then down the Post towards the Lift Head.
- Re-install both the Overhead Assembly Sheave, Sheave Pin, and Sheave Pin Bolt.
- Put the Threaded End of the Equalizing Cable through the hole at the top of the Lift Head, then install the Nut and securely tighten.



*Drawing not necessarily to scale. Not all components shown. View is from inside Lift looking at the inside of the Lift. Both Posts look the same from this viewpoint.*

- Perform Steps 3 through 9 for the other Equalizing Cable.

## Routing the Safety Lock Cable


The Safety Lock Cable and the Safety Lock Release Handle are used to release the Safety Locks, allowing the Lift to be lowered.

The following procedure describes how to put the Safety Lock Cable into place; it does **not** describe how to attach it to the Safety Lock Releases.

**⚠ WARNING** You will need to access the Overhead Assembly to route the Safety Lock Cable. Use care to avoid falling when working on a ladder or other lifting device.

### To route the Safety Lock Cable:

1. Locate the Safety Lock Cable.
2. **Starting on the inside of the Offside Post**, push the *loop end* of the Safety Lock Cable out through the hole in the Offside Post; leave the loop end hanging out of the hole, for now.



*Not necessarily to scale. Not all components shown.*

3. Route the other end of the Safety Lock Cable **under** the Safety Sheave, upwards on the inside of the Offside Post, up and over the Safety Sheave at the top of the Offside Post, across the Overhead Assembly, over the Safety Sheave at the top of the Powerside Post, and then downwards, on the inside of the Powerside Post, towards the Mounting Bracket.

Make sure the Safety Lock Cable stays on its Safety Sheaves; this keeps it out of the way of the Equalizing Cables and the Hydraulic Hoses.

4. **On the Powerside Post**, when the non-loop end of the Safety Lock Cable is near the Mounting Bracket, route it under the Safety Sheave, then push it out of the Powerside Post through a hole in the Post; leave the non-loop end hanging out of the hole, for now.

**Important:** When connecting the ends of the Safety Lock Cable later in the installation, make sure the Cable stays in all of the Safety Sheaves. This keeps it out of the way of the Hydraulic Hoses and Equalizing Cables.

5. **For both Posts**, locate the two Carriage Bolts (M10 rods, ~11 in / 275 mm long, threaded on both ends), two Nuts, and two Washers in the Parts Box, put them into place through the top of each Post (they go all the way through the top of the Post), and tighten them in place on both ends.



## Installing the Safety Assemblies

Your XPR-10 Lift has two Safety Assemblies: one on the Powerside Post (above the Power Unit) and the other on the Offside Post.

Routing the Safety Lock Cable was done earlier; refer to [Routing the Safety Lock Cable](#) for additional information.

The Safety Assembly on the **Powerside Post** includes a Safety Lock Release Handle, which angles up and is used to lower the Lift.

The Safety Assembly on the **Offside Post** is mostly the same as on the Powerside Post *except* that it does not have a handle.




### To install the two Safety Assemblies:

1. **Starting on the Powerside Post**, locate the Powerside Safety Assembly, a Safety Clevis Pin, a Spring, and one Cotter Pin.  
Refer to the drawings above for locations of the components of the two Safety Assemblies.
2. Insert the Safety Clevis Pin, from the right, through the hole in the right welded plate, then through the Safety Assembly, and then through the left welded plate.
3. Put the Spring on the left end of the Safety Clevis Pin, then install the Cotter Pin on the end of the Safety Clevis Pin.
4. Repeat Steps 1 through 4 for the Offside Safety Assembly on the Offside Post.


**Note:** The ends of the Safety Lock Cable should be sticking out of the hole in each Post, **but not attached** at either end. The following procedure describes how to hook up the Safety Cable on both Posts.

**To connect the Safety Lock Cable:**

1. **Starting on the Offside Post**, bring the loop end of the Safety Cable down through the *inside* of the Offside Post, then pull the Safety Cable out to the outside of the Offside Post.
2. Take the loop end and route it up and over the Bottom Pin, past the Safety Clevis Pin, and loop it over the right end of the Top Pin.



3. **Moving to the Powerside Post**, screw two Nuts and Washers onto the threaded end of the Welded Pin with Threads.
4. Bring the non-loop end of the Safety Cable down through the hole in the Post, put the non-loop end of the Safety Lock Cable over the front of the Welded Pin and into the hole in the Welded Pin with Threads, between the two Nuts and the two Washers.



5. Pull any slack out of the Safety Cable, then tighten the Nuts.  
When tightening the Nuts, keep tension on the Safety Cable and keep the Safety Cable centered between the two Nuts.
6. Operate the Safety Lock Release Handle, checking for proper operation of both Safety Assemblies.

**⚠ DANGER** Make sure that both the Powerside and the Offside Safety Assemblies engage properly **before** using the Lift.

---

## Mounting the Power Unit

This section describes how to mount the Power Unit for your Lift. You do **not** need an Electrician to **mount** the Power Unit, but you do need an Electrician to **connect** the Power Unit.

**Important:** Do not connect the Power Unit to the Hydraulic System or to the power source at this point in the installation; those connections will be made later.

The Power Unit **must** be mounted on the Mounting Bracket on the Powerside Post.

### To mount the Power Unit:


1. Find the supplied four Hex Bolts, four Nuts, and one Vibration Dampener.

 **Tip** The Power Unit is heavy. BendPak recommends having one person hold the Power Unit while a second person bolts it into place.

2. Put the Vibration Dampener into place next to the Mounting Bracket on the Powerside Post.  
Both the Vibration Dampener and the Mounting Bracket have four holes, one in each corner. Make sure to use all four holes to hold the Power Unit.
3. Move the Mount Plate on the back of the Power Unit next to the Vibration Dampener.
4. Push one of the Bolts through a hole in the Mount Plate, through the Vibration Dampener, and into the Mounting Bracket; attach a Nut to the thread end of the Bolt, then tighten the Nut.
5. Repeat Step 4 for the other three Bolts and Nuts.
6. Fill the reservoir with approved fluids.

The reservoir holds approximately 3.6 gallons (14 liters). Use care to keep the fluid clean when filling the reservoir.

**Important:** Do not connect the Power Unit to the Hydraulic System or the power source at this point.




## Connecting the Hydraulic Hoses

Some of the Hydraulic Hoses were put into place much earlier in the installation. It is now time to finish routing and installing them.

All XPR-10 Series Lifts use either three or four Hydraulic Hoses:

- **One Short Hydraulic Hose (A).** Goes from the Power Unit up to the Tee Fitting on the Powerside Post; connects on the outside of the Post. Not yet installed.
- **One Medium Hydraulic Hose (B).** Goes from the Tee Fitting on the inside of the Powerside Post down to the bottom of the Powerside Hydraulic Cylinder. Already installed.
- **One Long Hydraulic Hose (C).** Goes from the inside of the Powerside Post above the Tee Fitting, over the Overhead Assembly, and down the Offside Post to the bottom of the Offside Hydraulic Cylinder. Already connected to the Hydraulic Cylinder, but not yet routed over the Overhead Assembly to the Tee Fitting.
- **One Very Short Hydraulic Hose (D).** Goes on the inside of the Powerside Post, connecting to the Tee Fitting and then to the long Hydraulic Hose; **for Wide Configurations only**. Without this extension, the Long Hydraulic Hose would not be long enough for Wide Configurations. This Line is ~13" for Symmetric Lifts, ~8" for Asymmetric Lifts. *Not used for Narrow Configurations*. Not yet installed.

All Hydraulic Hoses and Hydraulic Fitting locations are shown in the drawing below.




The following procedure assumes the Hydraulic Hoses were put into position earlier in the installation. Refer to **Routing the Hydraulic Hoses** for more information. If they were **not** put into position earlier, you must do so now, **before** beginning the following procedure.

**To finish connecting the Hydraulic Hoses:**

1. Locate the Short Hydraulic Hose and the Elbow Fitting (P/N 5550183) for the Power Unit.
2. **On the Power Unit**, locate a Hydraulic Pressure Port on the Power Unit (labeled P, P1, or P2), remove the shipping plug, and install the Elbow Hydraulic Fitting.


The following drawing shows the locations of the Hydraulic Pressure Ports on the Power Units that are compatible with the XPR-10 Series of Lifts.



**Important:** There are multiple ports on the Power Units that are used with the XPR-10 Series Lifts. However, each XPR-10 Series Lift uses only **one** Hydraulic Pressure Port (labeled P1 in the drawing above) on the Power Unit. Do not connect to any of the other Ports and do not connect to more than one Hydraulic Pressure Port.

3. Tighten the Elbow Hydraulic fitting appropriately, with JIC end facing towards the Tee Fitting, as shown in the drawing on the following page.

The following drawing shows how to connect the Hydraulic Hoses in both Lift configurations.




*Drawing shows side of the Powerside Post. Not drawn to scale. Not all components shown.*

4. Connect the Short Hydraulic Hose to the JIC end of the Tee Fitting; finger tighten the connection. This connection is made on the outside of the Powerside Post. If the 06 JIC end of the Tee Fitting is not on the outside of the Powerside Post, this means the Tee Fitting was installed **incorrectly**.
5. Connect the other end of the Short Hydraulic Hose to the 06 JIC end on the Elbow Fitting.
6. **Switching to the Offside Post**, take the Long Hydraulic Hose and route it over the Overhead Assembly towards the Powerside Post, making sure to secure the Hose in the Clips inside the Posts and the Overhead Assembly.
7. If you are installing the Lift in a **Wide** Configuration, you need to install the Very Short Hydraulic Hose to the top of the Tee Fitting, and then install a Nipple Hydraulic Fitting (PN 5550095) to the top of the Very Short Hydraulic Hose.
8. Connect the Straight End of either the Long Hydraulic Hose (for Narrow Configurations) or the Very Short Hydraulic Hose (for Wide Configurations) to the 04 JIC end of the Tee Fitting.
9. Using appropriate tools, securely tighten all the connections.

## About Arm Restraint Gears

Arm Restraint Gears get installed on each Lift Arm on the opposite end from the Lift Pad.



The purpose of the Arm Restraint Gears is to hold the Lift Arms in place laterally (once they mesh with the Gear Stops) as the Lift Arm rises from the ground up to where the Lift Pads hit the manufacturer's recommended Lifting Points.

When the Lift is fully lowered, the Arm Restraint Gears are **not** meshed with the Gear Stops on the Lift Head. This is because you need to be able to move the Lift Arms to position them correctly under the Vehicle. When the Lift begins to rise, the Arm Restraint Gears mesh with the Gear Stops.

**Important:** Arm Restraint Gears do not keep the Lift Arms from moving once the weight of the Vehicle is on the Lift Arms. Arm Restraint Gears are designed to maintain the position of **unloaded** Lift Arms up to 150 pounds of horizontal (side to side) force. Put another way, Arm Restraint Gears keep the Lift Arms from moving laterally from just above the ground, when they mesh with the Gear Stops, until the Lift Pads start holding the weight of the Vehicle being raised.

Arm Restraint Gears for all XPR-10 models have an R imprinted on one side and an L imprinted on the other side. Before installing an Arm Restraint Gear, determine whether it is going to be a 'left' arm or a 'right' arm (described in [Installing Lift Arms](#)) and install the Arm Restraint Gear accordingly.

## Installing Lift Arms

There are several rules that govern which Lift Arms go where on a particular Lift.

The **first rule** is that 'short' Lift Arms get installed at the Front of the Lift and 'long' Lift Arms get installed at the Rear of the Lift.

(There is an exception to this rule: two Lift models, the XPR-10S-LP and the XPR-10XLS-LP, each have four Lift Arms of the *same length*; they can be installed at the Front or the Rear of these Lifts. The second rule still applies to them, however.)


To determine the Front and Rear of the Lift:

- **If you can only drive in one way.** The approach side is the Rear, the other side is the Front.
- **If you can drive in either way.** Choose one side as the Front and the other side as the Rear. The best way to make this decision is to pick one approach direction for the Vehicles you will be putting on the Lift, even though you can drive in either way. Once the decision is made, you approach the Lift from the Rear, so the other side is the Front.
- **If you have an Asymmetric Lift.** The 30° angled Lift Heads face the Rear of the Lift, so the other end is the Front.

The **second rule** is whether the Lift Arm is a 'right' or a 'left'. This is determined separately per Post.

To determine right and left, stand between the two Posts, then turn to face one of them straight on. From this viewpoint, the right side of the Post is the 'right' and the left side of the Post is the 'left'.

After finishing the first Post, repeat the process for the second Post.




The 'left' and 'right' designation comes into play when installing the Arm Restraint Gears on a Lift Arm. Once you install an Arm Restraint Gear on a Lift Arm, that Lift Arm can only be correctly used on the side you specified it for. For example, if you install an Arm Restraint Gear on a Lift Arm as Left, then it will not work correctly if you put that Lift Arm on the Right side of a Lift Head.

---


### To install an Arm Restraint Gear on a Lift Arm:

1. Find the Lift Arm, Arm Restraint Gear, three Bolts, three Washers, and three Split-Lock Washers.
2. Determine whether the Lift Arm is a 'left' or 'right' Lift Arm.
3. Turn the Arm Restraint Gear so that the L is facing up if the Lift Arm is a 'left' or the R is facing up if the Lift Arm is a 'right'.
4. Put the Arm Restraint Gear into place over the holes in the Lift Arm, place one of the Split-Lock Washers and Flat Washers onto a Bolt, then push that Bolt down through one of the holes in the Arm Restraint Gear and into the appropriate hole in the Lift Arm.
5. Using an appropriate tool, lightly tighten the Bolt into place.  
You want the Arm Restraint Gear to stay in place, but you also want to leave a little play in it.
6. Repeat Steps 5 and 6 for the other two Bolts.



### To install a Lift Arm in a Lift Head:

1. Raise the desired Lift Head at least three inches off the ground, then move the appropriate Lift Arm into place in the Lift Head.
2. Slide a Lift Head Pin through the holes in the Lift Head and the Lift Arm.  
The bottom of the Lift Head Pin needs to come out below the bottom hole in the Lift Head.  
You may need to move the Lift Arm around a little to fully align the holes so that the Lift Head Pin goes through all of the holes.
3. Push a Snap Ring into its grooves on the bottom of the Lift Head Pin.



4. Make sure the Arm Restraint Gears and the Gear Stop are meshing.
5. When the Arm Restraint Gears and the Gear Stop are meshing, fully tighten the Bolts holding the Arm Restraint Gears to 60 to 70 lb ft of torque.
6. Extend the Lift Arm as far as it will go and apply approximately 150 pounds of pressure.

The Lift Arms should not move and the Arm Restraint Gears and the Gear Stop should stay meshed; if they do not, take the Lift Arm off and start the process again.

- Repeat Steps 2 through 7 for the other three Lift Arms.

**⚠ WARNING** Make sure that the Arm Restraint Gears and the Gear Stops are meshing and staying in place when up to 150 pounds of lateral force is applied before putting the Lift into normal operation.

## Leveling

Before operating your Lift, you need to make sure the Lift Posts are straight and the Lift Arms are level:

- Lift Posts:** The Posts **must** be the same distance apart at the top and at the bottom.


To make sure the Posts are straight, measure the distance between the two Posts six inches below the Overhead Assembly and one foot off the ground (you will need to move the Lift Arms out of the way). The two measurements (**A** and **B** in the drawing below) must be the same.

If the Posts are not straight, shim them as required.

**⚠ CAUTION** If your Lift Posts are not straight or your Lift Arms are not level, this is a safety risk. The Vehicles you put on the Lift will be less secure; they could fall and cause injuries or damage to the Vehicle or to the Lift.

- Lift Arms:** When the Lift Posts are straight, make sure the Lift Arms are level. To make sure they are level, raise them to the first locking position and put a level on the Pads.

What can you do if the Lift Arms are not level? Adjust the Equalizing Cables. Determine which Lift Arm is low, then adjust the Nut on the bottom of the Threaded End of the Equalizing Cable until the Lift Arms are level. When you believe the Lift Arms to be level, raise the Lift and listen for the Lift Heads hitting the Safety Locks (there is a distinct thump). What you want is for the thumps to be simultaneous or close to it.



**Important:** If you have **not** yet torqued the Anchor Bolts (in order to make it easier to install the Overhead Assembly and to perform final leveling), you can torque them once you have completed final leveling.

---

## Contact the Electrician

As mentioned previously, there are installation tasks that require a certified Electrician.

 **DANGER** All wiring *must* be performed by a licensed, certified Electrician.

The Electrician needs to:

- **Connect to power.** The Power Unit comes with a pigtail for wiring to a power source. Have your Electrician connect a power cord with plug to the electrical box on the Lift (for connection to a power outlet) or have them wire it directly into the electrical system at the Lift location.
- **Connect the Microswitch to the Power Unit.** The Microswitch has to be wired to the Power Unit. The necessary wiring is included.
- **Install a Power Disconnect Switch.** Ensures you can quickly and completely interrupt electrical power to the Lift in the event of an electrical circuit fault, emergency situation, or when equipment is undergoing service or maintenance. You must put it within sight and easy reach of the Lift operator. Refer to [Installing a Power Disconnect Switch](#) for more information.
- **Install a Thermal Disconnect Switch.** Ensures the equipment shuts down in the event of an overload or an overheated motor. Refer to [Installing a Thermal Disconnect Switch](#) for more information.

These installation tasks are described in detail in the following sections.

The Electrician is responsible for providing:

- A power cord and appropriate 220 VAC plug for connecting to an appropriate power source or the items required to connect to the facility's power system
- a Power Disconnect Switch
- a Thermal Disconnect Switch

Additional information is supplied in the sections describing these tasks.

---

## Wiring the Microswitch

This section describes how to wire the Microswitch; *installing* the Microswitch was described in [Installing the Overhead Assembly, Safety Shutoff Bar, and the Microswitch](#).

The Lift comes with either one or two Microswitches, depending on the Power Unit:

- **1Ph Power Units.** You need only one Microswitch, which must be wired between incoming power and the Electrical Box on the Power Unit on one of the two “hot” wires.
- **3Ph Power Units.** You need two Microswitches, which must be wired between incoming power and the Electrical Box on the Power Unit on two of the three hot wires. Both Microswitches you receive are identical.

**Important:** If wiring *two* Microswitches, they ***must*** be wired on two **different** hot wires.

Refer to the diagrams in [Wiring Diagrams](#) for detailed Microswitch wiring information.

The following procedure assumes the Microswitch is already in place. If it is not, refer to [Installing the Overhead Assembly, Safety Shutoff Bar, and the Microswitch](#) to install it.

### To wire a Microswitch:

1. Locate the Microswitch Cable (14/4 SJO, UL 62, 300 VAC) supplied with the Lift and the Powerside Safety Cover.
2. ***On the Overhead Assembly***, appropriately connect one end of the Microswitch Cable to the Microswitch (or two Microswitches, for a 3 Phase Power Unit).

Refer to the diagrams in [Wiring Diagrams](#) for wiring information.

3. Route the Microswitch Cable from the Microswitch on the Overhead Assembly over to the Powerside Post, down the Powerside Post, out the hole in the Post near the top of the Safety Lock Release, and to the Electrical Box on the Power Unit.
4. Once the Microswitch Cable is routed from the Microswitch to the Power Unit, clip the Microswitch Cable using the clips on the Overhead Assembly and the inside of the Powerside Post.

Clipping the Microswitch Cable in place keeps it out of the way of the other components.

5. ***On the Power Unit***, open the Electrical Box and wire the Microswitch Cable per the instructions in [Connecting the Power Unit](#).

## Connecting the Power Unit

The Power Unit and the Microswitch must be connected to an appropriate power source.

**⚠ DANGER** All wiring **must** be performed by a licensed, certified Electrician. Do not perform any maintenance or installation on the Lift without first making sure that main electrical power has been disconnected from the Lift and cannot be re-energized until all procedures are complete. The Lift uses electrical energy; if your organization has Lockout/Tagout policies, make sure to implement them after connecting to a power source.


**Important:** Make clear to your Electrician that all electrical work **must** conform to applicable local, state, and federal codes, rules, and regulations, such as state and federal OSHA regulations and electrical codes.

There are several things you need to do to get your Power Unit ready for normal operation:

- Attach the Power Unit to the Powerside Post. *Already done.*
- Attach the Hydraulic Line to the correct location on the Power Unit. *Already done.*
- Wire the Microswitch. *Already done.*
- Attach the Power Unit and Microswitch to a power source. Covered in this section.
- Fill the Hydraulic Fluid reservoir. Covered in this section.

Some Power Units are provided by different vendors so there may be minor differences in look and feel. Nevertheless, all Power Units of the same type provide the same level of functionality.

The following drawing is a front view of a Power Unit. Your particular Power Unit may look somewhat different based on what type you purchased.



*Not necessarily to scale. Your Power Unit may be slightly different.*

Make clear to your Electrician that all electrical work **must** conform to applicable local, state, and federal codes, rules, and regulations, such as state and federal OSHA regulations and electrical codes.

---

## To prepare the Power Unit:

1. Have the Electrician locate the Pigtail coming out of the Electrical Box on the Power Unit.
2. Open the Electrical Box, remove the Pigtail, and then either:
  - Wire the Power Unit directly into the facility's electrical system.
  - Wire a power cord (with appropriate plug) *inside the Electrical Box* to the wiring that was connected to the Pigtail.

Wiring information is either on the outside of the Power Unit under the Electrical Box or inside the cover of the Electrical Box. Have the Electrician use that wiring information to wire the Power Unit to the power source.

3. Wire the Microswitch(es) into the incoming power.

Refer to **Wiring Diagrams** for wiring information.

4. Fill the Hydraulic Fluid reservoir with approved Hydraulic Fluid.

The reservoir holds ~3.5 gallons of Hydraulic Fluid, depending on which Power Unit you have.

When you receive the Power Unit, the reservoir is empty; you need to fill it.

Approved Hydraulic Fluids are any general purpose ISO-32, ISO-46, or ISO-68 hydraulic oil or approved automatic transmission fluids such as Dexron III, Dexron VI, Mercon V, Mercon LV, Shell Tellus S4 / S3 / S2, or any synthetic multi-vehicle automatic transmission fluid.

 **WARNING** Do not run the Power Unit without Hydraulic Fluid; you will damage it.

Important electrical information:

- Improper electrical installation can damage the Power Unit motor; this damage is **not** covered by the warranty.
- Use a separate circuit breaker for each Power Unit.
- Protect each circuit with a time-delay fuse or circuit breaker.
  - For a 220 VAC, single phase circuit, use a 25 amp or greater fuse.
  - For a 208-230 VAC three phase circuit, use a 20 amp or greater fuse.
  - For a 380 or 440 VAC three phase circuit, use a 15 amp fuse.
- As you require an Electrician on site to connect the Power Unit to a power source, you might also want to have them install the Power Disconnect Switch and the Thermal Disconnect Switch on the same visit.

 **DANGER** Risk of explosion: This equipment has internal arcing or parts that may spark and should not be exposed to flammable vapors. The Power Unit's motor should not be located in a recessed area or below floor level. Never expose the motor to rain or other damp environments; damage to the motor caused by water is not covered by the warranty.

## Installing a Power Disconnect Switch

### **WARNING**

A Power Disconnect Switch is **not** provided with this equipment.

A Power Disconnect Switch is a National Electrical Code (NEC) requirement. They are designed to interrupt main electrical power in the event of an electrical circuit fault, emergency situation, or when equipment is undergoing service or maintenance.

Make sure to install a Power Disconnect Switch that is properly rated for the incoming power source.


Your Power Disconnect Switch must be readily accessible and installed so that it is in easy reach of the operator or in their line of sight. The Power Disconnect Switch must be clearly marked to indicate its purpose.

The figure to the right shows a toggle-style Power Disconnect Switch located between the Lift's power source and its Power Unit. A quick flip of the switch immediately cuts power to the Lift.

In the case of the XPR-10 Series, the location directly above the Power Unit is being used by the Lowering Handle, so your Electrician may want to move the Power Disconnect Switch location up a little.

 **DANGER** Installing a Thermal Disconnect Switch **must** be performed by a licensed, certified Electrician.

Have the Electrician select a **UL-listed** Power Disconnect Switch.



## Installing a Thermal Disconnect Switch

 **WARNING** An XPR-10 Series Lift motor has **no** thermal overload protection.

Have the Electrician connect a motor Thermal Disconnect Switch or overload device that will make sure the equipment shuts down in the event of an overload or an overheated motor.

 **DANGER** Installing a Thermal Disconnect Switch **must** be performed by a licensed, certified Electrician. Do not perform **any** maintenance or installation on the Lift without first making sure that main electrical power has been disconnected from the Lift and **cannot** be re-energized until all procedures are complete.

High running amps that exceed the motor's full load amps (FLA) rating may result in permanent damage to the motor.

BendPak strongly recommends you **not** exceed the rated duty cycle of the Lift motor.

---

## Installing the Safety Covers

There are two Safety Covers, one for each Safety Assembly, on the outside of each Post.

Refer to **Installing the Safety Assemblies and the Safety Lock Cable** for more information about installing the Safety Assemblies.


### To install the Safety Covers:

1. Locate the two Safety Covers and four Cover Screws.
2. On the Offside Post, install the Cover Screws in each block.

Do not fully tighten the Cover Screws into the block: there must be enough space between the block and the Cover Screws to slide in the Safety Cover.

3. Slide the Safety Cover for the Offside Post into position, then fully tighten both Cover Screws into their blocks so that the Safety Cover is held securely.

The following graphics show the Offside Safety Covers installed on their respective Posts.



*Not drawn to scale. Not all components shown.*

4. Fully tighten both Cover Screws into their blocks so that the Safety Cover is held securely.
5. Repeat Steps 2 through 4 for the Powerside Post, making sure to position the Safety Release Handle through the Slot on the front of the Cover.

---

## Lubricating the Lift

XPR-10 Series Lifts work better and longer if you keep them lubricated.

Lubricate the following:

- Cable sheave pins, with WD-40 or equivalent.
- The four inside corners of both Posts, with light axle grease.

## Perform an Operational Test

Before putting your Lift into normal operation, we recommend raising and lowering it several times with a typical Vehicle on the Lift. This will help you get a feel for how to operate the controls and help get any residual air out of the Hydraulic System (sometimes called “bleeding” the system).

**⚠ DANGER** Automotive Lifts are dangerous tools when used by inexperienced or impaired technicians. When you even hear the words “automotive lift,” your brain should automatically register the fact that lifting a vehicle is a serious endeavor with life-threatening risks if mandatory lifting precautions are ignored.

During the Operational Test, check for proper installation and operation. Do not raise any additional Vehicles until a thorough Operational Test has been done with a typical Vehicle.

**⚠ WARNING** Never raise a Vehicle whose weight exceeds the rated capacity of the Lift. Do not leave the controls until the Lift is engaged on its Safety Locks. Only trained personnel should raise or lower the Lift.

### To perform an Operational Test:

1. Follow the instructions in **Raising a Vehicle** and **Lowering a Vehicle** to safely raise and lower a Vehicle on the Lift.

**⚠ WARNING** Be sure to follow the instructions carefully when it comes to contacting the manufacturer’s recommended Lifting Points on the underside of the Vehicle. If you do not, the Vehicle could become unstable and fall, which could damage the Vehicle, damage the Lift, and injure or even kill anyone under the Vehicle.

2. Adjust the Lift Arms under the Vehicle so the Adapters are **directly under** the Lifting Points for the Vehicle you are raising.

If necessary, use the included Auxiliary Adapters for extra height.

3. Raise the Lift until **just before** the Adapters make contact with the Lifting Points.
4. Check the Arm Restraint Gears on all four Lift Arms to make sure they are engaged.

If they are not engaged, move the Lift Arms back and forth until they engage.

5. Raise the Lift until the tires of the Vehicle are a few inches off the ground.
6. Check to make sure all four Adapters are making solid contact with the Lifting Points.

If any of the Adapters are **not** making solid contact with the Lifting Points, carefully lower the Lift and start over again; the Adapters **must** make solid contact with the Lifting Points.

7. Raise the Vehicle approximately three feet (one meter) off the ground, then lower it back down.

Watch and listen as the Lift raises and then lowers. The Lift may move erratically or make some odd noises the first couple of times you use it; this is normal.

**Tip**

Residual air in the Hydraulic System can cause the Lift to shake, move erratically, or squeak; this is normal when you first start using the Lift. It will soon stop doing this, as the Hydraulic System is self-bleeding.

8. Wait for one minute.

**NOTICE** The Power Unit is not a constant duty motor; ***it cannot be run continuously.***

9. Repeat the process, this time raising the Lift, engaging it on a Safety Lock position, taking it off the Safety Lock position, and then lowering it back down to the ground.

Again, follow the instructions in **Raising a Vehicle** and **Lowering a Vehicle** to safely raise and lower a Vehicle on the Lift, including engaging it on its Safety Locks.

10. If the Lift is working without shaking, moving erratically, or squeaking, there is no need to repeat the procedure.

If the Lift is shaking, moving erratically, or squeaking, repeat the procedure one more time.

If you continue to have issues, refer to **Troubleshooting** for assistance.

11. When the Lift is on the ground and the Vehicle is on all four tires, move the four Lift Arms to their full drive-through positions, then drive the Vehicle out.

12. With no Vehicle on the Lift Arms, press and hold the Up button on the Power Unit.

13. Have another person push up the Safety Shutoff Bar until it triggers the Microswitch.

If the Lift Arms do not stop rising when the Microswitch is triggered, this means the Microswitch is either not installed correctly or not wired correctly; check the wiring diagram for proper wiring.

**CAUTION**

Do not put the Lift into normal operation until you have confirmed that triggering the Microswitch stops the Lift Arms from rising.

## Review Final Checklist Before Operation

Make sure these things have been done before putting the Lift into normal operation:

- Review the **Installation Checklist** to make sure all steps have been performed.
- Make sure the Power Unit is getting power from the power source.
- Check the Hydraulic Fluid reservoir; it must be full of approved Hydraulic Fluid or automatic transmission fluid. ***You can harm the motor by running it without enough fluid.***
- Check the Hydraulic System for leaks.
- Make sure both Posts are properly plumbed, shimmed, and stable.
- Check to see that all Anchor Bolts are correctly torqued.
- Apply light axle grease to the inside of the Posts where the Slide Blocks move.
- Make sure both Carriage Bolts are in place and tightened near the top of both Posts.
- Make sure all Cables are properly positioned in their Sheaves.
- Make sure all Cable Sheave retaining pins and/or clips are secure.
- Make sure both Safety Assemblies are connected and working normally.
- Make sure that all Safety Locks are clear and free.
- Make sure an Operational Test has been done.
- Leave the *Installation and Operation Manual* with the owner/operator.

---

# Operation

This section describes how to operate your Lift.

 **DANGER** Automotive Lifts are dangerous tools when used by inexperienced or impaired technicians. When you even hear the words “automotive lift,” your brain should automatically register the fact that lifting a vehicle is a serious endeavor with life-threatening risks if mandatory lifting precautions are ignored.

## Lift Operation Safety Rules

**Important:** Your safety is dependent on reading, understanding, and implementing these Safety Rules. ***Do not skip over them; read them carefully and follow them!***

Do the following before you raise or lower a Vehicle on your Lift:

- **Check the Lift.** Check the Lift for any missing, heavily worn, or damaged parts. Do not operate the Lift if you find any issues; instead, take it out of service, contact your dealer, email [support@bendpak.com](mailto:support@bendpak.com), or call **(800) 253-2363**.
- **Check the area.** Keep the area around the Lift clean and free of obstructions; anything that could cause a problem for the Lift. Do not forget to check **above** the Lift. If you find an obstruction, move it out of the way. Do not allow any people or animals within 30 feet of the Lift while it is in motion.
- **Check the operators.** Make sure that everyone who is going to operate the Lift has been trained in its use, has read the labels on the unit, and has read the manual. Only the operator should be within 30 feet of the Lift when it is in motion. Do not allow children to operate the Lift. Do not allow anyone under the influence of drugs or alcohol to operate the Lift.
- **Check for safety.** Make sure everyone who is going to be walking near the Lift is aware of its presence and takes appropriate safety measures. Only put Vehicles on the Lift Arms. ***When raising a Vehicle on the Lift, do not leave it until it is positioned on Safety Locks.*** When lowering the Lift, do not leave it until it is on the ground.
- **Check the Vehicle.** Never exceed the Lift’s weight rating. Do not allow people inside a Vehicle you are going to raise. Make sure the Vehicle is not overbalanced on either end. Make sure you know the manufacturer’s recommended Lifting Points for the Vehicle. Never raise just one side, one corner, or one end of a Vehicle.

 **WARNING** Always use care when you are around your Lift. When it is in a lowered position, be careful not to trip over it. When it is raised, be careful not to bang your head on the Lift Arms or the Vehicle. ***When you are raising or lowering a Vehicle, keep all people, animals, and objects at least 30 feet away from the Lift.***

---

## About Lifting Points, Adapters, and Auxiliary Adapters

All of the Lifts in the XPR-10 Series are frame-engaging Lifts, which means that the Lift uses its four Lift Arms to raise Vehicles by their frames. This leaves the Wheels of the Vehicle free to be worked on.

One of the most important things to keep in mind when using a frame-engaging Lift is that the raised Vehicle needs to be balanced on the four Lift Arms. If the Vehicle is not balanced, it is more likely to become unstable and slide off the Lift, possibly damaging the Lift, the Vehicle, and anything under the Lift, including injuring people.

**⚠ WARNING** You **must** use all four Lift Arms when raising a Vehicle. Never use just one, two, or three Lift Arms to raise a Vehicle. The Vehicle will be unstable and could slip off the Lift, possibly damaging the Lift, damaging the Vehicle, and injuring anyone under it.

To balance a Vehicle on a frame-engaging Lift, you need to have the Adapters (also called Pads) contact the Vehicle on the manufacturer's recommended Lifting Points. By definition, when you raise a Vehicle by its Lifting Points, the Vehicle is balanced.

**Important:** The manufacturer's recommended Lifting Points do not take into consideration any major changes that might have been made to the Vehicle. If the motor is removed, for instance, or there is a 5,000 pound / 2,268 kg weight in the trunk, the Vehicle's Lifting Points will not be the best balancing points.

So how do you find the manufacturer's recommended Lifting Points? Some Vehicles have indicators on the underside that identify the Lifting Points; many do not.

Your best approach is to find the Vehicle in the book *Vehicle Lifting Points for Frame Engaging Lifts*, which was provided with your Lift, or contact the manufacturer of the Vehicle. The book also includes a page of safe lifting suggestions, which everyone who uses the Lift should read.

The book *Lifting it Right: A Safety Manual from the Automotive Lift Institute*, also provided with your Lift, includes a wide variety of information about Lifts and how to use them safely.

The Adapters and Auxiliary Adapters (also called height adapters or extenders) included with every XPR-10 Series Lift are:

- **Four Screw Lift Pads.** Best suited for Vehicles with Unibody constructions; they are also adjustable up to 3".
- **Four 2.5" / 63 mm Auxiliary Adapters.** Let you raise the height of your Auxiliary Adapters to make better contact with Vehicles.

Optional accessories for your XPR-10 Series Lift include:

- **Four Frame Cradle Pads.** Best suited for trucks, SUVs, and other Vehicles with Frame constructions. Highly recommended for raising these types of Vehicles correctly and safely.
- **Four 1.75" / 44 mm Auxiliary Adapters.** Let you raise the height of your Auxiliary Adapters.
- **Four 5" / 125 mm Auxiliary Adapters.** Let you raise the height of your Auxiliary Adapters.

**⚠ WARNING** You can stack Auxiliary Adapters, but only up to 9". If you stack Auxiliary Adapters above 9", the Vehicle could become unstable and slip off the Lift, possibly damaging the Lift, damaging the Vehicle, and injuring anyone under it.

---

## Raising a Vehicle

This section describes how to raise a Vehicle on your XPR-10 Series Lift.

-  **WARNING** Never raise a Vehicle whose weight exceeds the rated capacity of the Lift. Do not leave the controls until the Lift is engaged on a Safety Lock position or fully lowered. Only trained personnel should raise and lower the Lift.

### To raise a Vehicle:

1. Make sure all four Lift Arms are on the ground in their full drive-through positions.
2. Check under the Vehicle you are going to raise, check for the type of vehicle frame, and then put the most appropriate Adapters on the Lift Arms.

If you are lifting a sedan or a Vehicle with a unibody construction, a Screw Lift Pad is generally the best choice. If you are lifting an SUV, truck, or other Vehicle with a frame construction, a Frame Cradle Pad is generally the best choice.

-  **WARNING** Always use the Adapter type best suited for the Vehicle you are raising. If you use the wrong Adapter type, the Vehicle could become unstable.

3. Drive the Vehicle in.

-  **CAUTION** When driving a Vehicle into position, keep to the middle of the area between the Posts. If you hit a Lift Arm or any other portion of the Lift, you could damage the Vehicle and/or the Lift.

4. Put the Vehicle in park, put on the parking brake, and turn off the motor.  
If the Vehicle is a manual transmission, put it into first gear before turning off the motor.
5. Get out of the Vehicle; open the doors carefully to avoid banging them on the Lift.
6. Locate the manufacturer's recommended Lifting Points for the Vehicle you are raising.

If you are unsure where the Lifting Points are, consult *Vehicle Lifting Points for Frame Engaging Lifts*, which was provided with the Lift, or the manufacturer of the Vehicle. If you no longer have *Vehicle Lifting Points for Frame Engaging Lifts*, contact BendPak Support email [support@bendpak.com](mailto:support@bendpak.com) or call **(800) 253-2363** to get a replacement copy.

-  **WARNING** Do not 'eyeball' the best location for the Adapters. ***You must use the manufacturer's recommended Lifting Points.*** If you do not, the Vehicle could become unstable and fall, which could damage the Vehicle, damage the Lift, or injure or even kill anyone under the Vehicle.

7. Adjust the Lift Arms under the Vehicle so the Adapters are ***directly under*** the Lifting Points for the Vehicle you are raising.

If necessary, use the included Auxiliary Adapters for extra height.

8. Raise the Lift until ***just before*** the Adapters make contact with the Lifting Points.
9. Check the Arm Restraint Gears on all four Lift Arms to make sure they are engaged.  
If they are not engaged, move the Lift Arms back and forth until they engage.

10. Raise the Lift until the tires of the Vehicle are a few inches off the ground.
11. Check to make sure all four Adapters are making solid contact with the Lifting Points.

If any of the Adapters are **not** making solid contact with the Lifting Points, carefully lower the Lift and start over again; the Adapters **must** make solid contact with the Lifting Points.

12. Rock the Vehicle to make sure the Vehicle is stable and balanced.

If the Vehicle is **not** stable and balanced, lower the Lift back to the ground and start over.

If the Vehicle **is** stable and balanced, you can raise it to the desired height.

**⚠ DANGER** Do not raise the Lift further until you are certain the Vehicle on the Lift is both stable and balanced. If the Vehicle is **not** stable and balanced, it could fall, which could damage the Vehicle, damage the Lift, or injure or kill anyone under the Vehicle.

13. Press and hold the Up Button.

14. Listen as the Lift passes the Safety Locks; you should hear each side pass by the Safety Locks at approximately the same time.

15. When the Vehicle reaches the desired height, go past the next Safety Lock position (you will hear the clank as it passes), then release the Up Button.

16. Press and hold the Lowering Handle, which lowers the Lift onto the Safety Lock position you just passed. (Do not hold the Safety Lock Release Handle, that is for lowering the Lift to the ground.)


17. When the Lift stops moving down, it is engaged on its Safety Locks; release the Lowering Handle.

**Do not leave the Lift controls unless the Lift is engaged on its Safety Locks or fully lowered.**

18. Recheck the Adapters to make sure they are all still making solid contact with the Lifting Points.

19. Make sure the Lift is engaged on the same Safety Lock on both Posts. You do not want the Lift engaged on Safety Locks of two different heights or one Safety Lock engaged but the other not.

20. Begin work on the Vehicle.

<p><b>To raise Lift:</b></p> <ol style="list-style-type: none"><li>1. Press and hold Up Button.</li><li>2. When Lift is just past desired height, release Up Button.</li><li>3. Press and hold Lowering Handle.</li></ol> <p><i>Do not pull down the Safety Lock Release Handle. If you do, the Lift will continue to lower and will not engage on its Safety Locks.</i></p> <p>Lift engages on its Safety Locks and stops moving; release Lowering Handle when Lift stops.</p> <p><i>Only leave Lift on Safety Locks or fully lowered.</i></p>	 <p>The diagram shows a vertical control panel with three main components: a circular 'Up Button' at the top, a 'Lowering Handle' (a horizontal bar) in the middle, and a 'Safety Lock Release Handle' (a diagonal bar) at the bottom. Arrows point from the text labels to each of these components.</p>	<p><b>To lower Lift:</b></p> <ol style="list-style-type: none"><li>1. Press and hold Up Button for two to three seconds. This moves Lift off its Safety Locks.</li><li>2. Pull down and hold Safety Lock Release Handle <b>and</b> Lowering Handle. Lift begins lowering.</li><li>3. When Lift is fully lowered, release Safety Lock Release Handle and Lowering Handle.</li></ol> <p><i>Only leave Lift on Safety Locks or fully lowered.</i></p>
---	---	--

---

## Lowering a Vehicle

To lower a Vehicle off the Lift, first raise it a small amount to get it off its Safety Locks, then lower it.

### To lower a Vehicle off the Lift:

1. Check under and around the Vehicle to make sure the area is clear of all obstructions.  
If you find any obstructions, move them out of the way.
2. Press and hold the **Up** Button for a second or two to move the Lift off its Safety Locks.  
Raise the Lift at least two inches to get clear of the Safety Locks.
3. Pull down and hold the Safety Lock Release Handle (on the Powerside Post above and to the right of the Power Unit).
4. Push and hold the Lowering Handle (on the front of the Power Unit).

**Important:** Both the Safety Lock Release Handle *and* the Lowering Handle must be held down at the same time to lower the Lift.

The Lift begins lowering.

 **WARNING** Do not override the Lift controls; for safety purposes, they are designed to stop the Lift if released. Overriding the Lift controls could lead to damage to the Lift, damage to the Vehicle on the Lift, or injury (even death) to persons near the Lift.

Remain clear of the Lift as it comes down; obey the pinch point warning decals.

5. When the Lift is on the ground, release both Handles, then move all four Lift Arms to their full drive-through positions.
6. Drive the Vehicle out.


## About Safety Locks

Your Lift has 14 Safety Lock positions, spaced every three inches; having multiple Safety Lock positions let you lock the Lift at the best height for what you need to do.

A Safety Lock **position** is defined as when the Lift is engaged on both of the Lift's Safety Locks at the same height on both Posts.

**Important:** Always make sure the both Safety Locks are engaged at the same height on both Posts. You do not want the Lift engaged on Safety Locks of two different heights or the Safety Lock on one Post engaged but the Safety Lock on the other Post not engaged.

Safety Lock positions are created by the Safety Lock Weldments, which are on the back of each Lift Head. Safety Lock Weldments hit the Safety Locks and then move past them as the Lift Heads rise.



*Drawing not necessarily to scale. Not all components shown. Posts not shown for clarity. Offside Safety Lock not shown.*

As they move past the Safety Locks, the Weldments push the Safety Lock and the Safety Lock Release Handle down (the Safety Lock Release Handle is found on the Powerside Post only). When the Weldment is completely past the Safety Locks, the Safety Locks clank back into position between Weldments. This happens each time Safety Locks are passed, so you will generally be hearing multiple clanks as the Lift rises and lowers.

To engage the Lift on a Safety Lock position, wait until the Vehicle reaches the desired height for the work you are going to do, then listen for the clank as the Weldments pass the next Safety Lock position. When you hear the clank, release the Up Button and then hold down the Lowering Handle (on the front of the Power Unit) for a second or two to back the Weldments down onto the just-passed Safety Locks; **do not** hold down the Safety Lock Release Handle.

**⚠ WARNING** Only leave the Lift either fully lowered or engaged on Safety Locks. ***If you leave the Lift raised but not engaged on Safety Locks, the Vehicle is not secure.*** It could fall, possibly damaging the Vehicle, the Lift, and injuring anyone under the Vehicle.

---

# Maintenance

 **DANGER** Before performing any maintenance on your Lift, make sure it is completely disconnected from power. The Lift uses electrical energy; if your organization has Lockout/Tagout policies, make sure to implement them before performing any maintenance. If you come into contact with high voltage/current, you could be injured or killed.

## To maintain your Lift:

- **Daily:** Keep the Lift clean. Wipe up any spills, clean any dirt.
- **Daily:** Make a visual inspection of all moving parts and check for damage or excessive wear. Replace any damaged or worn parts before using the Lift.

 **DANGER** Do not use the Lift if the cables are damaged or extremely worn. If a Vehicle is raised when you notice the damage or extreme wear, very carefully lower the Vehicle to the ground. When the Lift is on the ground, remove it from service, disconnect it from power, and make arrangements to get it fixed.


- **Daily:** Make sure Safety Locks are in good operating condition. Do not use your Lift if the Safety Locks are damaged or excessively worn.
- **Weekly:** Check all controls to make sure they are functioning normally.
- **Weekly:** Check all labels on the Lift. Replace them if they are illegible or missing.
- **Monthly:** Lubricate the Posts. We recommend using white lithium grease or similar.
- **Monthly:** Check Hydraulic Fluid levels. Refill if low.
- **Monthly:** Check cable connections, bolts, and pins for proper mounting and torque.
- **Monthly:** Make sure all pivot arm pins are properly secure.
- **Every two months:** Check all Anchor Bolts to make sure they are correctly torqued. If they are not, torque them.
- **Every three to five years or as needed.** Carefully check the Equalizing Cables every three to five years, or immediately if there are signs of damage or extreme wear. See **Wire Rope Inspection and Maintenance** for additional information.

 **WARNING** Do not operate your Lift if you find maintenance issues; instead, remove it from service, then contact your dealer or BendPak Support via the Web at [bendpak.com/support](http://bendpak.com/support), via email at [support@bendpak.com](mailto:support@bendpak.com), or by phone at **(800) 253-2363**.

## Wire Rope Inspection and Maintenance

Your Lift's Lifting Cables, which are wire rope, should be inspected regularly:

- Wire rope should be replaced when there are visible signs of damage or extreme wear. *Do not use the Lift if it has damaged or worn Lifting Cables; **take it out of service!***



- Wire rope should be maintained in a well-lubricated condition at all times.

Wire rope is only fully protected when each wire strand is lubricated both internally and externally. Excessive wear shortens the life of wire rope. Use a wire-rope lubricant that penetrates to the core of the rope and provides long-term lubrication between each individual strand, such as 90-WT gear oil or ALMASOL® Wire Rope Lubricant. To make sure the inner layers of the rope remain well lubricated, lubrication should be done at least every three months during normal operation.

- All Sheaves and guide rollers that contact moving wire rope should be given regular visual checks for surface wear and lubricated to make sure they run freely. This should be done every three months during normal operation.

For all Sheave axles, use standard wheel bearing grease. For all Sheaves and/or guide rollers, use 90-WT gear oil or a similar heavy lubricant, applied by any method including pump/spray dispensing, brush, hand, or swabbing.

- How often should you inspect?

Wire rope should be visually inspected at least once each day when in use, as suggested by American Petroleum Institute's Recommended Practice 54 guidelines. Any wire rope that meets the criteria for removal must be immediately replaced.

- When should you replace wire rope due to broken wires?

Wire rope should be removed from service if you see six randomly distributed broken wires within any one lay length (where a single strand makes a full turn around the rope) or three broken wires in one strand within one lay length.

- Are there other reasons to replace your wire rope?

Yes. Corrosion that pits the wires and/or connectors, evidence of kinking, crushing, cutting, bird-caging, or a popped core, wear that exceeds 10% of a wire's original diameter, or heat damage.

- How do you find broken wires?

- a. Relax your rope to a stationary position and move the pick-up points off the Sheaves. Clean the surface of the rope with a cloth — a wire brush, if necessary — so you can see any breaks.
- b. Flex the rope to expose any broken wires hidden in the valleys between the strands.
- c. Visually check for any broken wires. One way to check for crown breaks is to run a cloth along the rope to check for possible snags.
- d. With an awl, probe between wires and strands and raise any wires that appear loose.

# Troubleshooting

This section describes how to troubleshoot your Lift.

**Note:** If your Lift is not functioning correctly, you must take it out of service until it is fixed.

**Important:** All repair work **must** be done by qualified personnel.

 **WARNING** The Lift uses electrical energy; if your organization has Lockout/Tagout policies, make sure to implement them before performing any Troubleshooting.

Issue	Action to Take
Lift does not raise or does not lower, once raised.	Make sure there is sufficient Hydraulic Fluid in the reservoir. Make sure there is no air in the Hydraulic System. Make sure none of the Hydraulic Hoses are pinched or leaking. Make sure the Power Unit is getting power. If the Hydraulic Fluid is dirty, replace it with clean fluid. Make sure the Lift is not overloaded. Make sure the load on the Lift is balanced.
Arms move erratically or squeak when in use.	Move the arms up and down a few times to flush any residual air from the Hydraulic System.
Lift does not stay up.	Make sure to leave the Lift engaged on its Safety Locks. Check for Hydraulic Fluid leaks.
Vehicle on Lift not level.	Make sure Lift is engaged on Safety Locks at the same height. Make sure the Safety Locks in both Posts are engaged. If either condition is not met, carefully lower the Vehicle back down to the ground and raise it again.
Motor not running.	Check connection to power source; make sure it is plugged in and the appropriate voltage. Check wiring diagram on Power Unit.
Hydraulic Fluid is dirty.	Replace the dirty Hydraulic Fluid with clean, approved ATF fluids, such as Dexron III, Dexron VI, Mercon V, Mercon LV, or comparable.
Lift makes odd noises.	Lubricate hinge points using white lithium grease.


If you continue to have issues with your Lift, take the Lift out of service, then contact your dealer or BendPak Support at [bendpak.com/support](http://bendpak.com/support), via email at [support@bendpak.com](mailto:support@bendpak.com), or by phone at **(800) 253-2363**.

# Wiring Diagrams


This section includes wiring information for the Microswitch(es).

**⚠ DANGER** All wiring **must** be performed by a licensed, certified Electrician. Make sure that main electrical power has been disconnected from the Lift and cannot be re-energized until all procedures are complete. If your organization has Lockout/Tagout policies, make sure to implement them after connecting the Lift to power.

## Single Phase



## Three Phase



# Labels



<b>IMPORTANT</b>	
OPERATION / MAINTENANCE INSTRUCTIONS - PLEASE READ	OPÉRATION / ENTRETIEN INSTRUCTIONS - Lisez S'IL VOUS PLÂT
<b>⚠ DANGER ⚠</b>	
Long wheelbase vehicles can damage lift and/or cause personal harm or injury if operated off level. All vehicles MUST be positioned on lift with CENTER OF GRAVITY midway between adapters.	Les véhicules à empattement long peuvent endommager l'élevateur et / ou causer des blessures corporelles aux opérateurs s'ils sont élevés de manière incorrecte. Tous les véhicules DOIVENT être placés sur l'élevateur avec le CENTRE DE GRAVITÉ à égale distance entre les adaptateurs.
<b>⚠ CAUTION ⚠    ⚠ MISE EN GARDE ⚠</b>	
Never lift any vehicle in any manner with FEWER than (4) arms. Rated capacity of each lift arm is no greater than 1/4 of the overall lifting capacity.	Ne jamais soulever un véhicule de quelque manière que ce soit avec moins de (4) bras. Le capacité nominale de chaque bras de levage n'est pas supérieure à 1/4 du capacité de levage globale.
<b>⚠ WARNING ⚠    ⚠ ATTENTION ⚠</b>	
<b>USE PROPER ADAPTERS</b> Do not attempt to lift trucks or other heavy types vehicles with standard frame adapters. ALWAYS use the correct adapter for the vehicle. ALWAYS REPLACE rubber wheels with new ones or ensure that the wheels are not damaged. See product information.	<b>UTILISEZ DES ADAPTATEURS APPROPRIÉS</b> N'essayez pas de soulever des camions ou d'autres véhicules à chassis standard avec des adaptateurs standards. TOUJOURS utiliser l'adaptateur approprié pour le véhicule. TOUJOURS REMPLACER les roues en caoutchouc par de nouvelles roues ou assurez-vous que les roues ne sont pas endommagées. Consultez toujours la notice relative à l'élevateur pour plus de détails.
<b>FRAME CRADLE ADAPTERS</b> (See #4) Designed for use with lifting trucks, vans or other frame vehicles that require additional stability.	<b>ADAPTATEURS DE CADRE DE CADRE</b> (Voir le #4) Conçus pour être utilisés avec des chariots, camionnettes ou autres véhicules à chassis standard qui nécessitent une stabilité supplémentaire.
<b>WIDE FRAME CRADLE ADAPTERS</b> (See #4) Recommended for use when lifting heavy duty wide frame vehicles. Fits axle "over" range up to 3.75 in.	<b>CADRE LARGE ADAPTATEURS DE CADRE</b> (Voir le #4) Recommandés pour une utilisation avec des véhicules à chassis large à large. Convient aux véhicules à chassis large jusqu'à 3,75 pouces.
<b>SUV &amp; VAN ADAPTERS</b> Recommended for trucks, SUVs and vans - not required for other lifting types.	<b>VUS &amp; ADAPTATEURS VAN</b> Recommandés pour les camions, SUV et les camionnettes nécessitant une aide de levage supplémentaire.
<b>STEEL LIFT PADS</b> Steel lift pads are recommended for use with all lift vehicles. They should be used on the chassis of all lift vehicles.	<b>TAMPONS DE LEVAGE EN ACIER</b> Tous les tampons de levage en acier sont recommandés pour être utilisés avec tous les véhicules à chassis standard. Ils doivent être utilisés sur le chassis de tous les véhicules à chassis standard.
<b>REPLACEMENT POLYURETHANE TUP PADS™</b> (See #5) Do not use lift pads in excess of 1000 lbs. Do not use lift pads of other materials.	<b>REMPLACEMENT POLYURETHANE TUP PADS™</b> (Voir le #5) Ne pas utiliser de tampons de levage en excès de 1000 livres. Ne pas utiliser de tampons de levage en d'autres matériaux.
<b>TO PLACE ORDER</b> Visit <a href="http://www.bendpak.com">www.bendpak.com</a> or call 1-800-939-9070	<b>POUR COMMANDER</b> Visitez <a href="http://www.bendpak.com">www.bendpak.com</a> ou composez 1-800-939-9070

<b>⚠ WARNING ⚠    ⚠ ATTENTION ⚠</b>	
<b>WIRE ROPE INSPECTION AND MAINTENANCE</b> • Lifting cables should be inspected at a minimum every 30 days. • All cables should be inspected for fraying, kinking, or other damage. • If a cable is found to be damaged, it should be replaced immediately. • All cables should be replaced with the same type and size as the original. • For all damaged cables, the factory must be notified immediately. • The factory must be notified immediately if a cable is found to be damaged. • The factory must be notified immediately if a cable is found to be damaged. • The factory must be notified immediately if a cable is found to be damaged.	<b>INSPECTION ET MAINTENANCE DES CÂBLES</b> • Les câbles de levage doivent être inspectés au minimum toutes les 30 jours. • Tous les câbles doivent être inspectés pour détecter toute usure, torsion ou autre dommage. • Si un câble est trouvé endommagé, il doit être remplacé immédiatement. • Tous les câbles doivent être remplacés par le même type et la même taille que l'original. • Pour tous les câbles endommagés, la fabrique doit être avisée immédiatement. • La fabrique doit être avisée immédiatement si un câble est trouvé endommagé. • La fabrique doit être avisée immédiatement si un câble est trouvé endommagé. • La fabrique doit être avisée immédiatement si un câble est trouvé endommagé.
<b>LIFT OPERATION</b> • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle. • Do not operate lift with more than one vehicle.	<b>OPÉRATION DE LEVAGE</b> • Ne pas utiliser l'élevateur avec plus d'un véhicule. • Ne pas utiliser l'élevateur avec plus d'un véhicule.

<b>MONTHLY MAINTENANCE</b> • Check all hydraulic hoses and lines for leaks and damage. • Check all hydraulic hoses and lines for leaks and damage. • Check all hydraulic hoses and lines for leaks and damage. • Check all hydraulic hoses and lines for leaks and damage. • Check all hydraulic hoses and lines for leaks and damage. • Check all hydraulic hoses and lines for leaks and damage.	<b>ENTRETIEN MENSUEL</b> • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage. • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage. • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage. • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage. • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage. • Vérifier toutes les lignes hydrauliques et les tuyaux pour détecter toute fuite ou dommage.
<b>WARNING!</b> • Do not attempt to lift vehicles with more than one adapter. • Do not attempt to lift vehicles with more than one adapter. • Do not attempt to lift vehicles with more than one adapter. • Do not attempt to lift vehicles with more than one adapter. • Do not attempt to lift vehicles with more than one adapter. • Do not attempt to lift vehicles with more than one adapter.	<b>ATTENTION!</b> • N'essayez pas de soulever des véhicules avec plus d'un adaptateur. • N'essayez pas de soulever des véhicules avec plus d'un adaptateur. • N'essayez pas de soulever des véhicules avec plus d'un adaptateur. • N'essayez pas de soulever des véhicules avec plus d'un adaptateur. • N'essayez pas de soulever des véhicules avec plus d'un adaptateur. • N'essayez pas de soulever des véhicules avec plus d'un adaptateur.

SANTA PAULA, CA USA  
WWW.BENDPAK.COM

LIFT TYPE: SURFACE MOUNT    CAP: MED/HVY DUTY    MFG. BPK    SEE DATA PLATE FOR PRODUCT DETAILS

POWER: ELECTRIC/HYDRAULIC    INSTALLATION - SEE OWNERS GUIDE OR CONTACT FACTORY

SAFETY INSTRUCTIONS: IF ATTACHMENTS, ACCESSORIES OR CONFIGURATION MODIFYING COMPONENTS ARE LOCATED IN THE LOAD PATH - CORRECT OPERATION OF THE LIFT AFFECTS THE LIFT ELECTRICAL LISTING OR AFFECT INTENDED VEHICLE ACCOMMODATION ARE USED ON THIS LIFT AND, IF THEY ARE NOT CERTIFIED FOR USE ON THIS LIFT, THEN THE CERTIFICATION OF THIS LIFT SHALL BECOME NULL AND VOID. CONTACT THE PARTICIPANT FOR INFORMATION PERTAINING TO CERTIFIED ATTACHMENTS, ACCESSORIES OR CONFIGURATION MODIFYING COMPONENTS.

BENDPAK LIFTS ARE SUPPLIED WITH CONCRETE FASTENERS MEETING THE CRITERIA AS PRESCRIBED BY ASTM E488 - 96(2003). LIFT BUYERS ARE RESPONSIBLE FOR ANY SPECIAL REGIONAL STRUCTURAL AND/OR SEISMIC ANCHORING REQUIREMENTS SPECIFIED BY ANY OTHER AGENCIES AND/OR CODES SUCH AS THE UNIFORM BUILDING CODE (UBC) AND/OR INTERNATIONAL BUILDING CODE (IBC).

THE MANUFACTURE, USE, SALE OR IMPORT OF THIS PRODUCT MAY BE SUBJECT TO ONE OR MORE UNITED STATES PATENTS, OR PENDING APPLICATIONS, OWNED BY BENDPAK, INC.  
DO NOT REMOVE    ENGINEERED BY BENDPAK INC. USA    MADE IN CHINA

## ⚠ DANGER ⚠

THE MAXIMUM LIFTING CAPACITY FOR THIS LIFT IS DESCRIBED BELOW

Maximum Lifting Capacity	10,000 lbs. / 4,536 kg
Max. Lifting Cap. / Front of Lift Center	5,000 lbs. / 2,268 kg
Max. Lifting Cap. / Rear of Lift Center	5,000 lbs. / 2,268 kg

Exceeding this weight capacity of this lift can damage lift and/or property and may cause personal harm, injury or death to operators and/or bystanders. All vehicles MUST be positioned on lift with CENTER OF GRAVITY midway between adapters and/or bystanders. Damage to lift due to overloading is NOT covered under warranty.

## ⚠ ATTENTION ⚠

MAXIMUM LIFTING CAPACITY  
CAPACITÉ DE LEVAGE MAXIMUM

# 10000 Lbs.

# 4536 Kg.

Exceeding this weight capacity of this lift can damage lift and/or property and may cause personal harm, injury or death to operators and/or bystanders. All vehicles MUST be positioned on lift with CENTER OF GRAVITY midway between adapters and/or bystanders. Damage to lift due to overloading is NOT covered under warranty.

## LA CAPACITÉ DE LEVAGE MAXIMUM POUR CE LEVAGE EST DÉCRIT CI-DESSOUS

Capacité de Levage Maximale	10,000 lbs. / 4,536 kg
Max. Capacité de Levage / Avant de centre de retraits	5,000 lbs. / 2,268 kg
Max. Capacité de Levage / Arrière de centre de levage	5,000 lbs. / 2,268 kg

Le dépassement de la capacité de levage peut endommager l'élevateur et / ou les biens et peut causer des dommages corporels, des blessures et / ou la mort aux opérateurs et / ou les témoins. Tous les véhicules DOIVENT être placés sur l'élevateur avec le CENTRE DE GRAVITÉ à mi-chemin entre les adaptateurs et / ou les témoins. Les dommages à l'élevateur dus à une surcharge ne sont pas couverts par la garantie.

## PLEASE READ

Internal packing oil may cause the cylinders to bleed oil during start up. This is normal. To extend cylinder and seal life, raise the lift to full height at least once every day.

## CERTIFIED AUTOMOTIVE LIFT

ALI CERTIFIED  
To the provisions of ANSULI ALCV21-2017  
SAFETY REQUIREMENTS FOR CONSTRUCTION, TESTING AND VALIDATION

Automotive Lift Institute, Inc. | Corland, NY 13045

MET LISTED  
Conforms to ANSULI 201  
SAFETY STANDARD FOR GARAGE EQUIPMENT

ANSULI 201  
SAFETY STANDARD FOR GARAGE EQUIPMENT

ALXXSAPLEXXX

## NOTICE

If attachments, accessories, or configuration modifying components are used on this lift, then the certification of this lift shall become null and void. Contact the participant for information pertaining to certified attachments, accessories, or configuration modifying components.

used on this lift are located in the load path and affect operation of the lift, affect the lift electrical listing, or affect intended vehicle accommodation; and if they are not certified for use on this lift, then the certification of this lift shall become null and void. Contact the participant for information pertaining to certified attachments, accessories, or configuration modifying components.

www.autolift.org    ©2011 by ALI, Inc.    ALI / WLSIA01

<b>TO RAISE LIFT:</b> 1. Press and hold UP button. 2. When lift is just PAST desired height, release UP button. 3. Hold down Lowering Handle. DO NOT hold down Safety Lock Release Handle. Lift engages on safety locks. 4. Release Lowering Handle.	<b>TO LOWER LIFT:</b> 1. Press and hold UP button for two to three seconds, moving lift off safety locks. 2. Hold down Safety Lock Release Handle and Lowering Handle. 3. When lift is fully lowered, release both handles.
--	--

# F

**NOTICE**

Read operating and safety manuals before using lift.

**NOTICE**

Proper maintenance and inspection is necessary for safe operation.

**NOTICE**

Do not operate a damaged lift.

**CAUTION**

Lift to be used by trained operator only.

**CAUTION**

Authorized personnel only in lift area.

**CAUTION**

Use vehicle manufacturer's lift points.

**CAUTION**

Always use safety stands when removing or installing heavy components.

**CAUTION**

Use height extenders when necessary to ensure good contact.

**CAUTION**

Auxiliary adapters may reduce load capacity.

**WARNING**

Clear area if vehicle is in danger of falling.

**WARNING**

Position vehicle with center of gravity midway between adapters.

**WARNING**

Remain clear of lift when raising or lowering vehicle.

**WARNING**

Avoid excessive rocking of vehicle while on lift.

**WARNING**

Do not override self-closing lift controls.

**WARNING**

Keep feet clear of lift while lowering.

**J**

**BP BendPak** Santa Paula, CA USA  
www.bendpak.com

MODEL NUMBER \_\_\_\_\_

DESCRIPTION \_\_\_\_\_

LIFT CAPACITY \_\_\_\_\_ DATE OF MFG. \_\_\_\_\_

<b>VOLTAGE</b>	<b>SERIAL NUMBER</b>
<input type="checkbox"/> 110-240V, 50-60 Hz, 1 Ph	_____
<input type="checkbox"/> 208-240V, 50-60 Hz, 1 Ph	
<input type="checkbox"/> 380-415V, 50-60 Hz, 3 Ph	
<input type="checkbox"/> 208-440V, 50-60 Hz, 3 Ph	
	<b>UPC</b>
	_____

**DANGER!** Disconnect Power Before Servicing

WARRANTY VOID IF DATA PLATE IS REMOVED PN 5905951

**EAC**

**K**

**BP BendPak** Santa Paula, CA USA  
www.bendpak.com

MODEL NUMBER \_\_\_\_\_

DESCRIPTION \_\_\_\_\_


LIFT CAPACITY \_\_\_\_\_ DATE OF MFG. \_\_\_\_\_

<b>VOLTAGE</b>	<b>SERIAL NUMBER</b>
<input type="checkbox"/> 110-240V, 50-60 Hz, 1 Ph	 <small>5153871</small>
<input type="checkbox"/> 208-240V, 50-60 Hz, 1 Ph	
<input type="checkbox"/> 380-415V, 50-60 Hz, 3 Ph	
<input type="checkbox"/> 208-440V, 50-60 Hz, 3 Ph	
	<b>UPC</b>
	 <small>89392-38382</small>



**DANGER!** Disconnect Power Before Servicing

WARRANTY VOID IF DATA PLATE IS REMOVED PN 5905950

**CE EAC**



# Parts Drawings




WHERE USED
XPR-10S
XPR-10S-168
XPR-10TS
XPR-10TS168
XPR-10S-1P
XPR-10S-1P-168

ITEM NO.	PART NUMBER	DESCRIPTION	QTY	REV
1	5215388	XPR-10 POWER SIDE POST ASSEMBLY	1	Y
2	5215389	XPR-10 OFF SIDE POST ASSEMBLY	1	Y
3	5210202	XPR-10 TOP TROUGH ASSEMBLY	1	J

DO NOT SCALE DRAWING	NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 93060
	DRAWN	TM	
	CHECKED	CA	11/29/2020
DIMENSIONS ARE IN INCH	THIRD ANGLE PROJECTION	TITLE	XPR-10 LIFT SUPERSTRUCTURE
	SEE DWG. NO.	SIZE	5245227
		REV	Z
SCALE: 1:30			SHEET 1 OF 1




DETAIL A  
SCALE 1: 6

ITEM NO.	PART NUMBER	DESCRIPTION	QTY	REV
1	5600507	XPR-10 INNER TOP TROUGH WELDMENT	1	E
2	5600506	XPR-10 OUTER TOP TROUGH WELDMENT	1	E
3	5565350	D2/GP/P/CL/XPR/PL-7000 SAFETY SHEAVE SPACER	2	C
4	5575112	D2/GP/P/CL/XPR/PL-7000 SAFETY SHEAVE	2	C
5	5575111	D2-8F, XPR-9/10 SHEAVE ASSEMBLY	4	G
6	5620141	XPR-9/10 CABLE SHEAVE PIN WELDMENT	4	F
7	5530030	HHB M6 x 1 x 8	4	-
8	5530756	HHB M6 x 1 x 25	2	-
9	5530738	HHB M10 x 1.5 x 25	6	-
10	5535013	NUT M10 x 1.5 NL	2	-
11	5535357	NUT M6 x 1.0 NL	2	-
12	5545341	WASHER M10 x Ø20 FLAT	6	-
13	5580211	STEEL HOLE PLUG 1 1/4"	1	-
14	5620445	XPR TRIP STOP BAR SLIDER WELDMENT	1	C
15	5300815	IOAP/D2/XPR STOP BAR CUSHION	1	D
16	5530055	SSS M6x1x10	2	-
17	5545200	WASHER M10 x Ø18 SL	4	-
18	5535998	NUT M10 x 1.5	4	-
19	5600501	XPR-10/10A MICROSWITCH STOP BAR WELDMENT	1	B

DO NOT SCALE DRAWING	NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 93060
	DRAWN	TM	
	CHECKED	CA	5/24/2018
DIMENSIONS ARE IN MM	THIRD ANGLE PROJECTION	TITLE	XPR-10 TOP TROUGH ASSEMBLY
	SEE DWG. NO.	SIZE	5210202
		REV	J
SCALE: 1:18			SHEET 1 OF 2




**BendPak**  
 1445 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10S PRODUCTION LIFT VER E

SEE DWG. NO.	REV
A 5260575	W

SCALE: 1:45 SHEET 2 OF 3




**BendPak**  
 1445 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10S-LP PRODUCTION LIFT VER E

SEE DWG. NO.	REV
A 5260566	X


SCALE: 1:45 SHEET 2 OF 3



**BendPak.**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10S PARTS BOX**

SEE DWG. NO. **A** REV **E**  
 SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10S  
 XPR-10S-LP  
 XPR-10IS

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174518	D2-12/15, XPR CLEARFLOOR PARTS BAG	1	N
2	5505116	D2-8F, XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5395367	CABLE ASSEMBLY Ø10 x 1007.6mm DBST	2	C
4	5370832	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2299mm SB	1	F
5	5370017	HYDRAULIC HOSE ASSEMBLY Ø10 x 1219mm SB	1	D
6	5395047	Ø2.4 x 7747 SAFETY CABLE	1	F
7	5370038	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 8015 SB	1	G
8	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
9	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
10	5715003	POWER UNIT VIBRATION DAMPENER	1	B
11	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
12	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
13	5734604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
14	5716173	D2-8/12/15, GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
15	5716174	D2-8/12/15, GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
16	5746192	ARM ADAPTER, MEDIUM	4	D
17	5540281	C RING Ø38mm OD 5103-150	4	-
18	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
19	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
20	5370176	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 330mm DS	1	F
21	5350095	FTG NPL -04 JIC x -04 JIC	1	-
22	5330337	AB 3/4" x 6.3"	12	-
23	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
24	5525150	SPDT MICRO SWITCH:25A@125VAC	1	-
25	5525112	MICRO SWITCH COVER-5PA2	1	-
26	5520116	14-4 SJO UL 62 CABLE 300vac	3635mm*	-
27	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

DRAWN TM DATE 10/12/2018  
 CHECKED OR DATE 10/19/2020

DIMENSIONS ARE IN MM


THIRD ANGLE PROJECTION

**BendPak.**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10S PARTS BOX**

SEE DWG. NO. **A** REV **E**  
 SCALE: 1:30 SHEET 1 OF 2

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BENDPAK INC. IS PROHIBITED.



ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5505113	2 POST SAFETY CLEVIS PIN	2	H
2	5715196	D2/XPR POLYETHYLENE COVER BLOCK 105 x 80	2	D
3	5535022	NUT 9/16"-18 IN	1	-
4	5550113	FIG ELB -04 NPT L x -04 JIC	2	-
5	5550183	FIG ELB -06 JIC -06L ORB	1	-
6	5550003	FIG TEE -04 JIC -04 JIC -06 JIC	1	-
7	5505350	MODEL #21 I HAIR PIN/ LARGE	2	-
8	5530261	PHPS M6 x 1 x 10	4	-
9	5545347	WASHER, M12 FLAT WASHER	2	-
10	5535354	NUT M12 x 1.75	10	-
11	5535001	NUT M8 x 1.25 NL	4	-
12	5530010	HBB M8 x 1.25 x 25	4	-
13	5545200	WASHER M10 x Ø18 SL	4	-
14	5535998	NUT M10 x 1.5	4	-
15	5530760	HBB M10 x 1.5 x 38	4	-
16	5540775	R.H., 2.5 WIRE DIA., Ø20.5 x 75 LG	2	B
17	5530799	HSDS M4.2 x 1.41 x 20	2	-
18	5545355	C WASHER SHIM FOR LIFTS	20	-
19	5545341	WASHER M10 x Ø20 FLAT	4	-
20	5550313	NUT M10 x 1.5 NL	4	-
21	5550115	ROTOR CLIP 12mm SS	1	-
22	5530115	BHS 6-32 x 1.25	2	-
23	5530190	HN 6-32	2	-
24	5520140	ROMEX CONNECTOR 3/8 #6623	2	-
25	5530093	HBB M6 x 1 x 20	4	-
26	5545005	M6 FLAT WASHER	8	-
27	5535357	NUT M6 x 1.0 NL	4	-
28	5580012	LIQUID PTFE THREAD SEALANT 50ml	1	-

DO NOT SCALE DRAWING

NAME: \_\_\_\_\_ DATE: \_\_\_\_\_

DRAWN: TM 02/11/2010

CHECKED: OR 10/19/2020

THIRD ANGLE PROJECTION


PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BENDPAK, INC. IS PROHIBITED.

**BendPak**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 92360

TITLE: D2-12/15, XPR CLEARFLOOR PARTS BAG

SEE DWG. NO. A 5174518 REV N

SCALE: 1:30 SHEET 1 OF 1



ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5505113	2 POST SAFETY CLEVIS PIN	2	H
2	5715196	D2/XPR POLYETHYLENE COVER BLOCK 105 x 80	2	D
3	5535022	NUT 9/16"-18 IN	1	-
4	5550113	FIG ELB -04 NPT L x -04 JIC	2	-
5	5550183	FIG ELB -06 JIC -06L ORB	1	-
6	5550003	FIG TEE -04 JIC -04 JIC -06 JIC	1	-
7	5505350	MODEL #21 I HAIR PIN/ LARGE	2	-
8	5530261	PHPS M6 x 1 x 10	4	-
9	5545347	WASHER, M12 FLAT WASHER	2	-
10	5535354	NUT M12 x 1.75	10	-
11	5535001	NUT M8 x 1.25 NL	4	-
12	5530010	HBB M8 x 1.25 x 25	4	-
13	5545200	WASHER M10 x Ø18 SL	4	-
14	5535998	NUT M10 x 1.5	4	-
15	5530760	HBB M10 x 1.5 x 38	4	-
16	5545201	WASHER, M12 SPRING LOCK	8	-
17	5545027	WASHER M12 x Ø37 x 3mm	16	-
18	5530076	HBB M12 x 1.75 x 35mm	8	-
19	5540075	R.H., 2.5 WIRE DIA., Ø20.5 x 75 LG	2	B
20	5530799	HSDS M4.2 x 1.41 x 20	2	-
21	5545355	C WASHER SHIM FOR LIFTS	20	-
22	5535013	NUT M10 x 1.5 NL	4	-
23	5545341	WASHER M10 x Ø20 FLAT	4	-
24	5505031	ROTOR CLIP 12mm SS	1	-
25	5530115	BHS 6-32 x 1.25	2	-
26	5535190	HN 6-32	2	-
27	5520140	ROMEX CONNECTOR 3/8 #6623	2	-
28	5580012	LIQUID PTFE THREAD SEALANT 50ml	1	-
29	5530093	HBB M6 x 1 x 20	4	-
30	5545005	M6 FLAT WASHER	8	-
31	5535357	NUT M6 x 1.0 NL	4	-

DO NOT SCALE DRAWING

NAME: \_\_\_\_\_ DATE: \_\_\_\_\_

DRAWN: TM 01/26/2010

CHECKED: OR 10/19/2020

THIRD ANGLE PROJECTION



PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BENDPAK, INC. IS PROHIBITED.

**BendPak**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 92360



TITLE: XPR CLEARFLOOR EXTENDED PARTS BAG

SEE DWG. NO. A 5174218 REV N


SCALE: 1:18 SHEET 1 OF 1



<b>BP BendPak.</b>	
1645 LEMONWOOD DR. SANTA PAULA, CA 93060	
TITLE: XPR-10S-168 PRODUCTION LIFT VER E	
SIZE DWG. NO.	REV
A 5260574	W
SCALE: 1:45	SHEET 2 OF 3



<b>BP BendPak.</b>	
1645 LEMONWOOD DR. SANTA PAULA, CA 93060	
TITLE: XPR-10S-168-LP PRODUCTION LIFT VER E	
SIZE DWG. NO.	REV
A 5260246	H
SCALE: 1:45	SHEET 2 OF 3



**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10S EXTENDED PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	5250089	<b>D</b>

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10S-168  
 XPR-10S-168-LP  
 XPR-10TS-168

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174218	XPR CLEARFLOOR EXTENDED PARTS BAG	1	N
2	5505116	D2-8F, XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595368	CABLE ASSEMBLY Ø10 x 1129mm DBST	2	C
4	5570832	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2299mm SB	1	F
5	5570017	HYDRAULIC HOSE ASSEMBLY Ø10 x 1219mm SB	1	D
6	5595104	XPR-10/10A EXTENDED Ø2.4 X 8839 SAFETY CABLE	1	E
7	5570005	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 9233 SB	1	F
8	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
9	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
10	5715003	POWER UNIT VIBRATION DAMPENER	1	B
11	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
12	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
13	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
14	5716173	D2-8/12/15, GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
15	5716174	D2-8/12/15, GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
16	5746192	ARM ADAPTER, MEDIUM	4	D
17	5540281	C RING Ø38mm OD 5103-130	4	-
18	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
19	5525150	SPDT MICRO SWITCH:25A@125VAC	1	-
20	5525112	MICRO SWITCH COVER-5PA2	1	-
21	5520116	14-4 SJO UL 62 CABLE 300vac	4275mm <sup>2</sup>	-
22	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
23	5570176	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 330mm DS	1	F
24	5530095	FTG NPL -04 JIC x -04 JIC	1	-
25	5530337	AB 3/4" x 6.3"	12	-
26	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
27	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

DRAWN	TM	DATE	10/12/2018
CHECKED	OR	DATE	10/19/2020



THIRD ANGLE PROJECTION

**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10S EXTENDED PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	5250089	<b>D</b>

SCALE: 1:30 SHEET 1 OF 2




WHERE USED
XPR-10AS
XPR-10AS-168
XPR-10AS-LP
XPR-10AS-168-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5215388	XPR-10 POWER SIDE POST ASSEMBLY	1	Y
2	5215389	XPR-10 OFF SIDE POST ASSEMBLY	1	Y
3	5210211	XPR-10A TOP TROUGH ASSEMBLY	1	C

DO NOT SCALE DRAWING		NAME	DATE	<b>BendPak</b> 1445 LEMONWOOD DR. SANTA PAULA, CA 93060
DRAWN	TM	10/07/2014		
CHECKED	OR	11/9/2020		
DIMENSIONS ARE IN MM		THIRD ANGLE PROJECTION	TITLE:	
			XPR-10AS LIFT SUPERSTRUCTURE	
		SIZE DWG. NO.	REV	
		A	5245044	L
		SCALE: 1:30		SHEET 1 OF 1







DETAIL A  
SCALE 1:6

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5600926	XPR-10A INNER TOP TROUGH WELDMENT	1	B
2	5600925	XPR-10A OUTER TOP TROUGH WELDMENT	1	B
3	5365350	D2/GP/PCI/XPR/PL-7000 SAFETY SHEAVE SPACER	2	C
4	5375112	D2/GP/PCI/XPR/PL-7000 SAFETY SHEAVE	2	C
5	5375111	D2-BE, XPR-9/10 SHEAVE ASSEMBLY	4	G
6	5620141	XPR-9/10 CABLE SHEAVE PIN WELDMENT	4	F
7	5330030	HHB M6 x 1 x 8	4	-
8	5330756	HHB M6 x 1 x 25	2	-
9	5330738	HHB M10 x 1.5 x 25	6	-
10	5335013	NUT M10 x 1.5 NL	2	-
11	5335357	NUT M6 x 1.0 NL	2	-
12	5345341	WASHER M10 x Ø20 FLAT	6	-
13	5380211	STEEL HOLE PLUG 1 1/4"	1	-
14	5620445	XPR TRIP STOP BAR SLIDER WELDMENT	1	C
15	5300815	10AP/D2/XPR STOP BAR CUSHION	1	D
16	5330055	SSS M6X1X10	2	-
17	5345200	WASHER M10 x Ø18 SL	4	-
18	5335998	NUT M10 x 1.5	4	-
19	5600301	XPR-10/10A MICROSWITCH STOP BAR WELDMENT	1	B

DO NOT SCALE DRAWING		NAME	DATE	<b>BendPak</b> 1445 LEMONWOOD DR. SANTA PAULA, CA 93060
DRAWN	TM	10/07/2014		
CHECKED	AW	12/20/2017		
DIMENSIONS ARE IN MM		THIRD ANGLE PROJECTION	TITLE:	
			XPR-10A TOP TROUGH ASSEMBLY	
		SIZE DWG. NO.	REV	
		A	5210211	C
		SCALE: 1:18		SHEET 1 OF 2







**BendPak.**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10AS-168  
 PRODUCTION LIFT VER F

SEE DWG. NO. REV  
**A** 5260561 X

SCALE: 1:45 SHEET 2 OF 3




**BendPak.**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10AS-168-LP  
 PRODUCTION LIFT VER F

SEE DWG. NO. REV  
**A** 5260559 X

SCALE: 1:45 SHEET 2 OF 3




**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10AS PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	<b>5250084</b>	<b>E</b>

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10AS  
 XPR-10AS-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174518	D2-12/15, XPR CLEARFLOOR PARTS BAG	1	N
2	5505116	D2-8F, XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595073	CABLE ASSEMBLY Ø10 x 9999mm DBST	1	D
4	5595072	CABLE ASSEMBLY Ø10 x 10115mm DBST	1	D
5	5570832	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2299mm SB	1	F
6	5570017	HYDRAULIC HOSE ASSEMBLY Ø10 x 1219mm SB	1	D
7	5595047	Ø2.4 x 7747 SAFETY CABLE	1	F
8	5570058	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 8090 SB	1	C
9	5570065	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 203mm DS	1	D
10	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
11	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
12	5715003	POWER UNIT VIBRATION DAMPENER	1	B
13	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
14	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
15	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
16	5716173	D2-8/12/15, GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
17	5716174	D2-8/12/15, GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
18	5746192	ARM ADAPTER, MEDIUM	4	D
19	5540281	C RING Ø38mm OD 5103-150	4	-
20	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
21	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
22	5550095	FIG NPL-04 JIC x-04 JIC	1	-
23	5530337	AB 3/4" x 6.3"	12	-
24	5525150	SPDT MICRO SWITCH-25A@125VAC	1	-
25	5525112	MICRO SWITCH COVER-5PA2	1	-
26	5520116	14-4 SJO UL 62 CABLE 300vac	3635mm*	-
27	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
28	5701660	TOP A/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

NAME DATE  
 DRAWN TM 10/11/2018  
 CHECKED OR 10/19/2020

DIMENSIONS ARE IN MM

THIRD ANGLE PROJECTION


**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10AS PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	<b>5250084</b>	<b>E</b>

SCALE: 1:35 SHEET 1 OF 2

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS  
 THE SOLE PROPERTY OF BENDPAK INC. ANY  
 REPRODUCTION OR TRANSMISSION IN ANY FORM  
 WITHOUT THE WRITTEN PERMISSION OF BENDPAK INC. IS  
 PROHIBITED.




**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10AS EXTENDED PARTS BOX

SIZE	DWG. NO.	REV
A	5250087	E

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10AS-168  
 XPR-10AS-168-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174218	XPR CLEARFLOOR EXTENDED PARTS BAG	1	N
2	5505114	D2-8F, XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595837	CABLE ASSEMBLY Ø10 x 11219mm DBST	1	D
4	5595923	CABLE ASSEMBLY Ø10 x 11335mm DBST	1	D
5	5570065	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 203mm DS	1	D
6	5570832	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2299mm SB	1	F
7	5570017	HYDRAULIC HOSE ASSEMBLY Ø10 x 1219mm SB	1	D
8	5595104	XPR-10/10A EXTENDED Ø2.4 x 8839 SAFETY CABLE	1	E
9	5570059	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 9308 SB	1	C
10	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
11	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
12	5715003	POWER UNIT VIBRATION DAMPENER	1	B
13	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
14	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
15	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
16	5716173	D2-8/12/15, GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
17	5716174	D2-8/12/15, GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
18	5746192	ARM ADAPTER, MEDIUM	4	D
19	5540281	C RING Ø38mm OD. 5103-150	4	—
20	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
21	5716634	D2/10AF/XPR MICROSWITCH COVER, PLASTIC	1	B
22	5550095	FIG NPL -04 JIC x -04 JIC	1	—
23	5530337	A6 3/4" x 6.3"	12	—
24	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	—
25	5525150	SPDT MICRO SWITCH H25A @125VAC	1	—
26	5525112	MICRO SWITCH COVER-SP2	1	—
27	5520114	14-4 SJO UL 42 CABLE 300vac	4275mm*	—
28	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

NAME: DATE: **BendPak**  
 DRAWN: TM 10/12/2018  
 CHECKED: OR 10/19/2020



DIMENSIONS ARE IN MM

THIRD ANGLE PROJECTION

TITLE: XPR-10AS EXTENDED PARTS BOX

SIZE	DWG. NO.	REV
A	5250087	E

SCALE: 1:30 SHEET 1 OF 2





WHERE USED
XPR-10XLS
XPR-10XLS-181
XPR-10XLS-LP
XPR-10XLS-181-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5215442	XPR-10XLS/AXIS POWER SIDE POST ASSEMBLY	1	K
2	5215440	XPR-10XLS/AXIS OFF SIDE POST ASSEMBLY	1	K
3	5210202	XPR-10 TOP TROUGH ASSEMBLY	1	J



DO NOT SCALE DRAWING		NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 92060
DRAWN	TM	05/10/2018		
CHECKED	OR	11/05/2020		
DIMENSIONS ARE IN MM		THIRD ANGLE PROJECTION		TITLE: XPR-10XLS LIFT SUPERSTRUCTURE
	<small>PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK INC. ANY REPRODUCTION OR TRANSMISSION OF THIS DRAWING WITHOUT THE WRITTEN PERMISSION OF BENDPAK INC. IS PROHIBITED.</small>			SEE DWG. NO. <b>A</b> 5245049
				REV <b>E</b>
				SCALE: 1:30 SHEET 1 OF 1





ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5245049	XPR-10XLS LIFT SUPERSTRUCTURE	1	E
2	5250203	XPR-10XLS PARTS BOX	1	E
3	5215287	XPR-9S/10S LOW PROFILE TRIPLE TELESCOPING ARM ASSEMBLY	2	L
4	5215700	XPR-9S/10S LOW PROFILE MEDIUM ARM ASSEMBLY	2	K
5	5905109	WARNING ALI/WL 101	1	--
6	5905131	2 POST DECAL KIT, LESS ALI	1	E
7	5905403	MAX CAPACITY 10K DANGER LABEL, ENGLISH-FRENCH	1	--
8	5905465	MANUFACTURER LABEL	1	--
9	5905655	MAX CAPACITY NTRL 10K LABEL, ENGLISH-FRENCH	1	--
10	5905940	PRODUCT DATA LABEL	1	--
11	5905950	SERIAL TAG A	1	--
12	5905653	LABEL: ALI-ALCTV-2017 COLD LABEL US: MET LABS	1	--
13	5905414	GP/XPR LOCK-RELEASE LABEL	1	--
14	5905285	SERIALTAG EXTERIOR PEEL OFF INVENTORY LABEL	1	--
15	5905377	NOTICE LABEL, ALI/WLSIA01	1	--

DO NOT SCALE DRAWING		NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 92060
DRAWN	TM	05/10/2018		
CHECKED	OR	11/05/2020		
DIMENSIONS ARE IN MM		THIRD ANGLE PROJECTION		TITLE: XPR-10XLS PRODUCTION LIFT VER E
	<small>PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK INC. ANY REPRODUCTION OR TRANSMISSION OF THIS DRAWING WITHOUT THE WRITTEN PERMISSION OF BENDPAK INC. IS PROHIBITED.</small>			SEE DWG. NO. <b>A</b> 5260193
				REV <b>K</b>
				SCALE: 1:30 SHEET 1 OF 3







**BP BendPak.**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 93060

TITLE: XPR-10XLS-181  
PRODUCTION LIFT VER E

SIZE	DWG. NO.	REV
A	5260239	J

SCALE: 1:45 SHEET 2 OF 3




**BP BendPak.**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 93060

TITLE: XPR-10XLS-181-LP  
PRODUCTION LIFT VER E

SIZE	DWG. NO.	REV
A	5260243	H

SCALE: 1:45 SHEET 2 OF 3




**BP BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10XLS PARTS BOX**

SIZE DWG. NO. REV  
**A 5250203 E**

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10XLS  
 XPR-10XLS-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174518	D2-12/15, XPR CLEARFLOOR PARTS BAG	1	N
2	5505116	XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595444	CABLE ASSEMBLY Ø10 x 10533mm DBST	2	B
4	5570075	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2451mm SB	1	D
5	5570076	HYDRAULIC HOSE ASSEMBLY Ø10 x 1371mm SB	1	D
6	5570095	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 8472 SB	1	B
7	5570176	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 330mm DS	1	F
8	5595100	XPR-10XLS/AXLS Ø2.4 x 8077 SAFETY CABLE	1	B
9	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
10	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
11	5715003	POWER UNIT VIBRATION DAMPENER	1	B
12	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
13	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
14	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
15	5736604	D2-12/15/GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
16	5716174	D2-12/15/GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
17	5746192	ARM ADAPTER, MEDIUM	4	D
18	5540281	C RING Ø38mm OD 5103-150	4	-
19	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
20	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
21	5550095	FTG NPL -04 JIC x -04 JIC	1	-
22	5530337	AB 3/4" x 6.3"	12	-
23	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
24	5525150	SPDT MICRO SWITCH:H:25A@125VAC	1	-
25	5525112	MICRO SWITCH COVER-5PA2	1	-
26	5520116	14-4 SJO UL 62 CABLE 300vac	3940mm*	-
27	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

NAME DATE  
 DRAWN TM 10/12/2018  
 CHECKED OR 10/15/2020

DIMENSIONS ARE IN MM

THIRD ANGLE PROJECTION


**BP BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10XLS PARTS BOX**

SIZE DWG. NO. REV  
**A 5250203 E**

SCALE: 1:30 SHEET 1 OF 2

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS  
 THE SOLE PROPERTY OF BENDPAK INC. AND  
 IS TO BE USED FOR THE MANUFACTURE OF THE  
 PRODUCTS IDENTIFIED THEREIN. NO REUSE OR  
 REPRODUCTION OF THIS DRAWING WITHOUT  
 THE WRITTEN PERMISSION OF BENDPAK INC. IS  
 FORBIDDEN.



**BendPak.**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 93050

TITLE: XPR-10XLS EXTENDED PARTS BOX

SIZE	DWG. NO.	REV
A	5250252	E

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
XPR-10XLS-181  
XPR-10XLS-181-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174218	XPR CLEARFLOOR EXTENDED PARTS BAG	1	N
2	5505116	XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595554	CABLE ASSEMBLY Ø10 x 1.175mm DBST	2	B
4	5570075	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2451mm SB	1	D
5	5570076	HYDRAULIC HOSE ASSEMBLY Ø10 x 1371mm SB	1	D
6	5595553	XPR-10XLS/10AXLS EXTENDED Ø2.4 x 9296mm SAFETY CABLE	1	A
7	5570096	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 9691mm SB	1	B
8	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
9	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
10	5715003	POWER UNIT VIBRATION DAMPENER	1	B
11	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
12	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
13	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
14	5716173	D2-12/15/GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
15	5716174	D2-12/15/GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
16	5746192	ARM ADAPTER, MEDIUM	4	D
17	5540281	C RING Ø38mm OD 5103-150	4	-
18	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
19	5525150	SPDT MICRO SWITCH:25A@125VAC	1	-
20	5525112	MICRO SWITCH COVER-5PA2	1	-
21	5520116	14-4 SJO UL 62 CABLE 300vac	4550mm*	-
22	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
23	5570176	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 330mm DS	1	F
24	5550095	FTG NPL-04 JIC x-04 JIC	1	-
25	5530337	AB 3/4" x 6.3"	12	-
26	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
27	5701640	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

DRAWN	TIM	DATE
CHECKED	OR	10/15/2020

**BendPak.**  
1645 LEMONWOOD DR.  
SANTA PAULA, CA 93050

DIMENSIONS ARE IN MM




THIRD ANGLE PROJECTION



TITLE: XPR-10XLS EXTENDED PARTS BOX

SIZE	DWG. NO.	REV
A	5250252	E

SCALE: 1:30 SHEET 1 OF 2




WHERE USED  
 XPR-10AXLS  
 XPR-10AXLS-181  
 XPR-10AXLS-LP  
 XPR-10AXLS-181-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5215442	XPR-10XLS/AXLS POWER SIDE POST ASSEMBLY	1	K
2	5215440	XPR-10XLS/AXLS OFF SIDE POST ASSEMBLY	1	K
3	5210211	XPR-10A TOP TROUGH ASSEMBLY	1	C



DO NOT SCALE DRAWING	NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 93060
DRAWN	HG	10/07/2015	
CHECKED	OR	11/9/2020	
DIMENSIONS ARE IN MM	THIRD ANGLE PROJECTION	TITLE:	XPR-10AXLS LIFT SUPERSTRUCTURE
 <small>PROPRIETARY AND CONFIDENTIAL          THE INFORMATION CONTAINED IN THIS DRAWING IS          THE SOLE PROPERTY OF BENDPAK INC. ANY          REPRODUCTION IN PART OR AS A WHOLE WITHOUT          THE WRITTEN PERMISSION OF BENDPAK INC. IS          PROHIBITED.</small>	SIZE	DWG. NO.	REV
	A	5245045	K
SCALE: 1:30			SHEET 1 OF 1





ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5245045	XPR-10AXLS LIFT SUPERSTRUCTURE	1	K
2	5230083	XPR-10AXLS PARTS BOX	1	E
3	5215286	XPR-10AS LOW PROFILE LONG ARM ASSEMBLY, R.H.	1	K
4	5215285	XPR-10AS LOW PROFILE LONG ARM ASSEMBLY, L.H.	1	K
5	5215284	XPR-10AS LOW PROFILE TRIPLE TELESCOPING ARM ASSEMBLY	2	L
6	5905109	WARNING ALI/WL 101	1	-
7	5905131	2 POST DECAL KIT, LESS ALI	1	E
8	5905403	MAX CAPACITY 10K DANGER LABEL, ENGLISH-FRENCH	1	-
9	5905465	MANUFACTURER LABEL	1	-
10	5905940	PRODUCT DATA LABEL	1	-
11	5905950	SERIAL TAG A	1	-
12	5905653	LABEL; ALI-ALCTV-2017 GOLD LABEL, US; MET LABS	1	-
13	5905414	GP/XPR LOCK-RELEASE LABEL	1	-
14	5905285	SERIALTAG EXTERIOR PEEL OFF INVENTORY LABEL	1	-
15	5905655	MAX CAPACITY NTRL 10K LABEL, ENGLISH-FRENCH	1	-
16	5905377	NOTICE LABEL, ALI/WLSIA01	1	-



DO NOT SCALE DRAWING	NAME	DATE	<b>BendPak</b> 1645 LEMONWOOD DR. SANTA PAULA, CA 93060
DRAWN	HG	10/08/2015	
CHECKED	OR	11/6/2020	
DIMENSIONS ARE IN MM	THIRD ANGLE PROJECTION	TITLE:	XPR-10AXLS PRODUCTION LIFT VER E
 <small>PROPRIETARY AND CONFIDENTIAL          THE INFORMATION CONTAINED IN THIS DRAWING IS          THE SOLE PROPERTY OF BENDPAK INC. ANY          REPRODUCTION IN PART OR AS A WHOLE WITHOUT          THE WRITTEN PERMISSION OF BENDPAK INC. IS          PROHIBITED.</small>	SIZE	DWG. NO.	REV
	A	5260120	Z
SCALE: 1:35			SHEET 1 OF 3





<b>BendPak</b>	
1645 LEMONWOOD DR. SANTA PAULA, CA 93050	
TITLE: XPR-10AXLS PRODUCTION LIFT VER E	
SIZE: DWG. NO.	REV
A 5260120	Z
SCALE: 1:45	SHEET 2 OF 3




<b>BendPak</b>	
1645 LEMONWOOD DR. SANTA PAULA, CA 93050	
TITLE: XPR-10AXLS-LP PRODUCTION LIFT VER E	
SIZE: DWG. NO.	REV
A 5260244	H
SCALE: 1:45	SHEET 2 OF 3



<b>BP BendPak.</b>		
1445 LEMONWOOD DR. SANTA PAULA, CA 92060		
TITLE: XPR-10AXLS-181 PRODUCTION LIFT VER F		
SIZE	DWG. NO.	REV
<b>A</b>	5260234	<b>J</b>
SCALE: 1:45		SHEET 2 OF 3



<b>BP BendPak.</b>		
1445 LEMONWOOD DR. SANTA PAULA, CA 92060		
TITLE: XPR-10AXLS-181-LP PRODUCTION LIFT VER F		
SIZE	DWG. NO.	REV
<b>A</b>	5260245	<b>H</b>
SCALE: 1:45		SHEET 2 OF 3



**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10AXLS PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	<b>5250083</b>	<b>E</b>

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10AXLS  
 XPR-10AXLS-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174518	D2-12/15, XPR CLEARFLOOR PARTS BAG	1	N
2	5303116	XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5393086	CABLE ASSEMBLY Ø10 x 1045mm DBST	1	D
4	5393087	CABLE ASSEMBLY Ø10 x 10372mm DBST	1	D
5	5570075	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2451mm SB	1	D
6	5570076	HYDRAULIC HOSE ASSEMBLY Ø10 x 1371mm SB	1	D
7	5951000	XPR-10XLS/AXLS Ø2.4 x 8077 SAFETY CABLE	1	B
8	5570077	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 8547 SB	1	C
9	5570065	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 203mm DS	1	D
10	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
11	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
12	5715003	POWER UNIT VIBRATION DAMPENER	1	B
13	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
14	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
15	5716173	D2-12/15/GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
16	5716174	D2-12/15/GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
17	5746192	ARM ADAPTER, MEDIUM	4	D
18	5540281	C RING- Ø38mm OD 5103-150	4	-
19	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
20	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
21	5550095	FTG NPL -04 JIC x -04 JIC	1	-
22	5530337	AB 3/4" x 6.3"	12	-
23	5525150	SPDT MICRO SWITCH:25A@125VAC	1	-
24	5525112	MICRO SWITCH COVER-5PA2	1	-
25	5520116	14-4 SJO UL 62 CABLE 300vac	3940mm*	-
26	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	-
27	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A
28	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B

DO NOT SCALE DRAWING

NAME	DATE
DRAWN	10/10/2018
CHECKED	OR 10/19/2020

DIMENSIONS ARE IN MM

THIRD ANGLE PROJECTION

**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE:  
**XPR-10AXLS PARTS BOX**

SIZE	DWG. NO.	REV
<b>A</b>	<b>5250083</b>	<b>E</b>

SCALE: 1:35 SHEET 1 OF 2

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BENDPAK, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BENDPAK, INC. IS PROHIBITED.



**BendPak**  
 1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10AXLS  
 EXTENDED PARTS BOX

SIZE DWG. NO. REV  
 A 5250236 E

SCALE: 1:25 SHEET 2 OF 2



WHERE USED  
 XPR-10AXLS-181  
 XPR-10AXLS-181-LP

ITEM NO	PART NUMBER	DESCRIPTION	QTY	REV
1	5174218	XPR CLEARFLOOR EXTENDED PARTS BAG	1	N
2	5505116	D2-BF, XPR-9/10 LIFT HEAD PIN WELDMENT	4	D
3	5595556	CABLE ASSEMBLY Ø10 x 11675mm DBST	1	B
4	5595557	CABLE ASSEMBLY Ø10 x 11791mm DBST	1	B
5	5570065	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 203mm DS	1	D
6	5570075	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 2451mm SB	1	D
7	5570076	HYDRAULIC HOSE ASSEMBLY Ø10 x 1371mm SB	1	D
8	5595553	XPR-10XLS/10AXLS EXTENDED Ø2.4 x 9296mm SAFETY CABLE	1	A
9	5570097	HYDRAULIC HOSE ASSEMBLY Ø6.35 x 9766mm SB	1	B
10	5210196	D2/XPR POWER SIDE INCLINED SAFETY ASSEMBLY	1	C
11	5210010	D2/XPR OFF SIDE SAFETY WELDMENT	1	F
12	5715003	POWER UNIT VIBRATION DAMPENER	1	B
13	5215704	ROUND ADJUSTABLE LIFT PAD ASSEMBLY	4	H
14	5701631	XPR-10 POST ASSEMBLY LIFT HEAD FOOT GUARD	2	B
15	5736604	TWO POST LIGHT DUTY BOLT ON ARM RESTRAINT GEAR	4	E
16	5716173	D2-8/12/15, GP/XPR POWER SIDE PLASTIC SAFETY COVER	1	B
17	5716174	D2-8/12/15, GP/XPR OFF SIDE PLASTIC SAFETY COVER	1	B
18	5746192	ARM ADAPTER, MEDIUM	4	D
19	5540281	C RING Ø38mm OD 5103-150	4	--
20	5746167	DOUBLE THREADED ROD M10 x 1.5 x 275	2	B
21	5716634	D2/10AP/XPR MICROSWITCH COVER, PLASTIC	1	B
22	5550095	FTG NPL-04 JIC x-04 JIC	1	--
23	5530337	AB 3/4" x 6.3"	12	--
24	5900951	XPR-10S SERIES INSTALLATION MANUAL	1	--
25	5525150	SPDT MICRO SWITCH:25A@125VAC	1	--
26	5525112	MICRO SWITCH COVER-5PA2	1	--
27	5520116	14-4 SJO UL 62 CABLE 300vcc	4550mm*	--
28	5701660	10PA/D2-12/15/XPR HEIGHT ADAPTER HOLDER	2	A

DO NOT SCALE DRAWING

DRAWN TM 10/15/2018

CHECKED OR 10/19/2020

THIRD ANGLE PROJECTION

DIMENSIONS ARE IN MM



NAME DATE

1645 LEMONWOOD DR.  
 SANTA PAULA, CA 93060

TITLE: XPR-10AXLS  
 EXTENDED PARTS BOX

SIZE DWG. NO. REV

A 5250236 E

SCALE: 1:30 SHEET 1 OF 2

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS  
 THE SOLE PROPERTY OF BENDPAK, INC. ANY  
 REPRODUCTION IN PART OR AS A WHOLE WITHOUT  
 THE WRITTEN PERMISSION OF BENDPAK, INC. IS  
 PROHIBITED.



# EC Type-Examination Certificate



(Fm 210-017, Rev.10)

For the requirements of the Machinery Directive 2006/42/EC

For Annex IV machinery

**Certificate No.:** CE-C-20120209-01-08-5E  
**Date of first issue:** 2014.01.27  
**Date of last review:** 2019.01.27  
**Date of next review:** 2024.01.26

**NAME AND ADDRESS OF THE MANUFACTURER:** Bendpak Inc.  
 1645 E. Lemonwood Drive, Santa Paula, CA, United States of America

**PRODUCT DESCRIPTION/ TYPE AND MODEL:** Range of 10,000lb (4536kg) 2 post vehicle servicing lifts. Top bar  
 XPR-10S Symmetric 145 H x 132/145W x 69Lift in + Extended  
 XPR-10S-168 Symmetric 168 H x 132/145W x 69Lift in  
 XPR-10S-LP Symmetric 145 H x 132/145W x 69Lift in  
 XPR-10S-LP-168 Symmetric 168 H x 132/145W x 69Lift in  
 XPR-10TS-168 Symmetric 168 H x 132/145W x 69Lift in

**APPLICABLE STANDARDS:** EN1493:2010 Vehicle Lifts  
 EN 60204-1:2006+A1:2009 Safety of machinery - Electrical equipment of machines - Part1:General requirements

**A COPY IS AVAILABLE FROM:** CCQS UK Ltd., 5 Harbour Exchange, London, E14 9GE, UK

**RE-ISSUE HISTORY**  
 CE-C-20120209-01-08-5A first issue  
 CE-C-20120209-01-08-5B reissued to update XPR-10 range  
 CE-C-20120209-01-08-5C reissued with renamed XPR range  
 CE-C-20120209-01-08-5D reissued with revised certificate template  
 CE-C-20120209-01-08-5E This issue – 5 year review  
 4 x Asymmetric AS models and XPR-10TS removed

*The technical file, accompanying documentation and the equipment which they describe have been found to be in compliance with the requirements of the Machinery Directive 2006/42/EC.*

*The responsible person defined above has responsibility for ensuring that all future serial manufacture of the machinery conforms to the sample submitted for EC type-examination referenced above.*

*Any changes to the design of the machinery certified here must be advised to CCQS UK Ltd. for re-assessment.*

*A CE marking should not be fixed to the equipment until the requirements of all relevant directives have been met.*

**Approved by:** Owen Bian – Office Manager

**Date:** 2019.01.27

Appointed by UK Government  
as a Notified Body  
for CE Marking No. 1105

**CCQS UK Ltd.,**  
5 Harbour Exchange, Canary Wharf,  
London, E14 9GE, UK  
Tel: +44 (0) 20 7868 1509  
Email [info@ccqs.co.uk](mailto:info@ccqs.co.uk)  
If in any doubt about the integrity of this certificate,  
please verify it on our website at  
<http://www.ccqs.co.uk>





# EC Type-Examination Certificate



(Fm 210-017, Rev.10)

For the requirements of the Machinery Directive 2006/42/EC

For Annex IV machinery

**Certificate No.:** CE-C-20120209-01-13-5A  
**Date of first issue:** 2019.05.30  
**Date of next review:** 2024.05.29

**NAME AND ADDRESS OF THE MANUFACTURER:** Bendpak Inc.  
 1645 E. Lemonwood Drive, Santa Paula, CA, United States of America

**PRODUCT DESCRIPTION/ TYPE AND MODEL:** Range of 12,000lb (5443kg) 2 post vehicle servicing lifts  
 Clear floor (top bar)  
 XPR-10XLS  
 XPR-10AXLS

**APPLICABLE STANDARDS:** EN1493:2010 Vehicle Lifts  
 EN 60204-1:2006+A1:2009 Safety of machinery - Electrical equipment of machines - Part1:General requirements

**A COPY IS AVAILABLE FROM:** CCQS UK Ltd., 5 Harbour Exchange, London, E14 9GE, UK  
**RE-ISSUE HISTORY** CE-C-20120209-01-13-5A first issue

*The technical file, accompanying documentation and the equipment which they describe have been found to be in compliance with the requirements of the Machinery Directive 2006/42/EC.*

*The responsible person defined above has responsibility for ensuring that all future serial manufacture of the machinery conforms to the sample submitted for EC type-examination referenced above.*

*Any changes to the design of the machinery certified here must be advised to CCQS UK Ltd. for re-assessment.*

*A CE marking should not be fixed to the equipment until the requirements of all relevant directives have been met.*

**Approved by:** Owen Bian – Office Manager 

**Date:** 2019.05.30

Appointed by UK Government  
 as a Notified Body  
 for CE Marking No. 1105

**CCQS UK Ltd.,**  
 5 Harbour Exchange, Canary Wharf,  
 London, E14 9GE, UK  
 Tel: +44 (0) 20 7868 1509  
 Email [info@ccqs.co.uk](mailto:info@ccqs.co.uk)  
 If in any doubt about the integrity of this certificate,  
 please verify it on our website at  
<http://www.ccqs.co.uk>



# Automotive Lift Institute (ALI) Store

You probably checked the [ALI's Directory of Certified Lifts](http://www.autolift.org/ali-directory-of-certified-lifts/) (www.autolift.org/ali-directory-of-certified-lifts/) before making your most recent Lift purchase, but did you know the **ALI Store** (www.autolift.org/ali-store/) offers a wide variety of professional, easy-to-use, and reasonably priced training and safety materials that will make your garage a safer place to work?


The ALI Store is your trusted source for workplace safety!




**Lifting It Right Online Certificate Course.** Make *sure* you and your people are lifting vehicles the right way.




**KPA Online Training Subscription.** Get all of your people up to speed on automotive industry topics.



**ANSI/ALI ALOIM Standard for Automotive Lifts.** Safety Requirements for Operation, Inspection, and Maintenance.




**ANSI/ALI ALIS Standard.** Safety Requirements for Installation and Service.



**Guide to Hitting Vehicle Lifting Points for Frame-Engaging Lifts.** Don't eyeball your lifting points, *know* where they are.



**Lift Operator Safety Materials.** Five safety documents in a single package.



**Lifting It Right.** A hardcopy version of the *Lifting It Right* safety manual from the Automotive Lift Institute.



**Uniform Warning Labels and Placards for 2-Posts.** Labels in Mandarin, French Canadian, and Spanish are also available.



**Safety Tips Card.** Reminds your people of 13 key safety tips to follow daily.

**Visit today and get the training and materials you need to work safely:**  
[www.autolift.org/ali-store/](http://www.autolift.org/ali-store/).



1645 Lemonwood Drive  
Santa Paula, CA 93060 USA