



If the lifting points of the vehicle contact the lift 6" or less from the inside edge of the runways, you **MUST** use cross support bars. (Without support bars, damage may occur)