

DEF EXTRACTOR

Operating Instructions



EXTRACTION

1. Connect the machine to a 12-volt power source.
The red light will indicate the machine is connected to power.
2. Insert the plastic draw tube into the DEF tank until it reaches the bottom.
3. Open the ball valve on the extraction hose.
4. Turn the switch to the "SUCTION" position to begin extraction.
5. Once the DEF tank is empty, turn the switch to the "OFF" position.
The red light will stay luminated to indicate the machine is still connected to power.
6. Close the ball valve on the extraction hose.
7. Remove the draw tube from the DEF tank and hang the extraction hose on the provided hanger.
8. Disconnect the machine from the 12-volt power source and hang the power cables on the provided hanger.
9. To drain the machine's waste fluid tank, open the ball valve located on the lower rear of the tank.
10. When finished draining, close the ball valve.

WASTE FLUID TANK DRAIN

1. Open the ball valve located on the lower rear of the tank.
2. When finished draining, close the ball valve.

PREVENTATIVE MAINTENANCE

DEF will crystalize over time. After each use, to keep the machine clean, use the extraction instructions using water to flush the line, pump, and waste fluid tank. Then drain.